

# OPEL COMBO

Owner's Manual





---

# Contents

Introduction .....	2
In brief .....	6
Keys, doors and windows .....	20
Seats, restraints .....	33
Storage .....	57
Instruments and controls .....	65
Lighting .....	95
Climate control .....	102
Driving and operating .....	108
Vehicle care .....	133
Service and maintenance .....	168
Technical data .....	171
Customer information .....	181
Index .....	184

## Introduction

Fuel	Designation	<input type="text"/>		
Engine oil	Grade	<input type="text"/>		
	Viscosity	<input type="text"/>		
Tyre pressure	Tyre size		Front	Rear
	Summer tyres	<input type="text"/>	<input type="text"/>	<input type="text"/>
	Winter tyres	<input type="text"/>	<input type="text"/>	<input type="text"/>
Weights	Gross vehicle weight rating	<input type="text"/>		
	- Kerb weight, basic model	<input type="text"/>		
	= Loading	<input type="text"/>		

## Vehicle specific data

Please enter your vehicle's data on the previous page to keep it easily accessible. This information is available in the sections "Service and maintenance" and "Technical data" as well as on the identification plate.

## Introduction

Your vehicle is a designed combination of advanced technology, safety, environmental friendliness and economy.

This Owner's Manual provides you with all the necessary information to enable you to drive your vehicle safely and efficiently.

Make sure your passengers are aware of the possible risk of accident and injury which may result from improper use of the vehicle.

You must always comply with the specific laws and regulations of the country that you are in. These laws may differ from the information in this Owner's Manual.

When this Owner's Manual refers to a workshop visit, we recommend your Opel Service Partner. For gas vehicles we recommend an Opel Repairer authorised for servicing gas vehicles.

All Opel Service Partners provide first-class service at reasonable prices. Experienced mechanics trained by Opel work according to specific Opel instructions.

The customer literature pack should always be kept ready to hand in the vehicle.

## Using this manual

- This manual describes all options and features available for this model. **Certain descriptions, including those for display and menu functions, may not apply to your vehicle due to model variant, country specifications, special equipment or accessories.**
- The "In brief" section will give you an initial overview.

- The table of contents at the beginning of this manual and within each section shows where the information is located.
- The index will enable you to search for specific information.
- This Owner's Manual depicts left-hand drive vehicles. Operation is similar for right-hand drive vehicles.
- The Owner's Manual uses the factory engine designations. The corresponding sales designations can be found in the section "Technical data".
- Directional data, e.g. left or right, or front or back, always relate to the direction of travel.
- The vehicle display screens may not support your specific language.
- Display messages and interior labelling are written in **bold** letters.

## Danger, Warnings and Cautions

### **Danger**

Text marked ** Danger** provides information on risk of fatal injury. Disregarding this information may endanger life.

### **Warning**

Text marked ** Warning** provides information on risk of accident or injury. Disregarding this information may lead to injury.

### **Caution**

Text marked **Caution** provides information on possible damage to the vehicle. Disregarding this information may lead to vehicle damage.

## Symbols

Page references are indicated with ⇨.  
⇨ means "see page".

We wish you many hours of pleasurable driving.

**Adam Opel AG**



## In brief

### Initial drive information

#### Vehicle unlocking

##### Unlocking with key



Turn the key in the driver's door lock towards the front of the vehicle.

#### Unlocking with radio remote control



Press  to unlock the vehicle.


Press  to unlock the load compartment only.

Open the doors by pulling the handles. To open the tailgate, press the button under the tailgate handle.

Radio remote control ⇨ 21, Central locking system ⇨ 22, Load compartment ⇨ 26, Power windows ⇨ 30.

## Seat adjustment

### Seat positioning



Pull handle, slide seat, release handle.


Try to move the seat back and forth to ensure that the seat is locked in place.

Seat position ⇨ 34, Seat adjustment ⇨ 35.

### **⚠ Danger**

Do not sit nearer than 25 cm from the steering wheel, to permit safe airbag deployment.


### Seat backrests



Turn handwheel. Do not lean on backrest when adjusting.

Seat position ⇨ 34, Seat adjustment ⇨ 35.

### Seat height




Lever pumping motion

up : higher  
down : lower

Operate lever and adjust body weight on seat to raise or lower it.

Seat position ⇨ 34, Seat adjustment ⇨ 35.

## Head restraint adjustment



Press release catch, adjust height, engage.

Head restraints ⇨ 33.

## Seat belt




Pull out the seat belt and engage in belt buckle. The seat belt must not be twisted and must fit close against the body. The backrest must not be tilted back too far (maximum approx. 25 °).

To release belt, press red button on belt buckle.

Seat position ⇨ 34, Seat belts ⇨ 42, Airbag system ⇨ 45.

## Mirror adjustment

### Interior mirror




Adjust the lever on the underside to reduce dazzle.

Interior mirror ⇨ 29.


## Exterior mirrors

### Manual adjustment



Swivel lever in required direction.

### Electric adjustment




Select the relevant exterior mirror by turning the control to left ◀ or right ▶. Then swivel the control to adjust the mirror.

In position ● no mirror is selected.

Convex exterior mirrors ⇨ 28,  
Electric adjustment ⇨ 28, Folding  
exterior mirrors ⇨ 29, Heated  
exterior mirrors ⇨ 29.

## Steering wheel adjustment




Unlock the lever, adjust the steering wheel, then engage lever and ensure it is fully locked.


Do not adjust steering wheel unless vehicle is stationary and the steering wheel lock has been released.

Airbag system ⇨ 45, Ignition positions ⇨ 109.

## Instrument panel overview



1	Fixed air vents .....	106	Front fog lights .....	97
2	Side air vents .....	106	Rear fog light .....	97
3	Light switch .....	95	Heated rear window .....	32
	Turn and lane-change signals, headlight flash, low beam and high beam .....	97	Heated exterior mirrors .....	29
4	Instruments .....	71	9 Front passenger airbag .....	49
	Driver Information Centre .....	86	10 Glovebox .....	58
5	Windscreen wiper, windscreen washer system, rear window wiper/washer .....	67	11 Climate control system .....	102
	Trip odometer reset .....	71	Electronic climate control system .....	104
6	Centre air vents .....	106	12 Selector lever, manual transmission .....	115
7	Document holder, pocket for Personal Navigation Device .....	57	Manual transmission automated .....	116
8	Headlight range adjustment .....	96	13 Ignition switch with steering wheel lock .....	109
	Driver Information Centre controls .....	86	14 Steering wheel controls .....	66
	Trip computer .....	92	15 Horn .....	66
	Instrument illumination .....	98	Driver airbag .....	49
	Hazard warning flashers .....	96	16 Steering wheel adjustment . .	66
			17 Cruise control .....	123
			18 Fuse box .....	149
			19 Bonnet release lever .....	135



## Exterior lighting



Turn light switch:

- : off / daytime running lights
- ☉ : sidelights / headlights

Lighting ⇨ 95, Daytime running lights ⇨ 96.


## Fog lights



Press light switch:

- ☉ : front fog lights
- ☉ : rear fog light


## Headlight flash, high beam and low beam



- headlight flash : pull lever
- high beam : push lever
- low beam : pull lever

High beam ⇨ 95, Headlight flash ⇨ 95.

### Turn and lane-change signals



lever up : right turn signal  
lever down : left turn signal

Turn and lane-change signals  
↪ 97.

### Hazard warning flashers



Operated by pressing .  
Hazard warning flashers ↪ 96.


### Horn



Press .

## Washer and wiper systems

### Windscreen wiper




Twist lever:

- : off
- ⏏ : intermittent wiping
- ⏏ : slow
- ⏏ : fast

For a single wipe when the windscreen wiper is off, move the lever up.

Windscreen wiper ↻ 67, Wiper blade replacement ↻ 140.


### Windscreen and headlight washer systems



Pull lever.

Windscreen and headlight washer system ↻ 67, Washer fluid ↻ 138.

### Rear window wiper and washer systems



Twist band to activate the rear window wiper.

The rear window wiper comes on automatically when the windscreen wiper is switched on and reverse gear is engaged.

Push lever: Washer fluid is sprayed on the rear window and the wiper wipes a few times.

Rear window wiper/washer ↻ 67.

## Climate control

Heated rear window, heated exterior mirrors



The heating is operated by pressing .

Heated rear window ⇨ 32.

## Demisting and defrosting the windows

Air conditioning system



Set the temperature control to warmest level.

Set fan speed to highest level.

Set air distribution control to .

Cooling  on.

Heated rear window  on.

## Electronic climate control system



Press .


Temperature and air distribution are set automatically and the fan runs at a high speed.

To return to automatic mode: press  or **AUTO**.

Climate control system ⇨ 102,  
Electronic climate control system  
⇨ 104.

## Transmission

### Manual transmission




Reverse: with the vehicle stationary, wait 3 seconds after depressing the clutch pedal, pull up the collar on the selector lever and engage the gear.

If the gear does not engage, set the lever to neutral, release the clutch pedal and depress again; then repeat gear selection.

Manual transmission ⇨ 115.

### Manual transmission automated



**N** : neutral position

● : drive position

**+** : higher gear

**-** : lower gear

**A/M** : switch between automatic and manual mode

**R** : reverse gear (with selector lever lock)


Manual transmission automated  
⇨ 116.

## Starting off

### Check before starting-off

- Tyre pressure and condition  
⇨ 152, ⇨ 180.
- Engine oil level and fluid levels  
⇨ 136.
- All windows, mirrors, exterior lighting and number plates are free from dirt, snow and ice and are operational.
- Proper position of mirrors, seats, and seat belts ⇨ 28, ⇨ 34, ⇨ 43.
- Brake function at low speed, particularly if the brakes are wet.

## Starting the engine




- Turn key to position 1.
- Move the steering wheel slightly to release the steering wheel lock.
- Operate clutch and brake.
- Manual transmission automated: operate brake, the transmission automatically shifts to **N** (neutral).
- Do not operate accelerator pedal.

- Diesel engines: turn the key to position 1 for preheating and wait until control indicator  goes out.
- Turn key to position 2 and release.

Starting the engine ⇨ 110.

## Stop-start system



If the vehicle is at a low speed or at a standstill and certain conditions are fulfilled, activate an Autostop as follows:

- Depress the clutch pedal.
- Set the lever in neutral.
- Release the clutch pedal.

An Autostop is indicated when  is displayed in the Driver Information Centre (DIC) ⇨ 86.

To restart the engine, depress the clutch pedal again.

Stop-start system ⇨ 111.

## Parking

### Warning

- Do not park the vehicle on an easily ignitable surface. The high temperature of the exhaust system could ignite the surface.
- Always apply parking brake without pressing release button. Apply as firmly as possible on a downhill slope or uphill slope. Depress brake pedal at the same time to reduce operating force.
- Switch off the engine. Turn the ignition key to position 0 and remove it. Turn the steering wheel until the steering wheel lock is felt to engage.
- If the vehicle is on a level surface or uphill slope, engage first gear before switching off the ignition. On an uphill slope, turn the front wheels away from the kerb.

If the vehicle is on a downhill slope, engage reverse gear before switching off the ignition. Turn the front wheels towards the kerb.

- Close the windows.
- Lock the vehicle with  on the radio remote control.
- The engine cooling fans may run after the engine has been switched off ⇨ 135.

### Caution

After running at high engine speeds or with high engine loads, operate the engine briefly at a low load or run in neutral for approx. 30 seconds before switching off, in order to protect the turbocharger.

Keys, locks ⇨ 20, Laying the vehicle up for a long period of time ⇨ 134.

## Keys, doors and windows

<b>Keys, locks</b> .....	<b>20</b>
Keys .....	20
Car Pass .....	21
Radio remote control .....	21
Door locks .....	22
Central locking system .....	22
Child locks .....	24
<b>Doors</b> .....	<b>24</b>
Sliding door .....	24
Rear doors .....	24
Load compartment .....	26
<b>Vehicle security</b> .....	<b>27</b>
Anti-theft locking system .....	27
Immobiliser .....	27
<b>Exterior mirrors</b> .....	<b>28</b>
Convex shape .....	28
Manual adjustment .....	28
Electric adjustment .....	28
Folding mirrors .....	29
Heated mirrors .....	29
<b>Interior mirrors</b> .....	<b>29</b>
Manual anti-dazzle .....	29

<b>Windows</b> .....	<b>30</b>
Windscreen .....	30
Manual windows .....	30
Power windows .....	30
Rear windows .....	32
Heated rear window .....	32
Sun visors .....	32

## Keys, locks

### Keys

#### Replacement keys

The key number is specified in the Car Pass or on a detachable tag.

The key number must be quoted when ordering replacement keys as it is a component of the immobiliser system.

Locks ⇨ 165.

#### Key with foldaway key section



Press button to extend. To fold the key, first press the button.

## Car Pass

The Car Pass contains security related vehicle data and should therefore be kept in a safe place.

When the vehicle is taken to a workshop, this vehicle data is needed in order to perform certain operations.

## Radio remote control



Used to operate:

- central locking system ⇨ 22
- anti-theft locking system ⇨ 27
- power windows ⇨ 30

The radio remote control has a range of up to 5 metres. It can be restricted by external influences. The hazard warning flashers confirm operation.

Handle with care, protect from moisture and high temperatures and avoid unnecessary operation.

### Fault

If the central locking system cannot be operated with the radio remote control, it may be due to the following:

- range exceeded
- battery voltage too low
- frequent, repeated operation of the radio remote control while not in range
- overload of the central locking system by operating at frequent intervals, the power supply is interrupted for a short time
- interference from higher-power radio waves from other sources

Unlocking ⇨ 22.


## Radio remote control battery replacement

Replace the battery as soon as the range reduces.



Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.

### Key with foldaway key section




Extend the key and remove the battery holder by undoing the screw with a suitable screwdriver. Remove the battery holder from the key and replace the battery (type CR 2032), paying attention to the installation position.

Refit the battery holder in the key and secure the screw.

## Door locks

### Anti-theft security lock



To prevent the front door from being opened from the outside, open the door and engage the anti-theft security lock.

Using a suitable tool, turn the lock switch on the door to locked position **1**. The door cannot be opened from outside.

The anti-theft security lock remains engaged even after unlocking the vehicle with the remote control.

To disengage, turn the switch to unlocked position **2**.

### Central locking system

Unlocks and locks the front doors, sliding side doors and load compartment.

A pull on an interior door handle unlocks and opens the respective door.

For safety reasons, the vehicle cannot be locked if the key is in the ignition switch.

## Unlocking

### Note

In the event of an accident of a certain severity, the vehicle unlocks automatically.

Fuel cut-off system ↪ 92.

### Van



Press : Front doors are unlocked.



Press : Rear doors / tailgate and sliding side doors are unlocked.

### Combi, Combo Tour

Press : All doors, including rear doors / tailgate and sliding side doors are unlocked.

Press : Rear doors / tailgate only are unlocked.

### Note

If engaged, the anti-theft security lock on the door remains engaged even after unlocking the vehicle with the remote control.

Anti-theft security lock ⇨ 22.

### Locking

Close all doors. If the doors are not closed properly, the central locking system will not work.

### Note

If a door or the tailgate is open, control indicator  illuminates in the instrument cluster ⇨ 85.



Press . All doors, including rear doors / tailgate and sliding side doors are locked.

### Automatic locking

The vehicle can be configured to automatically lock the doors when vehicle speed exceeds 20 km/h.

Driver Information Centre (DIC)  
⇨ 86.

### Unlocking the load compartment from inside the vehicle




Press : The load compartment (rear doors / tailgate and sliding side doors) are unlocked.

When the load compartment is locked, the LED in the button is illuminated.

## Child locks

### ⚠ Warning

Use the child locks whenever children are occupying the rear seats.




Using a suitable tool, turn child lock switch on sliding side door towards the horizontal position. The door cannot be opened from inside.

To deactivate, turn the child lock switch to the vertical position.

## Doors

### Sliding door



Pull lever on interior handle and slide door.

### Caution

Ensure the side door is fully closed and secure before driving the vehicle.


Central locking system ⇨ 22.

### Caution


To avoid damage, do not attempt to operate the sliding side door when the fuel filler flap is open.

Refuelling ⇨ 128.


## Rear doors



To open the left hand rear door pull the outside handle.



The door is opened from inside the vehicle by pressing down the interior handle.




The right hand rear door is released using the lever.

#### **⚠ Warning**

The rear lights may be obscured if the rear doors are open and the vehicle is parked on the roadside.

Make other road users aware of the vehicle, by using a warning triangle or other equipment specified in the road traffic regulations.



The doors are retained in the 90° position by locking stays. To open the doors to 180°, push the latch and swing open to the desired position.

#### **⚠ Warning**

Ensure extended opening doors are secured when fully opened.

Opened doors may slam closed due to the force of the wind!


Always close the right hand door before the left hand door.

Central locking system ⇨ 22.

## Load compartment

### Tailgate

#### Opening



Press the button underneath the moulding.

#### **⚠ Danger**

Do not drive with the tailgate open or ajar, e.g. when transporting bulky objects, since toxic exhaust gases, which cannot be seen or

smelled, could enter the vehicle. This can cause unconsciousness and even death.


#### **Caution**

Before opening the tailgate check overhead obstructions, such as a garage door, to avoid damage to the tailgate. Always check the moving area above and behind the tailgate.

#### **Note**

The installation of certain heavy accessories onto the tailgate may affect its ability to remain open.

#### **Closing**




Use the interior handle.

Ensure tailgate is fully closed before driving.

Central locking system ⇨ 22.

### Emergency tailgate opening from inside the vehicle



An access hole (arrowed) enables the tailgate latch to be released using a suitable tool. Push lever to the right to unlock and open the tailgate.

## Vehicle security

### Anti-theft locking system

#### ⚠ Warning

Do not use the system if there are people in the vehicle! The doors cannot be unlocked from the inside.

The system deadlocks all the doors. All doors must be closed otherwise the system cannot be activated.

The system is disabled automatically on every door when:

- unlocking the doors
- turning the ignition switch to position 1

### Activating



Press  on the radio remote control twice.

### Immobiliser

The system is part of the ignition switch and checks whether the vehicle is allowed to be started with the key being used.

The immobiliser is activated automatically after the key has been removed from the ignition switch.

If the control indicator  illuminates when starting, there is a fault in the system; the engine cannot be started. Switch off the ignition and repeat the start attempt.

If  remains illuminated, attempt to start the engine using the spare key and seek the assistance of a workshop.

#### Note

The immobiliser does not lock the doors. Always lock the vehicle after leaving it  22.


Control indicator   84.

## Exterior mirrors

### Convex shape

The convex exterior mirror contains an aspherical area and reduces blind spots. The shape of the mirror makes objects appear smaller, which will affect the ability to estimate distances.


### Manual adjustment



Adjust mirrors by swivelling lever in required direction.

The lower mirrors are not adjustable.


## Electric adjustment



Select the relevant exterior mirror by turning the control to left  or right . Then swivel the control to adjust the mirror.

In position  no mirror is selected.

## Folding mirrors



For pedestrian safety, the exterior mirrors will swing out of their normal mounting position if they are struck with sufficient force. Reposition the mirror by applying slight pressure to the mirror housing.

### Parking position

The exterior mirrors can be folded in by pressing gently on the outer edge of the housing, e.g. when in a confined parking situation.

## Heated mirrors




Operated by pressing .

Heating works with the engine running and is switched off automatically after a short time.

## Interior mirrors

### Manual anti-dazzle



To reduce dazzle, adjust the lever on the underside of the mirror housing.

## Windows

### Windscreen

#### Windscreen stickers

Do not attach stickers such as toll road stickers or similar on the windscreen in the area of the interior mirror.

### Manual windows

The door windows can be opened or closed with the window winders.

### Power windows

#### Warning

Take care when operating the power windows. Risk of injury, particularly to children.

If there are children on the rear seats, switch on the child safety system for the power windows.

Keep a close watch on the windows when closing them. Ensure that nothing becomes trapped in them as they move.

Switch on ignition to operate power windows.



Operate the switch for the respective window by pushing to open or pulling to close.

Pushing or pulling briefly: window moves up or down in stages if the switch is held.

Pushing or pulling firmly and then releasing: window moves up or down fully with safety function enabled. To stop movement, operate the switch once more in the same direction.

With the ignition key removed or in position 0, the windows can be operated for approx. 2 minutes and are deactivated as soon as a door is opened.

### Safety function

If the window glass encounters resistance during automatic closing, it is immediately stopped and opened again.

If the safety function is activated five times in less than a minute, the safety function is deactivated. The windows will only close in stages and not automatically.

Activate the window electronics by opening the windows. The safety function is restored and the windows will operate normally.

## Overload

If the windows are repeatedly operated within short intervals, the window operation is disabled for some time.

## Initialising the power windows

If the windows cannot be closed automatically (e.g. after disconnecting the vehicle battery), activate the window electronics as follows:

1. Close doors.
2. Switch on ignition.
3. Pull switch until the window is closed and keep pulling for an additional 5 seconds.
4. Repeat for each window.

## Child safety system for rear windows




Press  to deactivate rear door power windows.

To activate, press  again.

## Operating windows from outside

The windows can be operated remotely from outside the vehicle when locking or unlocking the vehicle.

Central locking system ⇨ 22.




Press and hold  to open windows.

Press and hold  to close windows.

Release button to stop window movement.

## Rear windows

### Opening rear windows



To open, move lever outwards until the window is fully open.

To close, pull lever then push until window is fully closed.

## Heated rear window



Operated by pressing .

Heating works with the engine running and is switched off automatically after a short time.

## Sun visors

The sun visors can be folded down or swivelled to the side to prevent dazzling.

If the sun visors have integral mirrors, the mirror covers should be closed when driving.

A ticket holder is located on the rear of the sun visor.

## Seats, restraints


<b>Head restraints</b> .....	<b>33</b>
<b>Front seats</b> .....	<b>34</b>
Seat position .....	34
Seat adjustment .....	35
Seat folding .....	36
Armrest .....	37
Heating .....	38
<b>Rear seats</b> .....	<b>38</b>
Second row seats .....	38
Third row seats .....	40
<b>Seat belts</b> .....	<b>42</b>
Three-point seat belt .....	43
<b>Airbag system</b> .....	<b>45</b>
Front airbag system .....	49
Side airbag system .....	50
Airbag deactivation .....	50
<b>Child restraints</b> .....	<b>52</b>
Child restraint systems .....	52
Child restraint installation locations .....	53
ISOFIX child restraint systems ..	56
Top-tether fastening eyes .....	56

## Head restraints

### Position

#### ⚠ Warning

Only drive with the head restraint set to the proper position.



The upper edge of the head restraint should be at upper head level. If this is not possible for extremely tall people, set to highest position, and set to lowest position for small people.

### Adjustment

#### Front head restraints, height adjustment



Press the release catch, adjust height and engage.

### Rear head restraints, height adjustment



Pull the head restraint upwards or press the release catches and push the head restraint downwards.

### Removal

#### Rear head restraints, removal

Press both release catches, pull the head restraint upwards and remove. Secure the removed head restraint in the load compartment.

#### Note

Approved accessories may only be attached if the seat is not in use.

## Front seats

### Seat position

#### ⚠ Warning

Only drive with the seat correctly adjusted.



- Sit with buttocks as far back against the backrest as possible. Adjust the distance between the seat and the pedals so that legs are slightly angled when pressing the pedals. Slide the front passenger seat as far back as possible.
- Sit with shoulders as far back against the backrest as possible. Set the backrest to an angle so that it is possible to reach the steering wheel with arms slightly bent. Maintain contact between shoulders and the backrest when turning the steering wheel. Do not tilt the backrest too far back. We recommend a maximum angle of approx. 25°.
- Adjust the steering wheel ↻ 66.
- Set the seat high enough to have a clear field of vision on all sides and on all display instruments. There should be at least one hand of clearance between head and the roof frame. Thighs should rest lightly on the seat without pressing into it.
- Adjust the head restraint ↻ 33.
- Adjust the height of the seat belt ↻ 43.
- Adjust the lumbar support so that it supports the natural shape of the spine.

## Seat adjustment

Drive only with seats and backrests properly engaged.

### ⚠ Danger

Do not sit nearer than 25 cm from the steering wheel, to permit safe airbag deployment.


### ⚠ Warning

Never adjust seats while driving as they could move uncontrollably.

### ⚠ Warning

Never store any objects under the seats except in the underseat storage compartment ⇨ 58.


## Seat positioning



Pull handle, slide seat, release handle.


Try to move the seat back and forth to ensure that the seat is locked in place.

## Seat backrests



Turn handwheel. Do not lean on backrest when adjusting.

## Seat height



Lever pumping motion

up : higher  
down : lower

Operate lever and adjust body weight on seat to raise or lower it.

## Lumbar support



Adjust lumbar support using handwheel to suit personal requirements.

Rotate handwheel to increase and decrease support.

## Seat folding

### Folding front passenger seat

Depending on version, the front passenger seat can be folded flat to the table position.

Slide the front passenger seat as far back as possible, to avoid contact with the instrument panel during folding.


#### Note

When seat height is in its highest position, push head restraints down before folding backrest.

Ensure that nothing prevents the seat from folding, e.g. sun visor, glovebox.



Pull release levers (1), fold backrest fully forwards then release the levers. Then push the backrest down further until it is completely flat.



Pull the flap (2) located at the base of the backrest and simultaneously push the backrest down as far as possible.

On some versions, there is a single release lever located on the inboard side of the front passenger seat. Pull release lever, fold backrest fully forwards, release lever then push backrest down until it is completely flat. The flap at the base of the backrest is not present on some versions.

#### Note

Do not operate handwheel for backrest inclination when backrest is folded forwards.

#### ⚠ Warning

When the front passenger seat is in the folded position, the front passenger airbag system must be deactivated.

Airbag deactivation ⇨ 50.

#### ⚠ Warning


Always make sure that the load in the vehicle is securely stowed. Otherwise objects can be thrown around inside the vehicle and cause personal injury or damage to the load or vehicle.

#### Unfolding front passenger seat

To restore the seat to the upright position, pull the flap located at the base of the backrest and simultaneously pull up the backrest as far as it will go.

Pull release levers and raise backrest fully then release levers.

#### Armrest



Raise or lower the armrest as required.

## Heating



Activate seat heating by pressing  for the respective front seat. Activation is indicated by the LED in the button.

Press  once more to deactivate seat heating.

Seat heating is thermostatically controlled and switches off automatically when seat temperature is sufficient.

Prolonged use for people with sensitive skin is not recommended.

Seat heating is operational with the ignition on and during an Autostop. Stop-start system ↗ 111.

## Rear seats

### Second row seats

#### Warning


Never adjust seats while driving as they could move uncontrollably.

Depending on version, the load compartment area can be increased by folding the second row seats (where fitted).

If a third row of seats are fitted, refer to "Folding the seats" or "Removing the seats" in the section "Third row seats" ↗ 40 to increase the load compartment area.

### Folding the seats

- Press release catches and push the head restraint downwards ↗ 33.
- Disengage the seat belts and ensure they do not obstruct the seat folding manoeuvre.
- Remove the load compartment cover if necessary ↗ 59.



1. Pull the backrest release lever and fold down the backrest onto the seat cushion.

#### Note


The red mark on the release lever becomes visible when the backrest is disengaged.

#### Note

The backrest is divided into two parts. Both parts can be folded down, if necessary.



2. Pull release lever; the seat base is tensioned and will start to rise automatically.



3. Fold the seat assembly forward completely.

#### Note

A label indicating the seat folding procedure may be located on the outer edge of the seat base.

#### ⚠ Warning

When folding the seat use caution - beware of moving parts. Ensure the seat is secure when completely folded.

#### Unfolding the seats

1. Ensure that the seat belts are disengaged and that they do not obstruct the unfolding manoeuvre.
2. Lower the seat assembly to the floor, ensuring the seat is securely latched into position.
3. Raise the backrest and adjust the head restraint.

#### Note

The backrest is properly engaged when the red mark on the release lever is no longer visible.

**⚠ Warning**

When unfolding the seat, ensure that the seat is securely locked in position before driving. Failure to do so may result in personal injury in the event of hard braking or a collision.

**⚠ Warning**

Only drive the vehicle if the backrests are securely locked into position. Otherwise there is a risk of personal injury or damage to the load or vehicle in the event of hard braking or a collision.

**Third row seats****⚠ Warning**

Never adjust seats while driving as they could move uncontrollably.

Depending on version, the load compartment area can be increased by folding up the third row seats.

**Folding the seats**

- Press release catches and push the head restraint downwards ⇨ 33.
- Disengage the seat belts and ensure they do not obstruct the seat folding manoeuvre.
- Remove the load compartment cover if necessary ⇨ 59.



1. Pull the backrest release lever and fold down the backrest onto the seat cushion.

**Note**

The red mark on the release lever becomes visible when the backrest is disengaged.

2. Pull the lower strap and fold the seat assembly forwards.



3. Secure the folded seat in the upright position by attaching the flexible cord (located on the seat frame) to the head restraint of the seat in front of the folded seat.

**Note**

A label indicating the seat folding procedure may be located on the lower rear part of the backrest.

**⚠ Warning**

When folding the seat use caution - beware of moving parts. Ensure the seat is secure when completely folded.

**⚠ Warning**

No person is allowed to occupy a rear seat when the seat in front is in the folded position. Risk of injury.

**Unfolding the seats**

1. Ensure that the seat belts are disengaged and that they do not obstruct the unfolding manoeuvre.
2. Remove the flexible cord and lower the seat assembly to the floor, ensuring the rear support is located on the anchor point and securely latched into position.
3. Raise the backrest and adjust the head restraint.

**Note**

The backrest is properly engaged when the red mark on the release lever is no longer visible.

**⚠ Warning**

When unfolding the seat, ensure that the seat is securely locked in position before driving. Failure to do so may result in personal injury in the event of hard braking or a collision.


**Removing the seats**

Depending on version, the load compartment area can be increased by removing the third row seats.

**⚠ Warning**

Removable rear seats are heavy! Do not attempt to remove without assistance.

- Press release catches and pull the rear seat head restraints upwards to remove them ⇨ 33.
  - Ensure that the seat belts are disengaged and that they do not obstruct the unfolding manoeuvre.
  - Remove the load compartment cover if necessary ⇨ 59.
1. Fold the seat assembly (refer to "Folding the seats" above).



2. Push the lower lever to disengage the locks and remove the seat assembly from the floor anchor points.
3. Store head restraints on the rear of the seat frame.

### Installing the seats



1. Attach the seat assembly front supports to the front anchor points.
2. Lower the rear of the seat assembly to the floor, ensuring the rear support is located on the anchor point.

3. Push the lower lever and pull it to ensure the locks are engaged and the seat assembly is locked securely in position.
4. Remove head restraints from the rear of the seat frame, then raise the backrest and replace the head restraints.

#### Note

The backrest is properly engaged when the red mark on the release lever is no longer visible.

#### **⚠ Warning**

When installing the rear seats, ensure that the seat assembly is properly located on the anchor points, the locks are fully engaged, and the backrest is returned to the correct position.

Failure to do so may result in personal injury in the event of hard braking or a collision.

## Seat belts



The seat belts are locked during heavy acceleration or deceleration of the vehicle holding the occupants in the sitting position. Therefore the risk of injury is considerably reduced.

#### **⚠ Warning**

Fasten seat belt before each trip.

In the event of an accident, people not wearing seat belts endanger their fellow occupants and themselves.

Seat belts are designed to be used by only one person at a time. Child restraint system ⇨ 52.

Periodically check all parts of the belt system for damage, pollution and proper functionality.

Have damaged components replaced. After an accident, have the belts and triggered belt pretensioners replaced by a workshop.

#### Note

Make sure that the belts are not damaged by shoes or sharp-edged objects or trapped. Prevent dirt from getting into the belt retractors.

Seat belt reminder 🚗 ⇨ 78.

### Belt force limiters

On the front seats, stress on the body is reduced by the gradual release of the belt during a collision.

### Belt pretensioners

In the event of a head-on or rear-end collision of a certain severity, the front seat belts are tightened.

#### ⚠ Warning

Incorrect handling (e.g. removal or fitting of belts) can trigger the belt pretensioners.

Deployment of the belt pretensioners is indicated by continuous illumination of control indicator 🚗 ⇨ 78.


Triggered belt pretensioners must be replaced by a workshop. Belt pretensioners can only be triggered once.

#### Note

Do not affix or install accessories or other objects that may interfere with the operation of the belt pretensioners. Do not make any modifications to belt pretensioner components as this will invalidate the approval of your vehicle.


## Three-point seat belt

### Fastening



Withdraw the belt from the retractor, guide it untwisted across the body and insert the latch plate into the buckle. Tighten the lap belt regularly whilst driving by pulling the shoulder belt.

Seat belt reminder 🚗 ⇨ 78.




Loose or bulky clothing prevents the belt from fitting snugly. Do not place objects such as handbags or mobile phones between the belt and your body.

#### **⚠ Warning**

The belt must not rest against hard or fragile objects in the pockets of your clothing.

#### Height adjustment



1. Pull belt out slightly.
2. Shift the height adjustment upwards or press button down to disengage and push the height adjustment downwards.



Adjust the height so that the belt lies across the shoulder. It must not lie across the throat or upper arm.

Do not adjust while driving.

## Removing



To release belt, press red button on belt buckle.

## Seat belts on the rear seats

The seat belt for the rear centre seat can only be withdrawn from the retractor if the backrest is in the rear position.

## Using the seat belt while pregnant



### Warning

The lap belt must be positioned as low as possible across the pelvis to prevent pressure on the abdomen.

## Airbag system

The airbag system consists of a number of individual systems depending on the scope of equipment.

When triggered, the airbags inflate within milliseconds. They also deflate so quickly that it is often unnoticeable during the collision.

### Note

Depending on the severity of a collision, the fuel system may also be cut-off and the engine switched off automatically, for safety reasons. Resetting the fuel cut-off system; refer to "Fuel system messages" ⇨ 92.

### Note

Expiry dates for replacing the airbag system components may be found on the label inside the glovebox. Contact a workshop to have the airbag system components replaced.

**⚠ Warning**

If handled improperly the airbag systems can be triggered in an explosive manner.

**Note**

The airbag systems and belt pretensioner control electronics are located in the centre console area. Do not put any magnetic objects in this area.

Do not fix any objects onto the airbag covers and do not cover them with other materials.

Each airbag is triggered only once. Have deployed airbags replaced by a workshop. Furthermore, it might be necessary to have the steering wheel, the instrument panel, parts of the panelling, the door seals, handles and the seats replaced.

Do not make any modifications to the airbag system as this will invalidate the vehicle type approval.

**⚠ Warning**

When the airbags inflate, escaping hot gases may cause burns.

Control indicator  for airbag systems  78.

**Fault**

If there is a fault in the airbag and belt tensioner system, the control indicator  illuminates in the instrument cluster. The system is not operational.

Have the cause of the fault remedied by a workshop.

Control indicator   78.

**Child restraint systems on front passenger seat with airbag systems**

Warning according to ECE R94.02:



**EN:** NEVER use a rear-facing child restraint system on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.

**DE:** Nach hinten gerichtete Kindersitze NIEMALS auf einem Sitz verwenden, der durch einen davor befindlichen AKTIVEN AIRBAG geschützt ist, da dies den TOD oder SCHWERE VERLETZUNGEN DES KINDES zur Folge haben kann.

**FR:** NE JAMAIS utiliser un siège d'enfant orienté vers l'arrière sur un siège protégé par un COUSSIN GONFLABLE ACTIF placé devant lui,

sous peine d'infliger des BLESSURES GRAVES, voire MORTELLES à l'ENFANT.

**ES:** NUNCA utilice un sistema de retención infantil orientado hacia atrás en un asiento protegido por un AIRBAG FRONTAL ACTIVO. Peligro de MUERTE o LESIONES GRAVES para el NIÑO.

**RU:** ЗАПРЕЩАЕТСЯ устанавливать детское удерживающее устройство лицом назад на сиденье автомобиля, оборудованном фронтальной подушкой безопасности, если ПОДУШКА НЕ ОТКЛЮЧЕНА! Это может привести к СМЕРТИ или СЕРЬЕЗНЫМ ТРАВМАМ РЕБЕНКА.

**NL:** Gebruik NOOIT een achterwaarts gericht kinderzitje op een stoel met een ACTIEVE AIRBAG ervoor, om DODELIJK of ERNSTIG LETSEL van het KIND te voorkomen.

**DA:** Brug ALDRIG en bagudvendt autostol på et forsæde med AKTIV AIRBAG, BARNET kan komme i LIVSFARE eller komme ALVORLIGT TIL SKADE.

**SV:** Använd ALDRIG en bakåtvänd barnstol på ett säte som skyddas med en framförvarande AKTIV AIRBAG. DÖDSFALL eller ALLVARLIGA SKADOR kan drabba BARNET.

**FI:** ÄLÄ KOSKAAN sijoita taaksepäin suunnattua lasten turvaistuinta istuimelle, jonka edessä on AKTIIVINEN TURVATYYNY, LAPSI VOI KUOLLA tai VAMMAUTUA VAKAVASTI.

**NO:** Bakovervendt barnesikringsutstyr må ALDRI brukes på et sete med AKTIV KOLLISJONSPUTE foran, da det kan føre til at BARNET utsettes for LIVSFARE og fare for ALVORLIGE SKADER.

**PT:** NUNCA use um sistema de retenção para crianças voltado para trás num banco protegido com um AIRBAG ACTIVO na frente do mesmo, poderá ocorrer a PERDA DE VIDA ou FERIMENTOS GRAVES na CRIANÇA.

**IT:** Non usare mai un sistema di sicurezza per bambini rivolto all'indietro su un sedile protetto da

AIRBAG ATTIVO di fronte ad esso: pericolo di MORTE o LESIONI GRAVI per il BAMBINO!

**EL:** ΠΟΤΕ μη χρησιμοποιείτε παιδικό κάθισμα ασφαλείας με φορά προς τα πίσω σε κάθισμα που προστατεύεται από μετωπικό ΕΝΕΡΓΟ ΑΕΡΟΣΑΚΟ, διότι το παιδί μπορεί να υποστεί ΘΑΝΑΣΙΜΟ ή ΣΟΒΑΡΟ ΤΡΑΥΜΑΤΙΣΜΟ.

**PL:** NIE WOLNO montować fotelika dziecięcego zwróconego tyłem do kierunku jazdy na fotelu, przed którym znajduje się WŁĄCZONA PODUSZKA POWIETRZNA. Niezastosowanie się do tego zalecenia może być przyczyną ŚMIERCI lub POWAŻNYCH OBRAŻEŃ u DZIECKA.

**TR:** Arkaya bakan bir çocuk emniyet sistemini KESİNLİKLE önünde bir AKTİF HAVA YASTIĞI ile korunmakta olan bir koltukta kullanmayınız. ÇOCUK ÖLEBİLİR veya AĞIR ŞEKİLDE YARALANABİLİR.

**UK:** НЕКОЛИ не використовуйте систему безпеки для дітей, що встановлюється обличчям назад,

на сидінні з УВІМКНЕНОЮ ПОДУШКОЮ БЕЗПЕКИ, інакше це може призвести до СМЕРТІ чи СЕРЬОЗНОГО ТРАВМУВАННЯ ДИТИНИ.

**HU:** SOHA ne használjon hátrafelé néző biztonsági gyerekülést előlről AKTÍV LÉGZSÁKKAL védett ülésen, mert a GYERMEK HALÁLÁT vagy KOMOLY SÉRÜLÉSÉT okozhatja.

**HR:** NIKADA nemojte koristiti sustav zadržavanja za djecu okrenut prema natrag na sjedalu s AKTIVNIM ZRAČNIM JASTUKOM ispred njega, to bi moglo dovesti do SMRTI ili OZBILJNIH OZLJEDA za DIJETE.

**SL:** NIKOLI ne nameščajte otroškega varnostnega sedeža, obrnjenega v nasprotni smeri vožnje, na sedež z AKTIVNO ČELNO ZRAČNO BLAZINO, saj pri tem obstaja nevarnost RESNIH ali SMRTNIH POŠKODB za OTROKA.

**SR:** NIKADA ne koristiti bezbednosni sistem za decu u kome su deca okrenuta unazad na sedištu sa AKTIVNIM VAZDUŠNIM

JASTUKOM ispred sedišta zato što DETE može da NASTRADA ili da se TEŠKO POVREDI.

**MK:** НИКОГАШ не користете детско седиште свртено наназад на седиште заштитено со АКТИВНО ВОЗДУШНО ПЕРНИЧЕ пред него, затоа што детето може ДА ЗАГИНЕ или да биде ТЕШКО ПОВРЕДЕНО.

**BG:** НИКОГА не използвайте детска седалка, гледаща назад, върху седалка, която е защитена чрез АКТИВНА ВЪЗДУШНА ВЪЗГЛАВНИЦА пред нея - може да се стигне до СМЪРТ или СЕРИОЗНО НАРАНЯВАНЕ на ДЕТЕТО.

**RO:** Nu utilizați NICIODATĂ un scaun pentru copil îndreptat spre partea din spate a mașinii pe un scaun protejat de un AIRBAG ACTIV în fața sa; acest lucru poate duce la DECESUL sau VĂTĂMAREA GRAVĂ a COPILULUI.

**CS:** NIKDY nepoužívejte dětský zádržný systém instalovaný proti směru jízdy na sedadle, které je chráněno před sedadlem AKTIVNÍM

AIRBAGEM. Mohlo by dojít k VÁŽNĚMU PORANĚNÍ nebo ÚMRTÍ DÍTĚTE.

**SK:** NIKDY nepoužívajte detskú sedačku otočenú vzad na sedadle chránenom AKTÍVNYM AIRBAGOM, pretože môže dôjsť k SMRTI alebo VÁŽNYM ZRANENIAM DIEŤAŤA.

**LT:** JOKIU BŪDU nemontuokite atgal atgręžtos vaiko tvirtinimo sistemas sėdynėje, prieš kurią įrengta AKTYVI ORO PAGALVĖ, nes VAJKAS GALI ŽŪTI arba RIMTAI SUSIŽALOTI.

**LV:** NEKĀDĀ GADĪJUMĀ neizmantojiet uz aizmuguri vērstu bērnu sēdekļīti sēdvietā, kas tiek aizsargāta ar tās priekšā uzstādītu AKTĪVU DROŠĪBAS SPILVENU, jo pretējā gadījumā BĒRNS var gūt SMAGAS TRAUMAS vai IET BOJĀ.

**ET:** ÄRGE kasutage tahapoole suunatud lapseturvaistet istmel, mille ees on AKTIIVSE TURVAPADJAGA kaitstud iste, sest see võib põhjustada LAPSE SURMA või TÕSISE VIGASTUSE.

**MT:** QATT tuża trażżin għat-tfal li jħares lejn in-naħa ta' wara fuq sit protett b'AIRBAG ATTIV quddiemu; dan jista' jikkawża l-MEWT jew GRIEHI SERJI lit-TFAL.

Beyond the warning required by ECE R94.02, for safety reasons never use a forward-facing child restraint system on the front passenger seat with active front airbag.

The airbag label may be located on both sides of the front passenger sun visor.

### **⚠ Danger**

Do not use a child restraint system on the passenger seat with active front airbag.

Airbag deactivation ⇨ 50.

## Front airbag system

The front airbag system consists of one airbag in the steering wheel and one in the instrument panel on the front passenger side. These can be identified by the word **AIRBAG**.



Additionally there is a warning label on the passenger's sun visor.

Child restraint systems ⇨ 52.

Airbag deactivation ⇨ 50.



The front airbag system is triggered in the event of a front-end impact of a certain severity. The ignition must be switched on.

The inflated airbags cushion the impact, thereby reducing the risk of injury to the upper body and head of the front seat occupants considerably.


### **⚠ Warning**

Optimum protection is only provided when the seat is in the proper position ⇨ 34.

Keep the area in which the airbag inflates clear of obstructions.

Fit the seat belt correctly and engage securely. Only then the airbag is able to protect.

## Side airbag system



The side airbag system consists of an airbag in each front seat backrest. This can be identified by the word **AIRBAG**.

The side airbag system is triggered in the event of a side impact of a certain severity. The ignition must be switched on.

The inflated airbags cushion the impact, thereby reducing the risk of injury to the upper body and pelvis in the event of a side-on collision considerably.

### ⚠ Warning

Keep the area in which the airbag inflates clear of obstructions.

#### Note

Only use protective seat covers that have been approved for the vehicle. Be careful not to cover the airbags.

## Airbag deactivation

The front passenger airbag system must be deactivated if a child restraint system is to be fitted on this seat.

The side airbag systems, the belt pretensioners and all driver airbag systems will remain active.

The front passenger airbag system can be deactivated via the settings menu in the Driver Information Centre (DIC) ↪ 86.



Deactivate the front passenger airbag system as follows:

1. Press **SET** ➔ once to access the settings menu.
2. Press **SET** ➔ again (repeatedly) to cycle through the menu functions until menu option **Pass bag** (in Standard version) - or - **Passenger bag** (in Multifunction version) is displayed.
3. Press **▲** or **▼** to switch from **Pass bag On** to **Pass bag off** (Standard version)

- or -

from **Passenger bag On** to **Passenger bag Off** (Multifunction version).

4. Press **SET**  to confirm selection. Depending on version, a confirmation message also appears in the display.
5. Press **▲** or **▼** to select **Yes**.
6. Press **SET**  briefly to confirm deactivation and automatically return to the previous display screen.



Front passenger seat airbags are deactivated and will not inflate in the event of a collision. Control indicator

 illuminates continuously in the roof console. A child restraint system can be installed in accordance with the chart **Child restraint installation locations**  53.

### Danger

Risk of fatal injury for a child using a child restraint system on a seat with activated front passenger airbag.

Risk of fatal injury for an adult person on a seat with deactivated front passenger airbag.

As long as the control indicator  is not illuminated, the front passenger airbag system will inflate in the event of a collision.

If control indicators  and  are illuminated at the same time, there is a system failure. The status of the system is not discernible, therefore no person is allowed to occupy the front passenger seat. Contact a workshop immediately.

Change status only when the vehicle is stationary with the ignition off. The status remains until the next change.

Control indicator  for airbag and belt tensioners  78.

Control indicator  for airbag deactivation  79.

Reactivating front passenger airbag system - see Driver Information Centre (DIC)  86.

## Child restraints

### Child restraint systems

We recommend the Opel child restraint system which is tailored specifically to the vehicle.

When a child restraint system is being used, pay attention to the following usage and installation instructions and also those supplied with the child restraint system.

Always comply with local or national regulations. In some countries, the use of child restraint systems is forbidden on certain seats.

#### Warning

When using a child restraint system on the front passenger seat, the airbag systems for the front passenger seat must be deactivated; if not, the triggering of the airbags poses a risk of fatal injury to the child.

This is especially the case if rear-facing child restraint systems are used on the front passenger seat.

Airbag deactivation ⇨ 50.

Airbag label ⇨ 45.

### Selecting the right system

The rear seats are the most convenient location to fasten a child restraint system.

Children should travel facing rearwards in the vehicle as long as possible. This makes sure that the child's backbone, which is still very weak, is under less strain in the event of an accident.

Suitable are restraint systems that comply with valid UN ECE regulations. Check local laws and regulations for mandatory use of child restraint systems.

Ensure that the child restraint system to be installed is compatible with the vehicle type.

Ensure that the mounting location of the child restraint system within the vehicle is correct.

Allow children to enter and exit the vehicle only on the side facing away from the traffic.

When the child restraint system is not in use, secure the seat with a seat belt or remove it from the vehicle.

#### Note

Do not affix anything on the child restraint systems and do not cover them with any other materials.

A child restraint system which has been subjected to stress in an accident must be replaced.

## Child restraint installation locations

### Permissible options for fitting a child restraint system

Weight and age class	Front passenger seat		Second row		Third row
	activated airbag	deactivated airbag	outboard seat	centre seat	
<b>Group 0: up to 10 kg</b> or approx. 10 months	X	U <sup>1</sup>	U, +	U	X
<b>Group 0+: up to 13 kg</b> or approx. 2 years	X	U <sup>1</sup>	U, +	U	X
<b>Group I: 9 to 18 kg</b> or approx. 8 months to 4 years	X	U <sup>1</sup>	U, +	U	X
<b>Group II: 15 to 25 kg</b> or approx. 3 to 7 years	X	X	U	U	X
<b>Group III: 22 to 36 kg</b> or approx. 6 to 12 years	X	X	U	U	X

<sup>1</sup> : When securing with a three-point seat belt, move seat height adjustment to uppermost position and ensure that the seat belt runs forwards from the upper anchorage point. Adjust seat backrest inclination as far as necessary to a vertical position to ensure that the belt is tight on the buckle side.

**+** : Vehicle seat available with ISOFIX attachments. When attaching using ISOFIX, only the ISOFIX child restraint systems permitted for the vehicle may be used.

**U** : Universal suitability in conjunction with three-point seat belt.

**X** : No child restraint system permitted in this weight class.

## Permissible options for fitting an ISOFIX child restraint system

Weight class	Size class	Fixture	On front passenger seat	On outboard seats in the second row	On centre seat in the second row	On the seats in the third row
Group 0: up to 10 kg	E	ISO/R1	X	IL	X	X
Group 0+: up to 13 kg	E	ISO/R1	X	IL	X	X
	D	ISO/R2	X	IL	X	X
	C	ISO/R3	X	IL <sup>1)</sup>	X	X
Group I: 9 to 18 kg	D	ISO/R2	X	IL	X	X
	C	ISO/R3	X	IL <sup>1)</sup>	X	X
	B	ISO/F2	X	IUF	X	X
	B1	ISO/F2X	X	IUF	X	X
	A	ISO/F3	X	IUF	X	X

1) The ISOFIX child seat can be installed by lifting the head restraint all the way up.

IL : Suitable for particular ISOFIX restraint systems of the 'specific-vehicle', 'restricted' or 'semi-universal' categories.

The ISOFIX restraint system must be approved for the specific vehicle type.

IUF : Suitable for ISOFIX forward-facing child restraint systems of universal category approved for use in this weight class.


X : No ISOFIX child restraint system approved in this weight class.

---

**ISOFIX size class and seat device**

- A – ISO/F3 : forward-facing child restraint system for children of maximum size in the weight class 9 to 18 kg
- B – ISO/F2 : forward-facing child restraint system for smaller children in the weight class 9 to 18 kg
- B1 – ISO/F2X : forward-facing child restraint system for smaller children in the weight class 9 to 18 kg
- C – ISO/R3 : rear-facing child restraint system for children of maximum size in the weight class up to 18 kg
- D – ISO/R2 : rear-facing child restraint system for smaller children in the weight class up to 18 kg
- E – ISO/R1 : rear-facing child restraint system for young children in the weight class up to 13 kg

## ISOFIX child restraint systems




Fasten vehicle-approved ISOFIX child restraint systems to the ISOFIX mounting brackets. Specific vehicle ISOFIX child restraint system positions are marked in the table by IL.

ISOFIX mounting brackets are indicated by a label on the backrest.

Before fastening a child seat adjust the head restraint to use position ↪ 33.

## Top-tether fastening eyes



In addition to the ISOFIX mounting, fasten the Top-Tether strap to the Top-Tether fastening eyes. The strap must run between the two guide rods of the head restraint.

ISOFIX child restraint systems of universal category positions are marked in the table by IUF.

## Storage


<b>Storage compartments</b> .....	<b>57</b>
Instrument panel storage .....	57
Glovebox .....	58
Cupholders .....	58
Overhead console .....	58
Underseat storage .....	58
<b>Load compartment</b> .....	<b>59</b>
Rear storage .....	59
Load compartment cover .....	59
Lashing eyes .....	62
Load compartment grille .....	62
<b>Roof rack system</b> .....	<b>63</b>
Roof rack .....	63
<b>Loading information</b> .....	<b>63</b>

## Storage compartments

### ⚠ Warning


Do not store heavy or sharp objects in the storage compartments. Otherwise vehicle occupants could be injured by objects being thrown around in the event of hard braking, a sudden change in direction or an accident.

## Instrument panel storage



Storage compartments are located in the instrument panel.


## Document holder



Pull the rear of the document holder upwards from the instrument panel and rest in tilted position.

To fold away, lower the document holder back into the instrument panel, pressing down until it engages audibly.

## Glovebox



Pull lever to open the glovebox cover. Depending on version, the glovebox may be lockable.


The glovebox should be closed whilst driving.

## Cupholders

Cupholders are located in the console between the front seats.


The cupholders can also be used to hold the portable ashtray unit ↗ 71.

## Overhead console



Store only lightweight items such as paperwork or maps in the overhead console.

## Underseat storage



Pull the loop on the seat cushion to gain access to the storage area.

## Load compartment

### Rear storage

#### Roof bars

Do not exceed the maximum load (which includes the weight of the bars) of 25 kg. Always distribute the load evenly on the roof bars. The load must not obstruct complete closure of the doors.

Retighten the fastening screws on the four brackets periodically.

#### Caution

Do not use elastic lashings, e.g. bungee cord. We recommend the use of webbing straps.

Roof bars are designed to be fitted in a specific position. Proper fastening of the roof bars cannot be guaranteed if refitted in another position.

No materials (e.g. rubber, plastic) should be placed between the feet of the bars and the vehicle body, to ensure proper fastening.

#### ⚠ Warning


The use of roof bars may affect steering and vehicle handling.

#### Removal

To remove the roof bars when not in use:



1. On one side of the vehicle, rotate handle below first roof bar (located beneath the bracket) to loosen, then slide handle inwards towards centre of vehicle.
2. Repeat above step for the other side of the vehicle.




3. Push up roof bar to release from bracket on both sides and remove roof bar completely.
4. Repeat above steps for the second roof bar.
5. Unfasten screws on the four brackets to remove the brackets from the vehicle body.


### Load compartment cover

#### Extendable load compartment cover


Do not place any heavy or sharp-edged objects on the extendable load compartment cover.

**Closing**

Pull the cover towards the rear using the handle and engage it in the retainers at the sides.

**Opening**

Remove load compartment cover from the retainers at the sides. Hold the cover and guide it until it is fully rolled up.

**Removing**

Open the load compartment cover. Pull the release lever and lift cover from retainers.

**Installing**

Insert either side of the load compartment cover in the recess, pull the release lever. Insert the load compartment cover and engage.


## Rear parcel shelf

The rear parcel shelf consists of two parts - a front part and rear part. The front part can be opened or closed, allowing for greater flexibility in the load compartment.


Do not place any excessively heavy or sharp-edged objects on the rear parcel shelf.

### Warning

Always make sure that the load in the vehicle is securely stowed. Otherwise objects can be thrown around inside the vehicle and cause personal injury or damage to the load or car.



The rear parcel shelf can be installed in 2 positions, i.e. the upper position




or the lower position. In the lower position, the maximum load permissible is 70 kg.

## Removing

If the rear seats are in the folded position, remove the parcel shelf and store it horizontally between the back of the front seats and the folded rear seats.

### Caution

For safety reasons, do not place loads on the folded rear seats.



To remove, lift the front part of the parcel shelf by releasing it from the front retainers (1) on both sides.


Lift the rear part of the parcel shelf by releasing it from the rear retainers (2 and 3) on both sides.

### Installing

Refit the parcel shelf by engaging in front and rear retainers on both sides.


## Lashing eyes

### Van



The lashing eyes are designed to secure items against slippage, e.g. using lashing straps or a luggage net.

### Combo Tour




## Load compartment grille

Depending on version, the load compartment area can be increased by opening the load compartment partition on the front passenger side (where fitted).

- Fold down the front passenger seat. Refer to "Seat folding" ⇨ 36.

- From inside the load compartment, release the pin (1) on the rear of the partition to unlock, then swing open the partition door over the folded front passenger seat.



- Insert the pin in the slot (2) on the backrest of the folded front passenger seat to lock in position.

### **Warning**

The load compartment partition must always be locked in either position during driving. Otherwise

vehicle occupants could be injured by the partition in the event of hard braking, a sudden change in direction or an accident.

### Ladder bulkhead

Depending on version, a ladder bulkhead is fixed behind the driver's seat or behind the rear seats to protect seat occupants from unsecured objects in the load compartment.

## Roof rack system

### Roof rack

For safety reasons and to avoid damage to the roof, the vehicle approved roof rack system is recommended. Contact a workshop for further information.

Follow the installation instructions and remove the roof rack when not in use.

### Mounting roof rack



To fasten a roof rack, insert the mounting bolts in the holes indicated in the illustration.

## Loading information

- Heavy objects in the load compartment should be evenly distributed and placed as far forward as possible. If objects can be stacked, the heavier objects should be placed at the bottom.
- Secure objects with lashing straps attached to lashing eyes ↪ 62.
- Secure loose objects in load compartment to prevent them from sliding.
- When transporting objects in the load compartment, the backrests of the rear seats must not be tilted forwards or folded down.
- Do not allow the load to protrude above the upper edge of the backrests.
- Do not place any objects on the extendable load compartment cover ↪ 59 or the instrument panel, and do not cover the sensor on top of the instrument panel ↪ 104.

- The load must not obstruct the operation of the pedals, parking brake and gear selector, or hinder the freedom of movement of the driver. Do not place any unsecured objects in the interior.
- Do not drive with an open load compartment.

### Warning

Always make sure that the load in the vehicle is securely stowed. Otherwise objects can be thrown around inside the vehicle and cause personal injury or damage to the load or vehicle.

- The payload is the difference between the permitted gross vehicle weight (see identification plate ⇨ 171) and the EC kerb weight.

To calculate the payload, enter the data for your vehicle in the Weights table at the front of this manual.

The EC kerb weight includes weights for the driver (68 kg),

luggage (7 kg) and all fluids (tank 90% full).

Optional equipment and accessories increase the kerb weight.

- Driving with a roof load increases the sensitivity of the vehicle to cross-winds and has a detrimental effect on vehicle handling due to the vehicle's higher centre of gravity. Distribute the load evenly and secure it properly with retaining straps. Adjust the tyre pressure and vehicle speed according to the load conditions. Check and retighten the straps frequently.

Do not drive faster than 120 km/h.

The permissible roof load (which includes the weight of the roof rack) is 100 kg. The roof load is the combined weight of the roof rack and the load.

# Instruments and controls

## Controls ..... 66

Steering wheel adjustment .....	66
Steering wheel controls .....	66
Horn .....	66
Windscreen wiper/washer .....	67
Rear window wiper/washer .....	67
Headlamp washer .....	68
Outside temperature .....	68
Clock .....	68
Power outlets .....	69
Cigarette lighter .....	70
Ashtrays .....	71

## Warning lights, gauges and indicators ..... 71

Instrument cluster .....	71
Speedometer .....	71
Odometer .....	71
Trip odometer .....	71
Tachometer .....	72
Fuel gauge .....	72
Fuel selector .....	73
Engine coolant temperature gauge .....	73
Service display .....	74

Transmission display .....	74
Control indicators .....	74
Generic warning .....	77
Turn signal .....	78
Seat belt reminder .....	78
Airbag and belt tensioners .....	78
Airbag deactivation .....	79
Charging system .....	79
Malfunction indicator light .....	79
Brake system .....	80
Brake pad wear .....	80
Antilock brake system (ABS) .....	80
Transmission .....	80
Upshift .....	81
Hill start assist .....	81
Ultrasonic parking assist .....	81
Electronic Stability Control .....	81
Engine coolant temperature .....	82
Preheating .....	82
Diesel particle filter .....	82
Tyre pressure monitoring system .....	83
Engine oil pressure .....	83
Change engine oil .....	83
Low engine oil level .....	84
Low fuel .....	84
Drain fuel filter .....	84
Immobiliser .....	84
Stop-start system .....	85
Exterior light .....	85

High beam .....	85
Fog light .....	85
Rear fog light .....	85
Cruise control .....	85
Door open .....	85

## Information displays ..... 86

Driver Information Centre .....	86
---------------------------------	----


## Vehicle messages ..... 91

Warning chimes .....	91
Fuel system messages .....	92

## Trip computer ..... 92

## Controls

### Steering wheel adjustment



Unlock lever, adjust steering wheel, then engage lever and ensure it is fully locked.

Do not adjust steering wheel unless vehicle is stationary and steering wheel lock has been released.

### Steering wheel controls



The Infotainment system and a connected mobile phone can be operated via the controls on the steering wheel.

Further information is available in the Infotainment system manual.

### Horn



Press .

## Windscreen wiper/washer

### Windscreen wiper



Twist lever:

-  : off
-  : intermittent wiping
-  : slow
-  : fast

For a single wipe when the windscreen wiper is off, move the lever up.

Do not use if the windscreen is frozen.

Switch off in car washes.

### Adjustable wiper interval

Wiper lever in position .

The windscreen wiper will automatically adapt to the speed of the vehicle.

### Windscreen washer




Pull lever briefly, washer fluid is sprayed onto the windscreen and the wiper wipes a few times.

Pull lever and hold, washer fluid is sprayed onto the windscreen and wiper wipes until the lever is released.

Washer fluid ↻ 138, Wiper blade replacement ↻ 140.

## Rear window wiper/washer



Twist to activate the rear window wiper.

Push lever. Washer fluid is sprayed onto the rear window and the wiper wipes a few times.

Do not use if the rear window is frozen.

Switch off in car washes.

The rear window wiper comes on automatically when the windscreen wiper is switched on and reverse gear is engaged.

## Headlamp washer

With the headlights on, washer fluid is sprayed onto the headlights when the windscreen washer is activated.

### Note

Washer fluid is not sprayed onto the headlights if fluid level is too low.


## Outside temperature

Depending on version, outside temperature may be shown continuously in the Driver Information Centre (DIC) ↷ 86, or displayed in the DIC by pressing **TRIP** on the end of the wiper lever ↷ 92.

### ⚠ Warning

The road surface may already be icy even though the display indicates a few degrees above 0 °C.

## Clock



Depending on version (standard or multifunction display), the current time and/or date may appear in the Driver Information Centre (DIC) ↷ 86.

Values can be adjusted via **SET** ↷, **▲** and **▼** on the instrument panel.

### Set time in DIC - Standard version

1. Press **SET** ↷ once to access the settings menu.
2. Scroll through the menu options using **▲** or **▼** until **HOUR** is displayed.

3. Press **SET** ↷ to access this menu option; the hours will flash in the display.
4. Press **▲** or **▼** to increase or decrease the displayed value.
5. Press **SET** ↷ to confirm changes; the minutes will flash in the display.
6. Press **▲** or **▼** to increase or decrease the displayed value.
7. Press **SET** ↷ briefly to confirm changes and automatically return to the previous display screen.

### Set time and date in DIC - Multifunction version

#### Setting the time

After accessing this menu option, it is possible to either set the time or change the clock mode between 12 hour and 24 hour clock.

Press **SET** ↷ once to access the settings menu.

Scroll through the menu options using **▲** or **▼** until **Set time** is displayed.

Press **SET** ↷ to access this menu option; **Time** and **Mode** are displayed.

To set the time:

1. Press ▲ or ▼ to select **Time** and press **SET** ➔ to access this submenu option; the hours will flash in the display.
2. Press ▲ or ▼ to increase or decrease the displayed value.
3. Press **SET** ➔ to confirm changes; the minutes will flash in the display.
4. Press ▲ or ▼ to increase or decrease the displayed value.
5. Press **SET** ➔ briefly to confirm changes and automatically return to the previous display screen.


To change the clock mode between 12 hour and 24 hour clock:

1. Press ▲ or ▼ to select **Mode** and press **SET** ➔ to access this submenu option; the display will flash.
2. Press ▲ or ▼ to change clock mode between 12h and 24h.
3. Press **SET** ➔ briefly to confirm changes and automatically return to the previous display screen.

### Setting the date

1. Press **SET** ➔ once to access the settings menu.
2. Scroll through the menu options using ▲ or ▼ until **Set date** is displayed.
3. Press **SET** ➔ to access this menu option; the year will flash in the display.
4. Press ▲ or ▼ to increase or decrease the displayed value.
5. Press **SET** ➔ to confirm changes; the month will flash in the display.
6. Press ▲ or ▼ to increase or decrease the displayed value.
7. Press **SET** ➔ to confirm changes; the day will flash in the display.
8. Press ▲ or ▼ to increase or decrease the displayed value.
9. Press **SET** ➔ briefly to confirm changes and automatically return to the previous display screen.


### Power outlets



A 12 Volt power outlet is located in the centre console.

### Rear power outlets

Depending on model variant, 12 Volt power outlets are located at the sidewall in the load compartment.

**Short wheelbase van****Long wheelbase van****Combo Tour**

Do not exceed the maximum power consumption of 180 watts.

With ignition off, the power outlets are deactivated. Additionally the power outlets are deactivated in the event of low battery voltage.


Electrical accessories that are connected must comply with the electromagnetic compatibility requirements laid down in DIN VDE 40 839.

**Caution**

Do not connect any current-delivering accessories, e.g. electrical charging devices or batteries.

Do not damage the outlet by using unsuitable plugs.

If the tyre repair kit is in operation, switch off all electrical consumers.  
Tyre repair kit ⇨ 155.

**Cigarette lighter**

The cigarette lighter is located in the centre console.

Press in cigarette lighter. It switches off automatically once the element is glowing. Pull out lighter.

## Ashtrays

### Caution

To be used only for ash and not for combustible rubbish.



The portable ashtray should be placed in the cupholders in the centre console.

## Warning lights, gauges and indicators

### Instrument cluster


The needles of the instruments briefly rotate to the end position when the ignition is switched on.

### Speedometer



Indicates vehicle speed.

### Odometer



Displays the recorded distance in km. **H** may appear in the display until the vehicle has travelled 100 km.

### Trip odometer

Displays the recorded distance since the last reset.

Depending on version (standard or multifunction display), there may be two independent trip odometers, **A** or **B**, which indicate how far the vehicle has been driven since the last reset.

To reset the trip odometer, press and hold **TRIP** on the end of the wiper lever for a few seconds while the relevant trip odometer is displayed.

## Tachometer



Displays the engine speed.

Drive in a low engine speed range for each gear as much as possible.

### Caution

If the needle is in the red warning zone, the maximum permitted engine speed is exceeded. Engine at risk.

## Fuel gauge



Displays the fuel level or gas level in the tank depending on the operation mode.

During natural gas operation, the system automatically switches over to petrol operation when the gas tanks are empty ⇨ 73. Fuel selector ⇨ 127.

Control indicator  illuminates if the level in the tank is low.

### Note

The symbol  beside  indicates that the fuel filler flap is located on the left side of the vehicle.

Never run the tank dry.

Because of the fuel remaining in the tank, the top-up quantity may be less than the specified tank capacity.

The needle will point to **0** and control indicator  will flash to indicate a fault in the system. Seek the assistance of a workshop.

Low fuel control indicator  ⇨ 84.

## CNG fuel gauge




In natural gas operation mode, the four vertical bars next to **CNG** correspond to the methane level in the cylinders. As the fuel level diminishes, the bars in the CNG fuel gauge disappear.

**CNG** and the one remaining bar will flash if the methane level in the cylinders is low.

Refuelling ⇨ 128.

## Fuel selector



Pressing  in the centre console switches between petrol and natural gas operation. The LED  status shows the current operating mode.

-  off : natural gas operation
-  illuminates : petrol operation

During natural gas operation, if control indicator  illuminates in the Driver Information Centre (DIC) ⇨ 86, the natural gas tanks are empty and petrol operation is automatically engaged.

Fuel for natural gas operation ⇨ 127, Refuelling ⇨ 128.

## Engine coolant temperature gauge



Displays the coolant temperature.

If control indicator  illuminates, the coolant temperature is too high. Depending on version, a message also appears in the Driver Information Centre (DIC) ⇨ 86. Seek the assistance of a workshop.

### Caution

If engine coolant temperature is too high, stop vehicle, switch off engine. Danger to engine. Check coolant level.

### Service display



Service display is available in vehicles with Multifunction version of the Driver Information Centre (DIC) ⇨ 86.

When the ignition is switched on, the remaining distance before the next service is due is shown briefly. Based

on driving conditions, the interval at which a service will be indicated can vary considerably.

When the remaining distance before the next service is less than 2,000 km, **Serv.** appears in the DIC. The service reminder is repeated after every additional 200 km and becomes more frequent when the remaining distance is below 200 km.

The vehicle needs a service. Seek the assistance of a workshop.


The remaining distance to the next service may also be viewed in the DIC by selecting **SERVICE** from the settings menu options ⇨ 86.

### Resetting the service display

After a service, the service display must be reset by a workshop.

Service information ⇨ 168.

### Transmission display



The mode and current gear of the manual transmission automated is shown in the transmission display.

Manual transmission automated ⇨ 116.

### Control indicators

The control indicators described are not present in all vehicles. The description applies to all instrument versions. Depending on the equipment, the position of the control indicators may vary.

When the ignition is switched on, most control indicators will illuminate briefly as a functionality test.

The control indicator colours mean:

red : danger, important reminder

yellow : warning, information, fault

green : confirmation of activation

blue : confirmation of activation

white : confirmation of activation

## Control indicators in the instrument cluster



## Control indicator in the roof console



Airbag deactivation ⇨ 50, ⇨ 79.

### Overview

- ▲ Generic warning ⇨ 77
- ↔ Turn signal ⇨ 78
- 🚗 Seat belt reminder ⇨ 78
- 🚒 Airbag and belt tensioners ⇨ 78
- 🚒 Airbag deactivation ⇨ 79
- 🔋 Charging system ⇨ 79

- 🚗 Malfunction indicator light ⇨ 79
- ⓐ Brake system ⇨ 80
- ⓐ Brake pad wear ⇨ 80
- ⓐ Antilock brake system (ABS) ⇨ 80
- ⚙️ Transmission ⇨ 80
- ⬆️ <sup>SHIFT</sup> Upshift ⇨ 81
- ⓐ Hill start assist ⇨ 81
- P <sup>▲</sup> Ultrasonic parking assist ⇨ 81
- 🚗 Electronic Stability Control ⇨ 81
- Engine coolant temperature ⇨ 82
- 🔥 Preheating ⇨ 82
- 🚗 Diesel particle filter ⇨ 82
- ⚠️ Tyre pressure monitoring system ⇨ 83
- 🚗 Engine oil pressure ⇨ 83, Change engine oil ⇨ 83

- 🚗 Low engine oil level ⇨ 84
- Low fuel ⇨ 84
- 🚗 Drain fuel filter ⇨ 84
- 🚗 Immobiliser ⇨ 84
- ⓐ Stop-start system ⇨ 85
- 🚗 Exterior light ⇨ 85
- 🚗 Exterior light failure ⇨ 85
- 🚗 High beam ⇨ 85
- 🚗 Fog light ⇨ 85
- 🚗 Rear fog light ⇨ 85
- 🚗 Cruise control ⇨ 85
- 🚗 Door open ⇨ 85

### Generic warning

▲ illuminates yellow.

Depending on model variant, control indicator ▲ may illuminate independently or in conjunction with ⓐ ⇨ 85, 🚗 ⇨ 85, ⓐ ⇨ 81 or P <sup>▲</sup> ⇨ 81.

If  illuminates together with   $\rightarrow$  83; stop engine immediately and seek the assistance of a workshop.

In the event of the failure of control indicator  for airbags and belt tensioners  $\rightarrow$  78,  will illuminate.

 also illuminates if the fuel cut-off switch is triggered. Consult a workshop.

Fuel cut-off system  $\rightarrow$  92, Vehicle shutdown  $\rightarrow$  110.

Depending on version, corresponding warning messages may also be displayed in the Driver Information Centre (DIC)  $\rightarrow$  86.

## Turn signal

$\rightarrow$  or  $\rightarrow$  flashes green.

## Flashes

A turn signal or the hazard warning flashers are activated.

Rapid flashing: failure of a turn signal light or associated fuse, failure of turn signal light on trailer.

Bulb replacement  $\rightarrow$  141, Fuses  $\rightarrow$  147.

Turn signals  $\rightarrow$  97.

## Seat belt reminder

### Seat belt reminder for front seats

 for driver's seat and/or front passenger seat illuminates or flashes red.

### Illuminates

When the ignition has been switched on, control indicator  illuminates briefly if driver's seat belt and/or front passenger seat belt is not engaged. A warning chime also sounds for a few seconds.

### Flashes

During driving  will flash and a warning chime will sound for 90 seconds until the front seat belts are fastened.

Three-point seat belts  $\rightarrow$  43.

## Warning

Fasten seat belt before each trip.

In the event of an accident, people not wearing seat belts endanger their fellow occupants and themselves.

To deactivate the seat belt reminder, consult a workshop. Reactivation of the warning chime for seat belt reminder can be done via the Driver Information Centre (DIC)  $\rightarrow$  86.

### Note

The volume of the warning chime can also be adjusted via the Driver Information Centre (DIC)  $\rightarrow$  86.

## Airbag and belt tensioners

 illuminates red.

When the ignition is switched on, the control indicator illuminates for approx. 4 seconds.

If it does not illuminate, does not go out after 4 seconds or illuminates whilst driving, there is a fault in the airbag system. Seek the assistance

of a workshop. The airbags and belt pretensioners may fail to trigger in the event of an accident.

Deployment of the belt pretensioners or airbags is indicated by continuous illumination of .

Depending on version,  will illuminate in the event of the failure of control indicator .

Generic warning   77.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  86.

### Warning

Have the cause of the fault remedied immediately by a workshop.

Belt pretensioners, airbag system  
 42,  45.

## Airbag deactivation

 illuminates yellow.

### With the front passenger airbag activated:

When the ignition is switched on, control indicator  illuminates for approx. 4 seconds, flashes for another 4 seconds and then extinguishes.

### With the front passenger airbag deactivated:

 permanently illuminates yellow.

Airbag deactivation  50.

### Danger

Risk of fatal injury for a child using a child restraint system together with activated front passenger airbag.

Risk of fatal injury for an adult person with deactivated front passenger airbag.

## Charging system

 illuminates red.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

### Illuminates when the engine is running

Stop, switch off engine. Battery is not charging. Engine cooling may be interrupted. The brake servo unit may cease to be effective. Seek the assistance of a workshop.

## Malfunction indicator light

 illuminates or flashes yellow.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

### Illuminates when the engine is running

Fault in the emission control system. The permitted emission limits may be exceeded. Seek the assistance of a workshop immediately.

## Flashes when the engine is running

Fault that could lead to catalytic converter damage. Ease up on the accelerator until the flashing stops. Seek the assistance of a workshop immediately.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  
 ⇨ 86.

## Brake system

 illuminates red.

Illuminates after the ignition is switched on if the parking brake is applied ⇨ 120. A warning chime will sound if a certain speed is exceeded with the parking brake applied.

Illuminates when the parking brake is released if the brake fluid level is too low ⇨ 138.

### Warning

Stop. Do not continue your journey. Consult a workshop.

Illuminates if the brake vacuum servo fails; the brake pedal becomes stiff when pressed. The brake system remains operational however, assistance will be reduced. The steering may also require considerably more effort when turning.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  
 ⇨ 86.

## Brake pad wear

 illuminates yellow.

The front brake pads are worn, seek the assistance of a workshop immediately.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  
 ⇨ 86.

## Antilock brake system (ABS)

 illuminates yellow.

Illuminates for a few seconds after the ignition is switched on. The system is ready for operation when the control indicator extinguishes.

If the control indicator does not extinguish after a few seconds, or if it illuminates while driving, there is a fault in the ABS. The brake system remains operational but without ABS regulation.

If  illuminates together with , there is a fault in the braking system. Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  
 ⇨ 86. Seek the assistance of a workshop immediately.

Antilock brake system ⇨ 120.

## Transmission

 illuminates red.

Illuminates for a few seconds after the ignition is switched on.

 illuminates during driving when a fault is present in the transmission.

A warning message may also appear in the Driver Information Centre (DIC)  
 ⇨ 86 in conjunction with a warning chime.

Continued driving is possible, provided the vehicle is driven with care and anticipation.

Have the cause of the fault remedied by a workshop as soon as possible.

Manual transmission automated  
 ⇨ 116.

## Upshift

 or  illuminates green in the Driver Information Centre (DIC)  
 ⇨ 86 when gearshifting is recommended to improve fuel economy.

## Hill start assist

 illuminates yellow.

Illuminates for a few seconds after the ignition is switched on.

If the control indicator does not extinguish after a few seconds, or if it illuminates while driving, there is a

fault in the Hill start assist. Seek the assistance of a workshop to have the fault remedied.

The Electronic Stability Control (ESC) control indicator  may also illuminate ⇨ 81 in conjunction with .

Depending on version,  may illuminate as an alternative if control indicator  is not present, in conjunction with a warning message in the Driver Information Centre (DIC) ⇨ 86.

Generic warning  ⇨ 77.

Hill start assist ⇨ 121.

## Ultrasonic parking assist

 illuminates yellow.

Fault in system

or

Fault due to sensors that are dirty or covered by ice or snow

or

Interference due to external sources of ultrasound. Once the source of interference is removed, the system will operate normally.

Have the cause of the fault in the system remedied by a workshop.

Control indicator  will illuminate as an alternative if control indicator  is not present. Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

Generic warning  ⇨ 77.

Ultrasonic parking assist ⇨ 125.

## Electronic Stability Control

 illuminates or flashes yellow.

Illuminates for a few seconds after the ignition is switched on. The system is ready for operation when the control indicator extinguishes.

## Flashes during driving

The system is actively engaged. Engine output may be reduced and the vehicle may be braked automatically to a small degree.

### Illuminates during driving

A fault in the system is present. Continued driving is possible. Driving stability, however, may deteriorate depending on road surface conditions.

Have the cause of the fault remedied by a workshop.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

Electronic Stability Control (ESC) ⇨ 122, Traction control system/Anti-Slip Regulator (ASR) ⇨ 122.

### Engine coolant temperature

○ illuminates red.

Illuminates for a few seconds after the ignition is switched on.

If control indicator ○ illuminates, the coolant temperature is too high. Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86. Seek the assistance of a workshop.

### Caution

If engine coolant temperature is too high, stop vehicle, switch off the ignition. Danger to engine. Check coolant level.

If the control indicator remains on, seek the assistance of your workshop.

Engine coolant temperature gauge ⇨ 73.

### Preheating

☞ illuminates yellow.

Preheating is activated. Only activates when outside temperature is low.

#### Note

In very hot outside temperatures, ☞ may illuminate briefly when the ignition is switched on.

The engine can be started when ☞ extinguishes.

Starting the engine ⇨ 110.

### Flashes

A fault is detected in the engine preheating system. Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

If ☞ does not extinguish, consult a workshop.

### Diesel particle filter

☞ illuminates yellow.

Illuminates for a few seconds after the ignition is switched on.

If it does not extinguish after a brief delay or illuminates whilst driving, the diesel particle filter requires cleaning. Continue driving until ☞ extinguishes. Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

If possible, do not allow engine speed to drop below 2000 rpm during the cleaning process.

Control indicator  illuminates when diesel particulate filter is full. Start cleaning process as soon as possible to avoid damage to the engine.

Diesel particulate filter  114, Stop-start system  111.

## Tyre pressure monitoring system

 illuminates or flashes yellow.

### Illuminates

Tyre pressure loss. Stop immediately and check tyre pressure.

Control indicator  illuminates together with a warning chime and, in vehicles with Multifunction version of the Driver Information Centre (DIC)  86, a corresponding message also appears when a puncture or severely under-inflated tyre is detected.

### Flashes

Fault in system. After several seconds  illuminates continuously. Consult a workshop.

Depending on version, a corresponding message also appears in the DIC when a tyre without a pressure sensor is mounted (e.g. spare wheel).

Tyre pressure monitoring system  152.

## Engine oil pressure

 illuminates red.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

### Illuminates when the engine is running

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  86.

### Caution

Engine lubrication may be interrupted. This may result in damage to the engine and/or locking of the drive wheels.

1. Depress clutch.
2. Select neutral gear (or move selector lever to **N**).
3. Move out of the flow of traffic as quickly as possible without impeding other vehicles.
4. Switch off ignition.

### Warning

When the engine is off, considerably more force is needed to brake and steer. During an Autostop the brake servo unit will still be operational.

Do not remove key until vehicle is stationary, otherwise the steering wheel lock could engage unexpectedly.

Check oil level before seeking the assistance of a workshop  136.

## Change engine oil

### Diesel engines with diesel particle filter

 flashes red.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

The engine oil life monitor lets you know when to change the oil. Control indicator  will flash to indicate that engine oil life has been diminished and the oil needs changing.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  86.

Based on driving conditions, the interval at which an oil change will be indicated can vary considerably.

Depending on model variant,  may flash in the following ways:

- for 1 minute every 2 hours, or
- for 3 minute cycles with  off for intervals of 5 seconds

The warning will be repeated every time the engine is started, until the engine oil is changed and the service display is reset. Seek the assistance of a workshop.

Service display  74.

## Low engine oil level

 illuminates red.

Illuminates for a few seconds after the ignition is switched on.

If the control indicator does not extinguish after a few seconds, or if it illuminates while driving, the engine oil level is insufficient.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  86.

Check oil level before seeking the assistance of a workshop  136.

## Low fuel

 illuminates or flashes yellow.

Illuminates for a few seconds after the ignition is switched on.

## Illuminates

Level in fuel tank is too low. Refuel immediately  128.

Never run the tank dry.

Catalytic converter  115.

## Flashes

Fault in fuel system. Have the cause of the fault remedied by a workshop.

The needle in the fuel gauge will point to **0**. Fuel gauge  72.

## Drain fuel filter

 illuminates yellow.

Illuminates for a few seconds after the ignition is switched on.

## Illuminates when the engine is running

Indicates the presence of water in the diesel. Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  86. Seek the assistance of a workshop immediately.

## Immobiliser

 illuminates yellow.

Fault in the immobiliser system. The engine cannot be started.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

Seek the assistance of a workshop.

## Stop-start system

ⓘ illuminates yellow.

A fault is present in the system. Have the cause of the fault remedied by a workshop.

Control indicator ⚠ will illuminate as an alternative if control indicator ⓘ is not present.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

Generic warning ⚠ ⇨ 77.

Stop-start system ⇨ 111.

## Exterior light

➤⚡ illuminates green.

The exterior lights are on ⇨ 95.

Control indicator ➤⚡ also illuminates when the exit lighting feature has been switched on ⇨ 100.

## Exterior light failure

⚡ illuminates yellow.

Failure of one or more of the exterior lights or associated fuse.

Control indicator ⚠ will illuminate as an alternative if ⚡ is not present.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

Generic warning ⚠ ⇨ 77.

Bulb replacement ⇨ 141.

## High beam

☰ⓘ illuminates blue.

Illuminated when high beam is on and during headlight flash ⇨ 95.

## Fog light

⚡Ⓚ illuminates green.

The front fog lights are on ⇨ 97.

## Rear fog light

Ⓚ⚡ illuminates yellow.

The rear fog light is on ⇨ 97.

## Cruise control

ⓀⓁ illuminates green.

The system is switched on.

Depending on version, a message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

Cruise control ⇨ 123.

## Door open

ⓀⓁ illuminates red.


Illuminates when a door, the bonnet or the tailgate is open.

Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC) ⇨ 86.

When the vehicle starts to move, a warning chime also sounds.

## Information displays

### Driver Information Centre



The Driver Information Centre (DIC) is located in the instrument cluster between the speedometer and tachometer. Two versions are available; a Standard version



and a Multifunction version with further adjustable settings.

Some of the displayed functions differ when the vehicle is being driven or at a standstill. Some options are only available when the vehicle is being driven.

Depending on version, the following items may appear in the display:

- odometer, trip odometer ↗ 71
- clock ↗ 68
- outside temperature ↗ 68, ↗ 92
- headlight range adjustment ↗ 96

- transmission display ↗ 116
- stop-start system indicator ↗ 111
- vehicle messages ↗ 91
- trip computer ↗ 92

### Selecting menus and options

The menus and options can be selected via the buttons on the instrument panel.



Press **SET** :

- once to access the settings menu
- press again to access a menu option and submenu options
- after changes have been made, briefly press again to confirm a value and automatically return to the previous display screen

Alternatively, press and hold **SET**  to return to the previous display screen without saving changes to the current menu option.

#### Note

The settings menu is exited automatically after a delay. Only changes already confirmed by briefly pressing **SET**  are stored.



Press **▲** to scroll up the screen and the menu options or to increase the displayed value. Press and hold to increase value rapidly (press again to stop on the required value).

Press **▼** to scroll down the screen and the menu options or to decrease the displayed value. Press and hold to decrease value rapidly (press again to stop on the required value).

### Settings menu options - Standard version

The settings menu contains the following options:

- **ILLU**
- **SPEEd**
- **HOUR**
- **UNIT**
- **bUZZ**
- **BAG P**
- **DRL**

#### ILLU (Brightness of interior lighting)

When driving at night with the low beam on, adjust the brightness of the vehicle's interior lighting (e.g. instrument panel, climate control display).

#### SPEEd (Speed limit warning chime)

Activate or deactivate the speed limit warning chime or change the speed limit. Speeds between 30 and 200 km/h can be stored.

When activated, the driver is alerted with a warning chime when the set speed limit is exceeded.

After accessing this menu option, activate or deactivate the function (set to **On** or **Off**) and confirm.

Press **SET** ➔ when activated (**On**) to access the current set speed. Adjust as required and confirm.

Warning chimes ⇨ 91.

### **hour (Setting the clock)**

Adjust the hours setting (flashing value) and confirm. Adjust minutes setting (flashing value) and confirm.

Clock ⇨ 68.

### **UNIT (Unit of measurement)**

Set the unit of measurement to **km** or **miles**.

### **BUZZ (Warning chime volume)**

Adjust the volume of warning chimes and confirm. 8 volume levels are available.

A chime is also sounded every time **SET** ➔, ▲ or ▼ is pressed.

Warning chimes ⇨ 91.

### **BAG P (Passenger front and side airbags activation/deactivation)**

Activate the front passenger airbags if an adult is occupying the front passenger seat. Deactivate airbags when a child restraint system is installed on this seat.

#### **⚠ Danger**

Risk of fatal injury for a child using a child restraint system on a seat with activated front passenger airbag.

Risk of fatal injury for an adult person on a seat with deactivated front passenger airbag.

After accessing this menu option, activate or deactivate the airbags (**BAG P On** or **BAG P Off**) and confirm; a confirmation message appears in the display. Select **YES** (to confirm changes) or **No** (to cancel changes).

Airbag deactivation ⇨ 50.

### **DRL (Daytime running lights)**

Activate the daytime running lights to increase visibility of the vehicle during daylight (set to **On**). Deactivate when not required (set to **Off**).

Daytime running lights ⇨ 96.

### **Settings menu options - Multifunction version**

The settings menu contains the following options:

- **Lighting**
- **Speed beep**
- **Trip B data**
- **Set time**
- **Set date**
- **Radio info**
- **Autoclose**
- **Unit of measurement**
- **Language**
- **Warning volume**
- **Button volume**
- **Seat belt buzzer**
- **Service**
- **Passenger airbag**

- **Daytime running lights**
- **Exit menu**

### **LIGHTING (Brightness of interior lighting)**

When driving at night with the low beam on, adjust the brightness of the vehicle's interior lighting (e.g. instrument panel, climate control display).

It is also possible to adjust the brightness by pressing ▲ or ▼ without accessing the settings menu.

### **SPEED BEEP (Speed limit warning chime)**

Activate or deactivate the speed limit warning chime or change the speed limit. Speeds between 30 and 200 km/h can be stored.

When activated, the driver is alerted with a warning chime when the set speed limit is exceeded.

After accessing this menu option, activate or deactivate the function (set to **On** or **Off**) and confirm.

Press **SET** ➔ when activated (**On**) to access the current set speed. Adjust as required and confirm.

Warning chimes ⇨ 91.

### **TRIP B DATA**

Activate or deactivate the second trip computer (set to **On** or **Off**).

Trip B records average consumption, distance travelled, average speed and travel time (driving time). The measurement can be restarted at any time. Trip computer ⇨ 92.

### **SET TIME (Setting the clock and clock mode)**

After accessing this menu option, it is possible to either set the time or change the clock mode between 12 hour and 24 hour clock.

Select **Time** and confirm. Adjust the hours setting (flashing value) and confirm. Adjust minutes setting (flashing value) and confirm.

Select **Mode** and confirm. Select 12h or 24h and confirm.

Clock ⇨ 68.

### **SET DATE**

Adjust the year setting (flashing value) and confirm. Adjust month setting (flashing value) and confirm. Adjust the day setting (flashing value) and confirm.

### **RADIO INFO (Display audio and radio information)**

Activate radio info (set to **On**) to display audio and radio information (e.g. station frequency, RDS messages, track number). Deactivate when not required (set to **Off**).

### **AUTOCLOSE (Automatic central locking when driving)**

Activate the autoclose feature (set to **On**) to automatically lock the doors when vehicle speed exceeds 20 km/h. Deactivate when not required (set to **Off**).

### **UNIT OF MEASUREMENT (for Distance, Fuel consumption and Temperature)**

After accessing this menu option, it is possible to set the unit of measurement for distance, fuel consumption and temperature.

Select **Distance** and confirm. Set the unit of measurement to **km** or **mi** (miles) and confirm.

Select **Consumption** and confirm. When the **Distance** unit is set to **km**, it is possible to set the unit of measurement for fuel consumption to either **l/100km** or **km/l**. When the **Distance** unit is set to **mi** (miles), fuel consumption is shown in **mpg**.

Select **Temperature** and confirm. Set the unit of measurement to **°C** or **°F** and confirm.

### LANGUAGE

Languages selectable include: English, German, French, Italian, Portuguese, Spanish, Dutch, Polish and Turkish. Select desired language and confirm.

### WARNING VOLUME (Warning chime volume)

Adjust the volume of warning chimes and confirm. 8 volume levels are available.

Warning chimes ⇨ 91.

### BUTTON VOLUME

A chime is sounded every time **SET** ⇨, ▲ or ▼ is pressed.

Adjust the volume of these chimes and confirm. 8 volume levels are available.

Warning chimes ⇨ 91.

### SEAT BELT BUZZER (Reactivate warning chime for driver and/or front passenger seat belt reminder)

This menu option is available only when the seat belt reminder has already been deactivated by a workshop.

When reactivated, the driver and/or front passenger are alerted with a warning chime when the corresponding seat belt is not fastened.

Seat belt reminder ⇨ 78.

### SERVICE (Distance to next service)

Access this menu option to view the remaining distance to the next service.

The distance to next service is also displayed automatically when the distance reaches 2,000 km and is repeated after every additional 200 km.

Service display ⇨ 74.

### PASSENGER AIRBAG (Passenger front and side airbags activation/deactivation)

Activate the front passenger airbags if an adult is occupying the front passenger seat. Deactivate airbags when a child restraint system is installed on this seat.

#### Danger

Risk of fatal injury for a child using a child restraint system on a seat with activated front passenger airbag.

Risk of fatal injury for an adult person on a seat with deactivated front passenger airbag.

After accessing this menu option, activate or deactivate the airbags (**Bag Pass On** or **Bag Pass Off**) and confirm; a confirmation message

appears in the display. Select **YES** (to confirm changes) or **No** (to cancel changes).

Airbag deactivation ⇨ 50.

### DAYTIME RUNNING LIGHTS

Activate the daytime running lights to increase visibility of the vehicle during daylight (set to **On**). Deactivate when not required (set to **Off**).

Daytime running lights ⇨ 96.

### EXIT MENU

Select this menu option to exit the settings menu.

## Vehicle messages

### Warning chimes

Only one warning chime will sound at a time.

The warning chime regarding unfastened seat belts has priority over any other warning chime.

### When starting the engine or whilst driving

- If seat belt is not fastened.
- If a certain speed is exceeded with the parking brake applied.
- If the parking assist detects an object.
- If a fault is detected in the parking assist.
- If a door, the bonnet or the tailgate is not fully closed when starting-off.
- If the vehicle speed briefly exceeds a set limit.
- If the stop-start system cannot restart the engine automatically.

- Vehicles with manual transmission automated; brake pedal has not been depressed when starting the engine.
- Vehicles with manual transmission automated; an incorrect gear has been selected when starting-off or during driving.
- Vehicles with manual transmission automated; when the vehicle is at a standstill, if engine is running and a gear is engaged; transmission automatically shifts to **N** in certain situations.
- If the clutch temperature is too high in vehicles with manual transmission automated.
- If a transmission fault is detected in vehicles with manual transmission automated.
- If a warning message, e.g. low tyre pressure, appears in the Driver Information Centre (DIC).

### When the vehicle is parked and/or the driver's door is opened

- When the key is in the ignition switch.

## Fuel system messages

### Fuel cut-off system

In the event of a collision of a certain severity, the fuel system is cut-off and the engine is switched off automatically, for safety reasons.

Control indicator  $\Delta \rightarrow 77$  illuminates if the fuel cut-off switch is triggered and, depending on version, a corresponding warning message may also appear in the Driver Information Centre (DIC)  $\rightarrow 86$ .

To reset the fuel cut-off system and enable the vehicle to be driven, refer to "Vehicle shutdown"  $\rightarrow 110$ .

## Trip computer

The trip computer provides information on driving data, which is continually recorded and evaluated electronically.



Depending on version, the following functions may be selected by pressing **TRIP** repeatedly on the end of the wiper lever:

### Standard version

- outside temperature
- average consumption
- instantaneous consumption

- range
- distance travelled
- average speed
- travel time (driving time)

### Multifunction version

Two trip odometers, Trip A and Trip B, are available for selection and are recorded separately.

The information of the two trip computers can be reset separately, making it possible to display different trip distances.

### Trip A

- outside temperature
- average consumption
- instantaneous consumption
- range
- distance travelled
- average speed
- travel time (driving time)

### Trip B

- average consumption
- distance travelled

- average speed
- travel time (driving time)

Trip B can be deactivated via the Driver Information Centre (DIC) ⇨ 86.

### Reset trip computer information

To reset the trip computer, select one of its functions, then press and hold **TRIP** for a few seconds.



The following trip computer information will be reset:

- average consumption
- distance travelled
- average speed
- travel time (driving time)

The trip computer will reset automatically when the maximum value of any of the parameters is exceeded.

### Outside temperature

The temperature outside the vehicle is displayed.

Outside temperature ⇨ 68, ⇨ 86.

### Average consumption

Average consumption is displayed, taking into consideration the distance travelled and the fuel used since the last reset.

The measurement can be restarted at any time.

### Instantaneous consumption

Display of the instantaneous fuel consumption.

— — — will appear in the display if the vehicle is left parked with the engine running for a long time.

### Range

The range is calculated from the current contents of the fuel tank and the average consumption since the last reset.

When the range is less than 50 km, — — — will appear in the display.

After refuelling, the range is updated automatically after a brief delay.

The measurement can be restarted at any time.

#### Note

The range will not be displayed if the vehicle is left parked with the engine running for a long time.

### Distance travelled

Displays the distance driven since the last reset.

The measurement can be restarted at any time.

### Average speed

The average speed since the last reset is displayed.

The measurement can be restarted at any time.

Interruptions in the journey with the ignition off are not included in the calculations.

### **Travel time (driving time)**

The time elapsed since the since the last reset is displayed.

The measurement can be restarted at any time.

### **Exit trip computer**

To exit the trip computer, press and hold **SET**  for more than 2 seconds.

Driver Information Centre (DIC) ⇨ 86.

### **Interruption of power supply**

If the power supply has been interrupted or if the battery voltage has dropped too low, the values stored in the trip computer will be lost.

## Lighting

<b>Exterior lighting</b> .....	<b>95</b>
Light switch .....	95
High beam .....	95
Headlight flash .....	95
Headlight range adjustment .....	96
Headlights when driving abroad .....	96
Daytime running lights .....	96
Hazard warning flashers .....	96
Turn and lane-change signals ...	97
Front fog lights .....	97
Rear fog lights .....	97
Reversing lights .....	97
Misted light covers .....	98
<b>Interior lighting</b> .....	<b>98</b>
Instrument panel illumination control .....	98
Interior lights .....	98
Load compartment lighting .....	99
<b>Lighting features</b> .....	<b>100</b>
Exit lighting .....	100
Battery discharge protection ....	101

## Exterior lighting

### Light switch



Turn light switch:


- : off / daytime running lights
- ☉ : sidelights / headlights

Control indicator ➤⚡⚡⚡ 85.

### Tail lights

Tail lights are illuminated together with headlights and sidelights.

### High beam



To switch from low to high beam, push lever.

To switch to low beam, pull lever.

### Headlight flash

To activate the headlight flash, pull lever.

## Headlight range adjustment

### Manual headlight range adjustment



To adapt headlight range to the vehicle load to prevent dazzling of other road users: Press or buttons until the required setting is displayed in the Driver Information Centre (DIC) ⇨ 86.

- 0 : front seats occupied
- 1 : all seats occupied
- 2 : all seats occupied and load compartment laden
- 3 : driver's seat occupied and load compartment laden

## Headlights when driving abroad

The asymmetrical headlight beam extends visibility at the edge of the road at the passenger side.

However, when driving in countries where traffic drives on the opposite side of the road, adjust the headlights to prevent dazzling of oncoming traffic.

Have the headlights adjusted by a workshop.

## Daytime running lights

Daytime running lights increase visibility of the vehicle during daylight.

When the function is activated and the ignition is switched on, the headlights come on automatically and instrument illumination is subdued. The light switch must be in position . The daytime running lights switch off when the ignition is switched off.

### Note

The driver remains responsible for switching on the low beam when required, e.g. when driving through a tunnel or at night.

The daytime running lights function is activated/deactivated via a menu in the Driver Information Centre (DIC) ⇨ 86.


When the function is deactivated, the headlights do not come on automatically when the ignition is switched on and the light switch is in position .

## Hazard warning flashers



Operated by pressing .

## Turn and lane-change signals



Lever up : right turn signal

Lever down : left turn signal

If the lever is moved past the resistance point, the turn signal is switched on constantly. When the steering wheel moves back, the turn signal is automatically deactivated.

For five flashes, e.g. when changing lanes, press the lever until resistance is felt and then release.

Move the lever to the resistance point and hold for longer indication.

Switch the indicator off manually by moving the lever to its original position.

## Front fog lights



Operated by pressing .

Switching on front fog lights will switch sidelights on automatically.

Press  again to turn the front fog lights off.

## Rear fog lights



Operated by pressing .

The rear fog light can only be switched on when both the ignition and headlights or sidelights (with front fog lights) are on.

Press  again to turn the rear fog light off, or turn off the headlights and/or the front fog lights.

## Reversing lights

The reversing lights come on when the ignition is on and reverse gear is selected.

## Misted light covers

The inside of the light covers may mist up briefly in poor, wet and cold weather conditions, in heavy rain or after washing. The mist disappears quickly by itself; to help, switch on the headlights.

## Interior lighting

### Instrument panel illumination control

When driving at night with the headlights on, adjust the brightness of the vehicle's interior lighting (including instrument panel, climate control display etc.) via the settings menu of the Driver Information Centre (DIC) ⇨ 86.

To adjust brightness:

#### Standard version of DIC

1. Press **SET** ⇨ once to access the settings menu.
2. Scroll through the menu options by pressing **▲** or **▼** until menu option **ILLU** appears in the display.
3. Press **▲** or **▼** to increase or decrease the displayed value.
4. Press **SET** ⇨ briefly to confirm changes and automatically return to the previous display screen.

#### Multifunction version of DIC

1. Press **SET** ⇨ to access the settings menu.
2. Scroll through the menu options by pressing **▲** or **▼** until menu option **LIGHTING** appears in the display.
3. Press **▲** or **▼** to increase or decrease the displayed value.
4. Press **SET** ⇨ briefly to confirm changes and automatically return to the previous display screen.

It is also possible to adjust the brightness by pressing **▲** or **▼** without accessing the settings menu. Driver Information Centre (DIC) ⇨ 86.

## Interior lights

Depending on model variant, during entry and exit of the vehicle the front and rear courtesy lights come on automatically and then switch off after a delay.

**Note**

In the event of an accident of a certain severity, the interior lights come on automatically. Fuel cut-off system ⇨ 92.

**Front courtesy light**

Centre switch position: automatic interior light.

To operate manually when the doors are closed, press the lens on either side.

**Front courtesy light with reading lights**

Centre switch position: automatic interior light.

Can be operated individually or together with rocker switch  when the doors are closed.

Press  left or right to operate respective reading light.

**Rear courtesy lights**


Centre switch position: automatic interior light.

To operate manually when the doors are closed, press the lens on either side.

**Load compartment lighting**

Depending on model variant, load compartment lighting switches on when the rear doors / tailgate or sliding side door is opened.

### Removable rear courtesy light



Depending on model variant, the removable rear courtesy light may illuminate when the rear doors / tailgate or sliding side doors are opened and the central switch is in the middle position.

Switch the light on permanently by pressing the top part of the central switch .


Switch the light off permanently by pressing the bottom part of the central switch (**AUTO OFF**).

To use as a handheld torch, press button on top of the lamp assembly (see illustration) to release it, swing

torch down carefully and remove. Press switch on the end of torch to turn the light on/off. Replace the torch in its original position to recharge the battery after use.

## Lighting features

### Exit lighting



If equipped, headlights come on for approx. 30 seconds after the vehicle is parked and the system is activated.

### Activation

1. Switch off ignition.
2. Remove ignition key.
3. Pull turn signal lever towards steering wheel.
4. Operate turn signal lever again within 2 minutes.

This action can be repeated up to seven times to a maximum period of 210 seconds.

Control indicator   85 illuminates in the instrument cluster during use. Depending on version, a warning message may also be displayed in the Driver Information Centre (DIC)  86.

### **Deactivation**

Pull turn signal lever for more than 2 seconds to deactivate.

### **Battery discharge protection**

To ensure reliable engine restarts, several battery discharge protection features are implemented as part of the stop-start system.

Stop-start system  111.

## Climate control

<b>Climate control systems</b> .....	102
Heating and ventilation system	102
Air conditioning system .....	103
Electronic climate control system .....	104
<b>Air vents</b> .....	106
Adjustable air vents .....	106
Fixed air vents .....	106
<b>Maintenance</b> .....	107
Air intake .....	107
Pollen filter .....	107
Air conditioning regular operation .....	107
Service .....	107

## Climate control systems

### Heating and ventilation system



Controls for:

- temperature
- fan speed
- air distribution

Heated rear window  ⇨ 32.

### Temperature

red : warm  
blue : cold

Heating will not be fully effective until the engine has reached normal operating temperature.

### Fan speed

Adjust the air flow by switching the fan to the desired speed.

### Air distribution

-  : to head area
-  : to head area and foot well
-  : to foot well
-  : to windscreen, front door windows and foot well
-  : to windscreen and front door windows


Intermediate settings are possible.

### Demisting and defrosting the windows

- Set temperature control to warmest level.
- Set fan speed to highest level.
- Set air distribution control to .
- Switch on heated rear window .

- Open side air vents as required and direct them towards door windows.
- For simultaneous warming of the foot well, set air distribution control to .

## Air conditioning system



Additional to the heating and ventilation system, the air conditioning system has controls for:

-  : cooling
-  : air recirculation

Heated front seats   38.

### Cooling

Press  to switch on cooling. Activation is indicated by the LED in the button. Cooling is only functional when the engine is running and climate control fan is switched on.

Press  again to switch off cooling.

The air conditioning system cools and dehumidifies (dries) the air when outside temperature is above a specific level. Therefore condensation may form and drip from under the vehicle.

If no cooling or drying is required, switch the cooling system off to save fuel.

### Air recirculation system

Press  to activate air recirculation mode. Activation is indicated by the LED in the button.

Press  again to deactivate air recirculation mode.

### Warning

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up. The quality of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

In warm and very humid ambient air conditions, the windscreen may mist up from outside, when cold air is directed towards it. If windscreen mists up from outside, activate windscreen wiper and deactivate .

### Maximum cooling

Briefly open the windows so that hot air can disperse quickly.

- Cooling .
- Air recirculation system  on.
- Set air distribution control to .
- Set temperature control to coldest level.

- Set fan speed to highest level.
- Open all air vents.

### Demisting and defrosting the windows

- Set temperature control to warmest level.
- Set fan speed to highest level.
- Set air distribution control to .
- Switch cooling  on.
- Switch on heated rear window .
- Open side air vents as required and direct them towards door windows.
- For simultaneous warming of the foot well, set air distribution control to .

### Electronic climate control system



Controls for:

- temperature
- air distribution and menu selection
- fan speed

**AUTO** : automatic mode

 : air recirculation

 : demisting and defrosting

**OFF** : switch on/off

Heated rear window  ⇨ 32.

The preselected temperature is automatically regulated. In the automatic mode the fan speed and air distribution automatically regulate the air flow.

The system can be manually adapted by use of air distribution and air flow controls.

The electronic climate control system is only fully operational when the engine is running.

For correct operation do not cover the sensor on the instrument panel.

### Automatic mode

Basic setting for maximum comfort:

- Press **AUTO**.
- Open all air vents.
-  on.
- Set desired temperature.

### Temperature preselection

Temperatures can be set to the desired value.

For reasons of comfort, change temperature only in small increments. Turn **AUTO** knob to adjust.

clockwise : warm  
 anticlockwise : cold

Heating will not be fully effective until the engine has reached normal operating temperature.

When the minimum temperature is set below 16 °C, the electronic climate control system runs at maximum cooling. LO appears in the display.

If the maximum temperature is set above 32 °C, the electronic climate control system runs at maximum heating. HI appears in the display.

### Fan speed

The selected fan speed is indicated with bars in the display.

Press **—** or **+** to increase or decrease the fan speed.

maximum fan : all bars displayed  
 speed

minimum fan : one bar displayed  
 speed

Press  to deactivate fan.

To return to automatic fan speed:  
 Press **AUTO**.

### Demisting and defrosting the windows

Press .

Temperature and air distribution are set automatically and the fan runs at a high speed.

When the vehicle reaches normal operating temperature the function remains active for approx. 3 minutes.

To return to automatic mode: press  or **AUTO**.

### Air distribution

Press **▲**, **▼** or **▶**.

LED in buttons illuminate.

Arrows shown in the display indicate the distribution settings.

### Cooling

Press  to switch on cooling.

Activation is indicated by the LED in the button. Cooling is only functional when the engine is running and climate control fan is switched on.

Press  again to switch off cooling.

The air conditioning system cools and dehumidifies (dries) when outside temperature is above a specific level. Therefore condensation may form and drip from under the vehicle.

If no cooling or drying is required press  again to switch the cooling system off, thus saving fuel.

### Manual air recirculation mode

Operated by pressing .

recirculation on : LED in button illuminated;  appears in the display

recirculation off : LED in button extinguishes;  appears in the display

### Warning

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up. The quality

of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

In warm and very humid ambient air conditions, the windscreen may mist up from outside, when cold air is directed towards it. If windscreen mists up from outside, activate windscreen wiper and deactivate .

## Air vents


### Adjustable air vents

At least one air vent must be open while cooling is on in order to prevent the evaporator from icing up due to lack of air movement.

#### Warning

Do not attach any objects to the slats of the air vents. Risk of damage and injury in case of an accident.

### Centre air vents




Slide knob to the left to open vent.

Direct the flow of air by swivelling the vent.

Slide knob to the right to close vent.

### Side air vents



Slide knob to the left to open vent.

Direct the flow of air by swivelling the vent.


Slide knob to the right to close vent.

### Fixed air vents

Additional air vents are located beneath the windscreen and door windows and in the foot wells.

## Maintenance

### Air intake



The air intake in front of the windscreen in the engine compartment must be kept clear to allow air intake. Remove any leaves, dirt or snow.

### Pollen filter

The pollen filter cleans dust, soot, pollen and spores from the air entering the vehicle through the air intake.

### Air conditioning regular operation

In order to ensure continuously efficient performance, cooling must be operated for a few minutes once a month, irrespective of the weather and time of year. Operation with cooling is not possible when outside temperature is too low.

### Service

For optimal cooling performance, it is recommended that the climate control system be checked annually, starting three years after initial vehicle registration, including:

- functionality and pressure test
- heating functionality
- leakage check
- check of drive belts
- cleaning of condenser and evaporator drainage
- performance check

## Driving and operating

<b>Driving hints</b> .....	<b>108</b>
Control of the vehicle .....	108
Steering .....	108
<b>Starting and operating</b> .....	<b>109</b>
New vehicle running-in .....	109
Ignition switch positions .....	109
Starting the engine .....	110
Vehicle shutdown .....	110
Overrun cut-off .....	111
Stop-start system .....	111
Parking .....	113
<b>Engine exhaust</b> .....	<b>114</b>
Diesel particle filter .....	114
Catalytic converter .....	115
<b>Manual transmission</b> .....	<b>115</b>
<b>Manual transmission automa- ted</b> .....	<b>116</b>
Transmission display .....	116
Starting the engine .....	116
Selector lever .....	117
Manual mode .....	118
Electronic driving programmes .....	119
Fault .....	119

<b>Brakes</b> .....	<b>120</b>
Antilock brake system .....	120
Parking brake .....	120
Brake assist .....	121
Hill start assist .....	121
<b>Ride control systems</b> .....	<b>122</b>
Traction Control system .....	122
Electronic Stability Control .....	122
<b>Driver assistance systems</b> .....	<b>123</b>
Cruise control .....	123
Parking assist .....	125
<b>Fuel</b> .....	<b>126</b>
Fuel for petrol engines .....	126
Fuel for diesel engines .....	127
Fuel for natural gas operation .	127
Refuelling .....	128
Fuel consumption - CO <sub>2</sub> - Emissions .....	130
<b>Trailer hitch</b> .....	<b>131</b>
General information .....	131
Driving characteristics and towing tips .....	131
Trailer towing .....	131

## Driving hints

### Control of the vehicle

#### Never coast with engine not running (except during Autostop)

Many systems will not function in this situation (e.g. brake servo unit, power steering). Driving in this manner is a danger to yourself and others. All systems function during an Autostop, but there will be a controlled reduction in power steering assist and vehicle speed is reduced.

Stop-start system ⇨ 111.

#### Pedals

To ensure the pedal travel is uninhibited, there must be no mats in the area of the pedals.

#### Steering

If power steering assist is lost because the engine stops or due to a system malfunction, the vehicle can be steered but may require increased effort.

### Caution

Never leave the steering wheel on full lock when the vehicle is stationary, as this may damage the power steering pump.

## Starting and operating

### New vehicle running-in


Do not brake unnecessarily hard for the first few journeys.

During the first drive, smoke may occur because of wax and oil evaporating off the exhaust system. Park the vehicle in the open for a while after the first drive and avoid inhaling the fumes.

During the running-in period fuel and engine oil consumption may be higher and the cleaning process of the diesel particle filter may take place more often. Autostop may be inhibited to allow for charging the battery.


Diesel particle filter ⇨ 114.

## Ignition switch positions



- 0 : steering wheel lock released, ignition off
- 1 : ignition on, for diesel engine preheating
- 2 : starting

## Starting the engine



Manual transmission: operate clutch and brake.

Manual transmission automated: operate brake, the transmission automatically shifts to **N** (neutral)

Do not operate the accelerator pedal.

Diesel engine: turn the key to position 1 for preheating until control indicator  extinguishes.

Turn the key briefly to position 2 and release.

Before restarting or to switch off the engine, turn the key back to position 0.

## Autostop

During an Autostop, the engine is restarted automatically by depressing the clutch pedal.

Vehicles with manual transmission automated (MTA): Shift to a forward gear, release brake pedal or move lever to **+**, **-** or **R** to enable an automatic restart.

Stop-start system ⇨ 111.

## Starting the vehicle at low temperatures

The start of the engine without additional heaters is possible down to  $-25\text{ }^{\circ}\text{C}$  for diesel engines and  $-30\text{ }^{\circ}\text{C}$  for petrol engines. Required is an engine oil with the correct viscosity, the correct fuel, performed services and a sufficiently charged battery.

## Turbo engine warm-up

Upon start-up, engine available torque may be limited for a short time, especially when the engine temperature is cold. The limitation is to allow the lubrication system to fully protect the engine.

## Vehicle shutdown

### Fuel cut-off system

In the event of a collision of a certain severity, the fuel system is cut-off and the engine is switched off automatically, for safety reasons.

Control indicator  illuminates if the fuel cut-off switch is triggered and, depending on version, a corresponding warning message may also appear in the Driver Information Centre (DIC) ⇨ 86.

Generic warning control indicator  ⇨ 77.

### Note

In addition, the vehicle is automatically unlocked and the hazard warning flashers and interior lights are illuminated.

Turn the ignition key to position 0 to prevent battery discharge and seek the assistance of a workshop immediately. Have the vehicle checked for fuel leaks in the engine compartment, beneath the vehicle and near the fuel tank.

To reset the fuel cut-off system and enable the vehicle to be driven:

1. Turn the ignition key to position 1  
↪ 109.
2. Fully actuate the right turn signal light ↪ 97.
3. Deactivate the right turn signal light.
4. Fully actuate the left turn signal light.
5. Deactivate the left turn signal light.
6. Repeat steps 2, 3, 4 and 5.
7. Turn the ignition key to position 0.

### **⚠ Danger**

If you can smell fuel in the vehicle, or a fuel leak is present, have the cause of this remedied immediately by a workshop. Do not reset the fuel cut-off system, to avoid the risk of fire.

Fuel system messages ↪ 92.

## **Overrun cut-off**

The fuel supply is automatically cut-off during overrun, i.e. when the vehicle is driven with a gear engaged but accelerator is released.

## **Stop-start system**


The stop-start system helps to save fuel and to reduce exhaust emissions. When conditions allow, it switches off the engine as soon as the vehicle is at a low speed or at a standstill, e.g. at a traffic light or in a traffic jam. It starts the engine automatically as soon as the clutch is depressed.

A battery sensor ensures that an Autostop is only performed if the battery is sufficiently charged for a restart.

### **Activation**

The stop-start system is available as soon as the engine is started, the vehicle starts-off and the conditions as stated below in this section are fulfilled.

## **Deactivation**



Deactivate the stop-start system manually by pressing  in the centre console. LED in the button illuminates to confirm deactivation.


Depending on version, a corresponding message may also appear in the Driver Information Centre (DIC) ↪ 86.

## Autostop

If the vehicle is at a low speed or at a standstill, activate an Autostop as follows:

- depress the clutch pedal
- set the lever to neutral
- release the clutch pedal

The engine will be switched off while the ignition stays on.



An Autostop is indicated when control indicator  flashes in the DIC ⇨ 86.

During an Autostop, the heating, power steering and brake performance will be maintained.

## Caution

The steering assist may be reduced during an Autostop.

### Conditions for an Autostop

The stop-start system checks if each of the following conditions is fulfilled. Otherwise an Autostop will be inhibited.

- the stop-start system is not manually deactivated
- the bonnet is fully closed
- the driver's door is closed and the driver's seat belt is fastened
- the battery is sufficiently charged and in good condition
- the engine is warmed up
- the engine coolant temperature is not too high
- the engine exhaust temperature is not too high, e.g. after driving with high engine load
- the ambient temperature is not too low
- the climate control system allows an Autostop

- the self-cleaning function of the diesel particle filter is not active
- the vehicle has moved since the last Autostop
- the brake vacuum is sufficient
- the windscreen wipers are not operating at fast speed
- reverse gear is not selected
- heated rear window is not operating

Ambient temperature near to the freezing point can inhibit an Autostop.

For manual transmission automated vehicles, an Autostop may be inhibited until a speed of approx. 10 km/h is reached.

Immediately after motorway driving an Autostop may be inhibited.

New vehicle running-in ⇨ 109.

### Battery discharge protection

To ensure reliable engine restarts, several battery discharge protection features are implemented as part of the stop-start system.

## Restarting the engine

### Manual transmission

The selector lever must be in neutral to enable an automatic restart.

Depress the clutch pedal to restart the engine.

### Manual transmission automated

If the lever is in position **N**, select another gear, otherwise release the brake pedal or move the lever to **+**, **-** or **R** to enable an automatic restart.

If an electrical accessory, e.g. a portable CD player, is connected to the power outlet, a brief power drop during the restart may be noticeable.

## Restarting the engine with the key

When one of the following conditions occurs during an Autostop, the engine will need to be restarted manually using the key.

- the driver's seat belt is unfastened and the driver's door is opened
- three minutes have elapsed since the engine was switched off

In this event, control indicator  flashes in the DIC in conjunction with a warning chime. Depending on version, a corresponding message may also appear in the DIC ⇨ 86.

## Fault

If control indicator  illuminates in the instrument cluster, there is a fault in the stop-start system ⇨ 85.

Depending on version,  will illuminate as an alternative if control indicator  is not present. A warning message may also be displayed in the DIC ⇨ 86.

Generic warning  ⇨ 77.

Seek the assistance of a workshop.

## Parking

### Warning

- Do not park the vehicle on an easily ignitable surface. The high temperature of the exhaust system could ignite the surface.

- Always apply parking brake without pressing release button. Apply as firmly as possible on a downhill slope or uphill slope. Depress brake pedal at the same time to reduce operating force.
- Switch off the engine. Turn the ignition key to position 0 and remove it. Turn the steering wheel until the steering wheel lock is felt to engage.
- If the vehicle is on a level surface or uphill slope, engage first gear before switching off the ignition. On an uphill slope, turn the front wheels away from the kerb.

If the vehicle is on a downhill slope, engage reverse gear before switching off the ignition. Turn the front wheels towards the kerb.

Lock the vehicle ⇨ 22 and activate the anti-theft locking system ⇨ 27 .

**Note**

In the event of an accident with airbag deployment, the engine is turned off automatically if the vehicle comes to a standstill within a certain time.

**Engine exhaust****⚠ Danger**

Engine exhaust gases contain poisonous carbon monoxide, which is colourless and odourless and could be fatal if inhaled.

If exhaust gases enter the interior of the vehicle, open the windows. Have the cause of the fault rectified by a workshop.

Avoid driving with an open load compartment, otherwise exhaust gases could enter the vehicle.

**Diesel particle filter**

The diesel particle filter system filters harmful soot particles out of the exhaust gases. The system includes a self-cleaning function that runs automatically during driving without any notification. The filter is cleaned by periodically burning off the soot particles at high temperature. This process takes place automatically under set driving conditions and may take up to 25 minutes. Typically it

needs 15 minutes. Autostop is not available and fuel consumption may be higher during this period. The emission of smells and smoke during this process is normal.

Under certain driving conditions, e.g. short distances, the system cannot clean itself automatically.

If the cleaning of the filter is required and if previous driving conditions did not enable automatic cleaning, it will be indicated by control indicator . Depending on version, a warning message may also appear in the Driver Information Centre (DIC)  86.

Control indicator  illuminates when diesel particle filter is full. Start cleaning process as soon as possible to avoid damage to the engine.

**Cleaning process**

To activate cleaning process, continue driving, keep engine speed above 2000 rpm. Shift down if necessary. Diesel particle filter cleaning is then started.

**Caution**

If the cleaning process is interrupted, there is a risk of provoking severe engine damage.

Cleaning takes place quickest at high engine speeds and loads.

Control indicator  extinguishes as soon as the self-cleaning operation is complete.

**Catalytic converter**

The catalytic converter reduces the amount of harmful substances in the exhaust gases.


**Caution**

Fuel grades other than those listed on pages  126,  174 could damage the catalytic converter or electronic components.

Unburnt petrol will overheat and damage the catalytic converter. Therefore avoid excessive use of

the starter, running the fuel tank dry and starting the engine by pushing or towing.

In the event of misfiring, uneven engine running, a reduction in engine performance or other unusual problems, have the cause of the fault rectified by a workshop as soon as possible. In an emergency, driving can be continued for a short period, keeping vehicle speed and engine speed low.

**Manual transmission**

To engage reverse, with the vehicle stationary, wait 3 seconds after depressing the clutch pedal, pull up the collar on the selector lever and engage the gear.

If the gear does not engage, set the lever to neutral, release the clutch pedal and depress again; then repeat gear selection.

Do not slip the clutch unnecessarily.

When operating, depress the clutch pedal completely. Do not use the pedal as a foot rest.


**Caution**

It is not advisable to drive with the hand resting on the selector lever.

When gearshifting is recommended to improve fuel economy, control indicator  or  illuminates in the Driver Information Centre (DIC) ⇨ 81.

**Manual transmission automated**

The manual transmission automated (MTA) permits manual (manual mode) or automatic gear shifting (automatic mode), both with automatic clutch control.

**Transmission display**

Shows the mode and current gear.

**Starting the engine**

Depress the brake pedal when starting the engine.

If the brake pedal is not depressed, a warning message appears in the Driver Information Centre (DIC) together with a warning chime ⇨ 91 and the engine cannot be started.

**Note**

The volume of the warning chime can also be adjusted via the Driver Information Centre (DIC) ⇨ 86.


When the brake pedal is depressed, the transmission automatically shifts to **N** (neutral) and the engine can be started. There may be a slight delay.

**Autostop**

During an Autostop, if the gearshift lever is in position **N**, select another gear, otherwise release the brake pedal or move the lever to **+**, **-** or **R** to enable an automatic restart of the engine.

Stop-start system ⇨ 111.

## Selector lever



Always move the selector lever in the appropriate direction as far as it will go.

After selecting **A/M**, **+** or **-** and releasing the selector lever, the lever automatically returns to the centre position.

- N** : neutral
- : drive position
- A/M** : switch between automatic and manual mode

The transmission display shows **AUTO** when in automatic mode.

- R** : reverse gear  
Engage only when vehicle is stationary. The transmission display shows "R" when reverse gear is engaged.
- +** : shift to a higher gear
- : shift to a lower gear

### Caution

It is not advisable to drive with the hand resting on the selector lever.

### Starting-off

When the engine is started, depress the brake pedal and move the selector lever towards **+** to engage first gear. Shift to a higher or lower gear by moving selector lever to **+** or **-**.

Gears can be skipped by moving the selector lever repeatedly at short intervals.

The driver will be alerted to an incorrect gear selection by an audible warning chime in conjunction with a message in the Driver Information

Centre (DIC) ⇨ 86. The system will downshift, selecting the most appropriate gear automatically.

If **R** is selected, reverse gear is engaged. The vehicle starts to move when the brake pedal is released. To start off quickly, release the brake pedal and accelerate immediately after engaging a gear.

Move the selector lever towards **A/M** to engage automatic mode; the transmission shifts to other gears automatically, dependent on driving conditions.

To engage manual mode, move the selector lever towards **A/M**. The current gear will appear in the transmission display.

### Stopping the vehicle

In automatic or manual mode, first gear is engaged and the clutch is released when the vehicle is stopped. In **R**, reverse gear remains engaged.

When the vehicle is at a standstill, if the engine is running and a forward or reverse gear is engaged, a warning

chime will sound and the transmission automatically shifts to **N** in certain situations.

When stopping on gradients, engage parking brake or depress the brake pedal. To prevent overheating of the clutch, an intermittent audible warning chime may sound as a signal to depress the brake pedal or apply the parking brake.

Switch off engine if stopping for a lengthy period, e.g. in traffic jams.

### Engine braking

#### Automatic mode

When driving downhill, the manual transmission automated does not shift into higher gears until a fairly high engine speed has been reached. It shifts down in good time when braking.

#### Manual mode

To utilise the engine braking effect, select a lower gear in good time when driving downhill.

### Rocking the vehicle

Rocking the vehicle is only permissible if the vehicle is stuck in sand, mud, snow or a hole. Move the selector lever between **R** and **A/M** (or between **+** and **-**) in a repeat pattern, while applying light pressure to the accelerator pedal. Do not race the engine and avoid sudden acceleration.

### Parking

Apply the parking brake. The most recently engaged gear (see transmission display) remains engaged.

<b>Caution</b>
Do not leave the vehicle with the transmission in position <b>N</b> .

When the ignition is switched on, a warning chime will sound when the vehicle is parked if the transmission is still in **N**.

When the ignition is switched off, the transmission no longer responds to movement of the selector lever.

### Manual mode


If engine speed is too low, the transmission automatically shifts to a lower gear.

In manual mode, no automatic shifting to a higher gear takes place at high engine revolutions. If engine speed is too high, the transmission only switches to a higher gear via kickdown ⇨ 119.

When gearshifting is recommended to improve fuel economy, control indicator  or  illuminates in the Driver Information Centre (DIC) ⇨ 81.

## Electronic driving programmes

### Eco mode E



When automatic mode is engaged, the Eco mode can be selected to reduce fuel consumption.

Eco mode selects the most suitable gear depending on the speed of the vehicle, the engine speed and the intensity with which the accelerator is pressed.

### Activation

Press **E** on the selector lever housing. Control indicator **E** is shown in the transmission display to indicate activation.

### Deactivation

Eco mode is switched off by:

- pressing **E** again
- switching to manual mode

In order to protect the transmission at extremely high clutch temperatures, an intermittent audible warning chime may sound. In such cases, depress the brake pedal, select **N** and apply the parking brake to allow the clutch to cool down.

### Kickdown

If the accelerator pedal is pressed past the pressure point, the transmission shifts to a lower gear depending on engine speed. Full engine power is available for acceleration.

If engine speed is too high the transmission switches to a higher gear, even in manual mode. Without kickdown this automatic shift is not effected in manual mode.

### Fault

In the event of a fault, control indicator  is shown in the transmission display.

Continued driving is possible, provided the vehicle is driven with care and anticipation. A warning message may appear in the Driver Information Centre (DIC) in conjunction with a warning chime  91.

### Note

The volume of the warning chime can also be adjusted via the Driver Information Centre (DIC)  86.

Have the cause of the fault remedied by a workshop.

## Brakes

The brake system comprises two independent brake circuits.

If a brake circuit fails, the vehicle can still be braked using the other brake circuit. However, braking effect is achieved only when the brake pedal is depressed firmly. Considerably more force is needed for this. The braking distance is extended. Seek the assistance of a workshop before continuing your journey.

When the engine is not running, the support of the brake servo unit disappears once the brake pedal has been depressed once or twice. Braking effect is not reduced, but braking requires significantly greater force. It is especially important to bear this in mind when being towed.

Control indicator (D) ⇄ 80.

### Antilock brake system

Antilock brake system (ABS) prevents the wheels from locking.

ABS starts to regulate brake pressure as soon as a wheel shows a tendency to lock. The vehicle remains steerable, even during hard braking.

ABS control is made apparent through a pulse in the brake pedal and the noise of the regulation process.

For optimum braking, keep the brake pedal fully depressed throughout the braking process, despite the fact that the pedal is pulsating. Do not reduce the pressure on the pedal.

After starting off the system performs a self-test which may be audible.

Control indicator (ABS) ⇄ 80.

### Fault

#### **⚠ Warning**


If there is a fault in the ABS, the wheels may be liable to lock due to braking that is heavier than normal. The advantages of ABS are no longer available. During

hard braking, the vehicle can no longer be steered and may swerve.

Have the cause of the fault remedied by a workshop.

## Parking brake

### Manual parking brake



**⚠ Warning**

Always apply parking brake firmly without operating the release button, and apply as firmly as possible on a downhill or uphill slope.

To release the parking brake, pull the lever up slightly, press the release button and fully lower the lever.

To reduce the operating forces of the parking brake, depress the brake pedal at the same time.

A warning chime will sound if a certain speed is exceeded with the parking brake applied.

**Note**

The volume of the warning chime can also be adjusted via the Driver Information Centre (DIC) ↪ 86.

Control indicator (ⓘ) ↪ 80.

**Brake assist**

If the brake pedal is depressed quickly and forcefully, maximum brake force is automatically applied (full braking).

Maintain steady pressure on the brake pedal for as long as full braking is required. Maximum brake force is automatically reduced when the brake pedal is released.

**Hill start assist**

The system helps prevent unintended movement when driving away on inclines.

When releasing the brake pedal after stopping on an incline, the brakes remain on for a further two seconds. The brakes release automatically as soon as the vehicle begins to accelerate.

If control indicator (ⓘ) illuminates while driving, there is a fault in the Hill start assist ↪ 81. Seek the assistance of a workshop to have the fault remedied.

The Hill start assist is not active during an Autostop.

Stop-start system ↪ 111.

## Ride control systems

### Traction Control system

The Anti-Slip Regulator (ASR) is a component of the Electronic Stability Control (ESC).

ASR improves driving stability when necessary, regardless of the type of road surface or tyre grip, by preventing the drive wheels from spinning.

As soon as the drive wheels starts to spin, engine output is reduced and the wheel spinning the most is braked individually. This considerably improves the driving stability of the vehicle on slippery road surfaces.

ASR is operational as soon as the control indicator  extinguishes.


When ASR is active, control indicator  flashes.

### Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

### Deactivation



ASR can be switched off when spinning of drive wheels is required: press **ASR OFF** briefly.

LED in button illuminates and, depending on version, a message may also appear in the Driver Information Centre (DIC)  86.

ASR is reactivated by pressing **ASR OFF** again.

ASR is also reactivated the next time the ignition is switched on.

### Fault

ASR will switch off automatically in the event of a fault. Control indicator  will illuminate in the instrument cluster. Depending on version, a message may also appear in the DIC  86.

Have the cause of the fault remedied by a workshop.

Control indicator   81.

### Electronic Stability Control

Electronic Stability Control (ESC) improves driving stability when necessary, regardless of the type of road surface or tyre grip. It also prevents the drive wheels from spinning.

As soon as the vehicle starts to swerve (understeer/oversteer), engine output is reduced and the wheels are braked individually. This

considerably improves the driving stability of the vehicle on slippery road surfaces.

ESC is operational as soon as control indicator  extinguishes.

When ESC comes into action, control indicator  flashes.

The ESC system is automatically activated when the vehicle is started and cannot be deactivated.

### Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

### Fault

In the event of a fault, ESC will be automatically switched off and control indicator  will illuminate in the instrument cluster. Depending on version, a message may also appear in the Driver Information Centre (DIC)  86. The LED in the **ASR OFF** button will also illuminate.

Have the cause of the fault remedied by a workshop.

Control indicator   81.

## Driver assistance systems

### Warning


Driver assistance systems are developed to support the driver and not to replace the driver's attention.

The driver accepts full responsibility when driving the vehicle.

When using driver assistance systems, always take care regarding the current traffic situation.

## Cruise control

The cruise control can store and maintain speeds above approx. 30 km/h. Deviations from the stored speeds may occur when driving uphill or downhill.



Do not use the cruise control if it is not advisable to maintain a constant speed.

Control indicator  ⇨ 85.

### Switching on

Turn end of lever to the **ON** position; control indicator  illuminates in the instrument cluster. Depending on version, a message may also appear in the Driver Information Centre (DIC) ⇨ 86.

### Activation

Accelerate to the desired speed and push lever upwards (+); the current speed is stored and maintained. Accelerator pedal can be released.

Vehicle speed can be increased by depressing the accelerator pedal. When the accelerator pedal is released, the previously stored speed is resumed.

Cruise control remains activated while gearshifting.

### Increase speed

With cruise control active, push lever upwards (+) or briefly push lever upwards (+) repeatedly: speed increases continuously or in small increments.

Alternatively accelerate to the desired speed and store by pushing lever upwards (+).

### Reduce speed

With cruise control active, push lever downwards (-) or briefly push lever downwards (-) repeatedly; speed decreases continuously or in small increments.

### Deactivation

Automatic deactivation:

- vehicle speed below approx. 30 km/h
- the brake pedal is depressed
- the clutch pedal is depressed
- the traction control system/Anti-Slip Regulator (ASR) or Electronic Stability Control (ESC) is operating


### Resume stored speed

Press  at a speed above 30 km/h. The stored speed will be obtained.

## Switching off

Turn end of lever to the **OFF** position; control indicator  extinguishes. The stored speed is deleted. Switching off the ignition also deletes the stored speed.

## Parking assist



The parking assist makes parking easier by measuring the distance between the vehicle and obstacles, and giving acoustic signals. It is the driver, however, who bears full responsibility for the parking manoeuvre.

The system consists of four ultrasonic parking sensors in the rear bumper.

Control indicator   $\rightarrow$  81.

### System operation

The parking assist is turned on automatically when reverse gear is engaged.

The intervals between the beeps become shorter as the vehicle gets closer to the obstacle. When the distance is less than 30 cm, the beeping is a continuous tone which stops immediately when the distance is increased.

### Fault

In the event of a fault in the system,  illuminates and a message is displayed in the Driver Information Centre (DIC)  $\rightarrow$  86.

The following conditions could affect the system's performance:

- The ultrasonic sensors are not clean. Keep the bumper free of mud, dirt, snow, ice and slush.
- The sensors are covered by frost or ice.

- The rear doors / tailgate are open.
- An object was hanging out of the rear doors / tailgate during the last drive cycle. Once the object has been removed, the parking assist will return to normal operation.
- An object or cover is attached to the rear of the vehicle.
- The bumper is damaged. Take the vehicle to a workshop to repair the system.
- Other conditions, such as vibrations from a jackhammer, are affecting system performance.

In the event the system still does not work properly, seek the assistance of a workshop.

A warning chime is also sounded briefly if a fault is present when reverse gear is engaged  $\rightarrow$  91.

### Note

The volume of the warning chime can also be adjusted via the Driver Information Centre (DIC)  $\rightarrow$  86.

## Important hints for using the parking assist systems

### ⚠ Warning

Under certain circumstances, various reflective surfaces on objects or clothing as well as external noise sources may cause the system to fail to detect obstacles.

Special attention has to be paid to low obstacles which can damage the lower part of the bumper. If such obstacles leave the detection area of the sensors during approach of the vehicle, a continuous warning tone will sound.

### Caution

Performance of the sensor can be reduced when sensors are covered, e.g. by ice or snow.

Performance of the parking assist systems can be reduced due to heavy loading.

Special conditions apply if there are taller vehicles involved (e.g. off-road vehicles, mini vans, vans). Object identification in the upper part of these vehicles cannot be guaranteed.

Objects with a very small reflection cross section, like objects of narrow size or soft materials, may not be detected by the system.

Parking assist will not avoid a collision with objects which are out of the detection range of the sensors.

### Note

The parking assist system automatically detects factory-fitted towing equipment. It is deactivated when the connector is plugged in.

The sensor may detect a non-existent object (echo disturbance) caused by external acoustic or mechanical disturbances.

## Fuel

### Fuel for petrol engines

Only use unleaded fuel that complies with European standard EN 228 or E DIN 51626-1 or equivalent.

Your engine is capable of running with E10 fuel that fulfills these standards. E10 fuel contains up to 10% bioethanol.

Use fuel with the recommended octane rating  $\geq 174$ . Use of fuel with too low an octane rating can reduce engine power and torque and slightly increases fuel consumption.

### Caution

Do not use fuel or fuel additives that contain metallic compounds such as manganese-based additives. This may cause engine damage.

**Caution**

Use of fuel that does not comply to EN 228 or E DIN 51626-1 or equivalent can lead to deposits or engine damage and may affect your warranty.

**Caution**

Use of fuel with too low an octane rating could lead to uncontrolled combustion and engine damage.

**Fuel for diesel engines**

Only use diesel fuel that complies with EN 590.

In countries outside the European Union use Euro-Diesel fuel with a sulphur concentration below 50 ppm.

**Caution**

Use of fuel that does not comply to EN 590 or similar can lead to engine powerloss, increased wear or engine damage and may affect your warranty.


Do not use marine diesel oils, heating oils, Aquazole and similar diesel-water emulsions. Diesel fuels must not be diluted with fuels for petrol engines.

**Fuel for natural gas operation**

Use natural gas with a methane content of approx. 78 - 99%. L-gas (low) has approx. 78 - 87% and H-gas (high) has approx. 87 - 99%. Biogas with the same methane content can also be used if it has been chemically prepared and desulphurised.

Only use natural gas or biogas that complies with DIN 51624.

Liquid gas or LPG must not be used.

**Fuel selector**

Pressing  in the centre console switches between petrol and natural gas operation. The LED  status shows the current operating mode.

-  off : natural gas operation
-  illuminates : petrol operation

As soon as the natural gas tanks are empty, petrol operation is automatically engaged. Control indicator  illuminates in the Driver Information Centre (DIC)  86 until the ignition is switched off.

A slight loss of power and torque can be expected in petrol operation. You must therefore adapt your driving style (e.g. during overtaking manoeuvres) and vehicle loads (e.g. towing loads) accordingly.

Every six months run the petrol tank down until control indicator **O** illuminates and then refuel. This is necessary to maintain fuel quality as well as system function necessary for petrol operation.

Fill the tank completely at regular intervals to prevent corrosion in the tank.

### Refuelling

Fuel filler flap is located at left rear side of vehicle.

#### **⚠ Danger**

Before refuelling, switch off engine and any external heaters with combustion chambers. Switch off any mobile phones.

Follow the operating and safety instructions of the filling station when refuelling.

#### **⚠ Danger**

Fuel is flammable and explosive. No smoking. No naked flames or sparks.

If you can smell fuel in your vehicle, have the cause of this remedied immediately by a workshop.

#### **Caution**

In case of misfuelling, do not switch on ignition.

Release the fuel filler flap by pulling the flap by hand.

Insert key into fuel filler cap and turn anticlockwise to unlock.

To remove fuel filler cap, rotate anticlockwise.

#### **Caution**

To avoid damage, do not attempt to operate the sliding side door when the fuel filler flap is open.

#### **Note**

Depending on model, the sliding side door may be fitted with a safety system that prevents the door from being opened fully when the fuel filler flap is open.

Sliding side door ⇨ 24.



The fuel filler cap can be retained in the bracket on the fuel filler flap.

To refuel, fully insert the pump nozzle and switch it on.

After the automatic cut-off, the fuel tank can be topped up with a maximum of two doses of fuel.

### Caution

Wipe off any overflowing fuel immediately.

To close, replace fuel filler cap and turn clockwise.

Insert key into fuel filler cap and turn clockwise to lock, then remove key.

Close the fuel filler flap.

## Natural gas refuelling



Open the fuel filler flap.

### ⚠ Warning

Refuel only with a maximum output pressure of 250 bar. Use only temperature compensated filling stations.

The refuelling procedure must be completed, i.e. the filler neck must be vented.

The capacity of the natural gas tank depends on outside temperature, filling pressure and type of refuelling system.

Close the fuel filler flap after refuelling.

Terms for "**natural gas vehicles**" abroad:

**German** Erdgasfahrzeuge

**English** NGVs = Natural Gas Vehicles

**French** Véhicules au gaz naturel – or – Véhicules GNV

**Italian** Metano auto

Terms for "**natural gas**" abroad:

**German** Erdgas

**English** CNG = Compressed Natural Gas

**French** GNV = Gaz Naturel (pour) Véhicules - or - CGN = carburantgaz naturel

**Italian** Metano (per auto)

### Fuel filler cap

Only use genuine fuel filler caps. Diesel-engined vehicles have special fuel filler caps.

### Fuel cut-off system

In the event of a collision of a certain severity, the fuel system is cut-off and the engine is switched off automatically, for safety reasons.

Resetting the fuel cut-off system; refer to "Fuel system messages" ⇨ 92.

## Fuel consumption - CO<sub>2</sub>-Emissions

The fuel consumption (combined) of the Opel Combo is within a range of 7.7 to 4.7 l/100 km.

The CO<sub>2</sub> emission (combined) is within a range of 179 to 124 g/km.

For the values specific to your vehicle, refer to the EEC Certificate of Conformity provided with your vehicle or other national registration documents.

### General information

The official fuel consumption and specific CO<sub>2</sub> emission figures quoted relate to the EU base model with standard equipment.

Fuel consumption data and CO<sub>2</sub> emission data are determined according to regulation R (EC) No. 715/2007 (in the applicable version), taking into consideration the vehicle weight in running order, as specified by the regulation.

The figures are provided only for the purpose of comparison between different vehicle variants and must not be taken as a guarantee for the actual fuel consumption of a particular vehicle.

Additional equipment may result in slightly higher results than the stated fuel consumption and CO<sub>2</sub> figures. Furthermore, fuel consumption is dependent on personal driving style as well as road and traffic conditions.

### Natural gas

The fuel consumption information was obtained using reference fuel G20 (methane proportion 99 - 100 mol%) under prescribed driving conditions. When using natural gas with a lower proportion of methane, the fuel consumption can differ from the specified values.

## Trailer hitch

### General information

Only use towing equipment that has been approved for your vehicle. Vehicles with natural gas engine may require special towing equipment.

Entrust retrofitting of towing equipment to a workshop. It may be necessary to make changes that affect the cooling system, heat shields or other equipment.

Fitting of towing equipment could cover the opening of the towing eye. If this is the case use the coupling ball bar for towing. Always keep the coupling ball bar in the vehicle.

### Driving characteristics and towing tips

Before attaching a trailer, lubricate the coupling ball. However, do not do so if a stabiliser, which acts on the coupling ball, is being used to reduce snaking movements.

For trailers with low driving stability and caravan trailers with a permitted gross vehicle weight of more than 1300 kg the use of a stabiliser is strongly recommended when driving above 80 km/h.

If the trailer starts snaking, drive more slowly, do not attempt to correct the steering and brake sharply if necessary.

When driving downhill, drive in the same gear as if driving uphill and drive at a similar speed.

Adjust tyre pressure to the value specified for full load ⇨ 180.

## Trailer towing

### Trailer loads

The permissible trailer loads are vehicle and engine-dependent maximum values which must not be exceeded. The actual trailer load is the difference between the actual gross weight of the trailer and the actual coupling socket load with the trailer coupled.

The permissible trailer loads are specified in the vehicle documents. In general, they are valid for gradients up to max. 12%.

The permitted trailer load applies up to the specified incline and up to an altitude of 1000 metres above sea level. Since engine power decreases as altitude increases due to the air becoming thinner, therefore reducing climbing ability, the permissible gross train weight also decreases by 10% for every 1000 metres of additional altitude. The gross train weight does not have to be reduced when driving on roads with slight inclines (less than 8%, e.g. motorways).

The permissible gross train weight must not be exceeded. This weight is specified on the identification plate ⇨ 171.

### Vertical coupling load

The vertical coupling load is the load exerted by the trailer on the coupling ball. It can be varied by changing the weight distribution when loading the trailer.

The maximum permissible vertical coupling load (60 kg) is specified on the towing equipment identification plate and in the vehicle documents. Always aim for the maximum load, especially in the case of heavy trailers. The vertical coupling load should never fall below 25 kg.

### **Rear axle load**

The permissible axle loads (see identification plate or vehicle documents) must not be exceeded.

## Vehicle care

<b>General Information</b> .....	<b>133</b>
Accessories and vehicle modifications .....	133
Vehicle storage .....	134
End-of-life vehicle recovery .....	134
<b>Vehicle checks</b> .....	<b>135</b>
Performing work .....	135
Bonnet .....	135
Engine oil .....	136
Engine coolant .....	137
Power steering fluid .....	137
Washer fluid .....	138
Brakes .....	138
Brake fluid .....	138
Vehicle battery .....	138
Wiper blade replacement .....	140
<b>Bulb replacement</b> .....	<b>141</b>
Halogen headlights .....	141
Fog lights .....	143
Tail lights .....	143
Side turn signal lights .....	144
Centre high-mounted brake light .....	144
Number plate light .....	144

Interior lights .....	145
Instrument panel illumination ...	146
<b>Electrical system</b> .....	<b>147</b>
Fuses .....	147
Engine compartment fuse box .	148
Instrument panel fuse box .....	149
<b>Vehicle tools</b> .....	<b>150</b>
Tools .....	150
<b>Wheels and tyres</b> .....	<b>151</b>
Winter tyres .....	151
Tyre designations .....	151
Tyre pressure .....	152
Tyre pressure monitoring system .....	152
Tread depth .....	154
Changing tyre and wheel size .	154
Wheel covers .....	155
Tyre chains .....	155
Tyre repair kit .....	155
Wheel changing .....	158
Spare wheel .....	159
<b>Jump starting</b> .....	<b>162</b>
<b>Towing</b> .....	<b>163</b>
Towing the vehicle .....	163
Towing another vehicle .....	164
<b>Appearance care</b> .....	<b>165</b>
Exterior care .....	165
Interior care .....	167

## General Information

### Accessories and vehicle modifications

We recommend the use of genuine parts and accessories and factory approved parts specific for your vehicle type. We cannot assess or guarantee reliability of other products - even if they have a regulatory or otherwise granted approval.

Do not make any modifications to the electrical system, e.g. changes of electronic control units (chip tuning).

#### Caution

When transporting the vehicle on a train or on a recovery vehicle, the mud flaps might be damaged.

## Vehicle storage

### Storage for a long period of time

If the vehicle is to be stored for several months:

- Wash and wax the vehicle.
- Have the wax in the engine compartment and underbody checked.
- Clean and preserve the rubber seals.
- Fill up fuel tank completely.
- Change the engine oil.
- Drain the washer fluid reservoir.
- Check the coolant antifreeze and corrosion protection.
- Adjust tyre pressure to the value specified for full load.
- Park the vehicle in a dry, well ventilated place. Engage first or reverse gear to prevent the vehicle from rolling.
- Do not apply the parking brake.

- Open the bonnet, close all doors and lock the vehicle.
- Disconnect the clamp from the negative terminal of the vehicle battery. Beware that all systems are not functional, e.g. anti-theft locking system.

### Putting back into operation

When the vehicle is to be put back into operation:

- Connect the clamp to the negative terminal of the vehicle battery. Activate the electronics of the power windows.
- Check tyre pressure.
- Fill up the washer fluid reservoir.
- Check the engine oil level.
- Check the coolant level.
- Fit the number plates if necessary.

## End-of-life vehicle recovery

Information on end-of-life vehicle recovery centres and the recycling of end-of-life vehicles is available on our website. Only entrust this work to an authorised recycling centre.

Natural gas vehicles must be recycled by a service centre authorised for natural gas vehicles.

## Vehicle checks

### Performing work



#### **⚠ Warning**

Only perform engine compartment checks when the ignition is off.

The cooling fan may start operating even if the ignition is off.

#### **⚠ Danger**

The ignition system uses extremely high voltage. Do not touch.

### Bonnet


#### Opening



Pull the release lever and return it to its original position.



Push the safety catch and open the bonnet.



Secure the bonnet support.

If the bonnet is opened during an Autostop, the engine will be restarted automatically for safety reasons.

Stop-start system ⇨ 111.

## Closing

Lower the bonnet and allow it to fall into the latch from a low height (approx. 20 cm). Check that the bonnet is engaged.

## Engine oil

Check the engine oil level manually on a regular basis to prevent damage to the engine. Ensure that the correct specification of oil is used.


Recommended fluids and lubricants ⇨ 169.

Low engine oil level control indicator  ⇨ 84.


Check with the vehicle on a level surface. The engine must be at operating temperature and switched off for at least 5 minutes.

Pull out the dipstick, wipe it clean, insert it to the stop on the handle, pull out and read the engine oil level.

Insert dipstick to the stop on the handle and make half a turn.



When the engine oil level has dropped to the **MIN** mark, top up engine oil.



We recommend the use of the same grade of engine oil that was used at last change.

The engine oil level must not exceed the **MAX** mark on the dipstick.

### Caution

Overfilled engine oil must be drained or suctioned out.

Capacities ⇨ 179.

Fit the cap on straight and tighten it.

## Engine coolant

The coolant provides freeze protection down to approx.  $-28^{\circ}\text{C}$ . In northern countries with very low temperatures, the factory filled coolant provides frost protection down to approx.  $-37^{\circ}\text{C}$ .

### Caution

Only use approved antifreeze.

## Coolant level

### Caution

Too low a coolant level can cause engine damage.



If the cooling system is cold, the coolant level should be between the **MIN** and **MAX** mark. Top up if the level is low.


### ⚠ Warning

Allow the engine to cool before opening the cap. Carefully open the cap, relieving the pressure slowly.

To top up use a 1:1 mixture of released coolant concentrate mixed with clean tap water. If no coolant concentrate is available, use clean tap water. Install the cap tightly. Have

the coolant concentration checked and have the cause of the coolant loss remedied by a workshop.


## Power steering fluid



If the fluid level in the reservoir falls below the **MIN** mark consult a workshop.

If an unusual noise sounds during steering or the power steering reacts conspicuously, seek the assistance of a workshop.

## Washer fluid



Fill with clean water mixed with a suitable quantity of windscreen washer fluid which contains antifreeze.

### Caution

Only washer fluid with a sufficient antifreeze concentration provides protection at low temperatures or a sudden drop in temperature.

Use of washer fluid containing isopropanol can damage exterior lamps.

## Brakes

A squealing noise, or illumination of brake pad wear control indicator  indicates that the brake lining is at its minimum thickness.

Continued driving is possible but have the brake linings replaced as soon as possible.


Once new brake linings are installed, do not brake unnecessarily hard for the first few journeys.

Brake pad wear indicator  ⇨ 80.

## Brake fluid

### Warning

Brake fluid is poisonous and corrosive. Avoid contact with eyes, skin, fabrics and painted surfaces.



The brake fluid level must be between the **MIN** and **MAX** marks.

When topping up, ensure maximum cleanliness as contamination of the brake fluid can lead to brake system malfunctions. Have the cause of the loss of brake fluid remedied by a workshop.

Only use high-performance brake fluid approved for the vehicle.

Brake and clutch fluid ⇨ 169.

## Vehicle battery

The vehicle battery is maintenance-free provided that the driving profile allows sufficient charging of the

battery. Short-distance-driving and frequent engine starts can discharge the battery. Avoid the use of unnecessary electrical consumers.



Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.

Laying up the vehicle for more than 4 weeks can lead to battery discharge. Disconnect the clamp from the negative terminal of the vehicle battery.

Ensure the ignition is switched off before connecting or disconnecting the vehicle battery.

Vehicle battery discharge protection ⇨ 101.

## Replacing the vehicle battery

### Note

Any deviation from the instructions given in this paragraph may lead to a temporary deactivation of the stop-start system.

In vehicles with stop-start system, ensure the correct battery is used when replacing the battery. We recommend that you have the battery replaced by a workshop.

Stop-start system ⇨ 111.

## Charging the vehicle battery

### ⚠ Warning

On vehicles with stop-start system, ensure that the charging potential does not exceed 14.6 volts when using a battery charger. Otherwise the battery might be damaged.

Jump starting ⇨ 162.

## Warning label




Meaning of symbols:

- No sparks, naked flames or smoking.
- Always shield eyes. Explosive gases can cause blindness or injury.
- Keep the vehicle battery out of reach of children.
- The vehicle battery contains sulphuric acid which could cause blindness or serious burn injuries.

- See the Owner's Manual for further information.
- Explosive gas may be present in the vicinity of the vehicle battery.

## Wiper blade replacement




Lift the wiper arm until it stays in the raised position, press button to disengage the wiper blade and remove.

Attach the wiper blade slightly angled to the wiper arm and push until it engages.

Lower wiper arm carefully.


### Wiper blade on rear swing door



Lift wiper arm, press and hold retaining clip and detach wiper blade. Attach the wiper blade slightly angled to the wiper arm and push until it engages.

Lower wiper arm carefully.

### Wiper blade on tailgate



Lift wiper arm, press retaining clips to detach wiper blade.

Attach the wiper blade to the wiper arm and push until it engages.

Lower wiper arm carefully.

## Bulb replacement

Switch off the ignition and switch off the relevant switch or close the doors. Only hold a new bulb at the base! Do not touch the bulb glass with bare hands.


Use only the same bulb type for replacement.

Replace headlight bulbs from within the engine compartment.

### Bulb check

After a bulb replacement, switch on the ignition, operate and check the lights.

## Halogen headlights




Headlights have separate systems for low beam/sidelight **1** (outer bulb), high beam/daytime running light **2** (inner bulb).

To access bulbs, pull off protective covers.

### Low beam


1. Remove protective cover.
2. Detach connector from bulb.
3. Disengage wire clip and remove bulb from reflector.



4. Insert new bulb in reflector so that the locating tab of the bulb aligns with the reflector recess.
5. Attach connector to bulb.
6. Engage wire clip.
7. Install protective cover.

### High beam

1. Remove protective cover.
2. Detach connector from bulb.
3. Disengage wire clip and remove bulb from reflector.



4. Insert new bulb in reflector so that the bulb aligns with the reflector recess.
5. Engage wire clip and attach connector onto bulb.
6. Install protective cover.

### Sidelight


1. Remove protective cover.  
Withdraw bulb holder from reflector by turning anticlockwise.



2. Remove bulb from socket, insert new bulb.
3. Insert bulb holder in reflector.
4. Rotate clockwise to engage.
5. Install protective cover.

### Daytime running light


1. Remove protective cover.



2. Withdraw bulb holder from reflector by turning anticlockwise.
3. Remove bulb from socket, insert new bulb.
4. Insert bulb holder in reflector.
5. Rotate clockwise to engage.
6. Install protective cover.

### Front turn signal light

1. Remove protective cover.



2. Withdraw bulb holder from reflector by turning anticlockwise.
3. Push bulb into holder slightly, rotate anticlockwise, remove and renew bulb.
4. Insert bulb holder in reflector.
5. Rotate clockwise to engage.
6. Install protective cover.


## Fog lights

Have bulbs replaced by a workshop.


## Tail lights



1. Remove the three retaining screws.
2. Remove light housing from vehicle.
3. Disengage connector plug from bulb holder.



4. Unscrew the four retaining screws using a screwdriver. Turn bulb holder for reverse light anticlockwise and replace bulb.
5. Remove bulb holder and seal from light housing.
6. Push bulb into socket slightly, rotate anticlockwise, remove and renew bulb.



Brake light (1)

Turn signal light (2)

Tail light (3)

Tail light/fog light (4)

7. Install seal on bulb holder ensuring it is fitted correctly. Install bulb holder in light housing ensuring that it engages correctly. Tighten the four retaining screws using a screwdriver.
8. Install reverse light bulb holder and turn clockwise to tighten.
9. Engage connector plug.

10. Insert light housing in body, ensuring correct positioning. Tighten the three retaining screws.

11. Switch on ignition, operate and check all lights.

### Side turn signal lights

Have bulbs replaced by a workshop.

### Centre high-mounted brake light


Have bulbs replaced by a workshop.

### Number plate light

#### Tailgate



1. Insert screwdriver as indicated by the arrows, press to the side and release the bulb housing.



2. Turn the bulb holder anticlockwise to remove from the bulb housing. Remove the bulb by pulling.
3. Replace the bulb.
4. Insert bulb holder in bulb housing and rotate clockwise
5. Install the bulb housing ensuring it engages correctly.

### Back doors



1. Insert screwdriver as indicated by the arrows, press to the left and release the bulb housing.
2. Press bulb slightly towards spring clip and remove.
3. Replace the bulb.
4. Install the bulb housing ensuring it engages correctly.


### Interior lights

#### Front and rear courtesy light



1. Remove lens using a flat blade screwdriver.
2. Open the rear cover.
3. Renew bulb.
4. Close rear cover.
5. Reinstall lens.

### Front courtesy light, reading lights




1. Remove lens using a flat blade screwdriver.
2. Open the rear cover.
3. Renew bulbs.
4. Close rear cover.
5. Reinstall lens.

### Removable rear courtesy light



1. Press the button at the top of the lamp assembly to release it.



2. Prise the lamp assembly out at the points illustrated.
3. Renew bulb, ensuring it engages correctly.
4. Reinstall lamp assembly.

### Instrument panel illumination

Have bulbs replaced by a workshop.

## Electrical system

### Fuses


Data on the replacement fuse must match the data on the defective fuse.

There are two fuse boxes in the vehicle:

- on the right of the engine compartment, next to the battery
- behind a cover on the lower part of the instrument panel, on the driver's side

Before replacing a fuse, turn off the respective switch and the ignition.

There are different types of fuses in the vehicle.



Depending on the type of fuse, a blown fuse can be recognised by its melted wire. Do not replace the fuse until the cause of the fault has been remedied.

It is advisable to carry a full set of fuses.


Some functions are protected by several fuses. Fuses may also be inserted without existence of a function.


#### Note

Not all fuse box descriptions in this Owner's Manual may apply to your vehicle. Refer to the fuse box label, where fitted.

### Fuse extractor

Use a fuse extractor to remove fuses.






To help in replacing fuses, a fuse extractor may be used.

Place the fuse extractor on the various types of fuse from the top or side, and withdraw fuse.

## Engine compartment fuse box



The fuse box is on the right of the engine compartment, next to the battery.

To remove the protective cover and access the fuses, remove the two screws (see illustration).



**No. Circuit**

F09 Rear door switch

F10 Horn

F14 High beam

F15 PTCI heater

F19 Air conditioning system

F20 Heated rear window

F21 Fuel pump

F30 Fog lights

F84 CNG system

F85 Power outlets


F86 Cigarette lighter / heated seats

F87 Stop-start system


F88 Mirror heating

After having changed defective fuses refit the fuse box cover.

If the fuse box cover is not closed correctly, malfunction may occur.

**Instrument panel fuse box**

The fuse box is located behind a cover on the lower part of the instrument panel, on the driver's side.



**No. Circuit**

---

- F12 Right low beam
- F13 Left low beam / headlight range adjustment
- F31 Fusebox relays / body control unit relays
- F32 Courtesy lights
- F36 Diagnostic connector / climate control system / Infotainment system / tyre pressure monitoring system / alarm siren
- F37 Instrument panel / braking system
- F38 Central locking system
- F43 Windscreen washer system
- F47 Power windows
- F48 Power windows
- F49 Exterior mirrors / Infotainment system / parking assist / tyre pressure monitoring system / instrument illumination / rain sensor

**No. Circuit**


---

- F51 Infotainment system / braking system / clutch / interior heater
- F53 Instrument panel
- F94 Power outlet load compartment
- F95 Cigarette lighter / power outlet
- F96 Cigarette lighter / power outlet
- F97 Heated front seat
- F98 Heated front seat

## Vehicle tools


### Tools

#### Van



The tools and the vehicle jacking equipment are in the storage area behind the front seat. Pull front handle and slide seat forwards to access ↻ 35.

## Combi, Combo Tour



The tools and the vehicle jacking equipment are stored in the load compartment behind a panel on the right-hand side.

Wheel changing ⇨ 158.

Spare wheel ⇨ 159.

## Wheels and tyres

### Tyre condition, wheel condition

Drive over edges slowly and at right angles if possible. Driving over sharp edges can cause tyre and wheel damage. Do not trap tyres on the kerb when parking.

Regularly check the wheels for damage. Seek the assistance of a workshop in the event of damage or unusual wear.

### Winter tyres

Winter tyres improve driving safety at temperatures below 7 °C and should therefore be fitted on all wheels.

Tyres of size 185/65 R15, 195/65 R15 and 195/60 R16 C are permitted as winter tyres.

In accordance with country-specific regulations, affix the speed sticker in the driver's field of view.

### Tyre designations

E.g. **215/60 R 16 95 H**

**215** : tyre width, mm

**60** : cross-section ratio (tyre height to tyre width), %

**R** : belt type: Radial

**RF** : type: RunFlat

**C** : cargo or commercial use

**16** : wheel diameter, inches

**95** : load index e.g. 95 is equivalent to 690 kg

**H** : speed code letter

Speed code letter:

**Q** : up to 160 km/h

**S** : up to 180 km/h

**T** : up to 190 km/h

**H** : up to 210 km/h

**V** : up to 240 km/h

**W** : up to 270 km/h

### Directional tyres

Fit directional tyres such that they roll in the direction of travel. The rolling direction is indicated by a symbol (e.g. an arrow) on the sidewall.

## Tyre pressure

Check the pressure of cold tyres at least every 14 days and before any long journey. Do not forget the spare wheel. This also applies to vehicles with tyre pressure monitoring system.

Unscrew the valve cap.

Tyre pressure ⇨ 180.

The tyre pressure information label on the door frame (if fitted) indicates the original equipment tyres and the correspondent tyre pressures.

The tyre pressure data refers to cold tyres. It applies to summer and winter tyres.

Always inflate the spare tyre to the pressure specified for full load.

Incorrect tyre pressures will impair safety, vehicle handling, comfort and fuel economy and will increase tyre wear.

Tyre pressures differ depending on various options. For the correct tyre pressure value, follow the procedure below:

1. Identify the engine identifier code. Engine data ⇨ 174.

2. Identify the respective tyre.

The tyre pressure tables show all possible tyre combinations ⇨ 180.

For the tyres approved for your vehicle, refer to the EEC Certificate of Conformity provided with your vehicle or other national registration documents.

The driver is responsible for correct adjustment of tyre pressures.

### Warning

If the pressure is too low, this can result in considerable tyre warm-up and internal damage, leading to tread separation and even to tyre blow-out at high speeds.

## Tyre pressure monitoring system

The Tyre Pressure Monitoring System (TPMS) uses radio and sensor technology to check tyre pressure levels.

### Caution

Tyre pressure monitoring system warns only about low tyre pressure condition and does not replace regular tyre maintenance by the driver.

The TPMS sensors monitor the air pressure in the tyres and transmit tyre pressure readings to a receiver located in the vehicle.


All wheels must be equipped with pressure sensors and the tyres must have the prescribed pressure.

Tyre pressure chart ⇨ 180.

### Note

In countries where the tyre pressure monitoring system is legally required, the use of wheels without pressure sensors will invalidate the vehicle type approval.

## Low tyre pressure condition



A detected low tyre pressure condition is indicated by illumination of control indicator (⚠) ⇨ 83 together with a warning chime. In vehicles with Multifunction version of the Driver Information Centre (DIC), a corresponding message is also displayed.

If (⚠) illuminates, stop as soon as possible and inflate the tyres as recommended ⇨ 180.

After inflating, driving may be required to update the tyre pressure values in the system. During this time (⚠) may illuminate.

If (⚠) illuminates at lower temperatures and extinguishes after some driving, this could be an indicator for approaching a low tyre pressure condition. Check tyre pressure of all four tyres.

If the tyre pressure must be reduced or increased, switch off ignition.

Only mount wheels with pressure sensors, otherwise the tyre pressure value cannot be recognised by the system and (⚠) flashes for several seconds then illuminates continuously. In vehicles with Multifunction version of the DIC, a corresponding message is also displayed.

A spare wheel or temporary spare wheel is not equipped with pressure sensors. TPMS is not operational for these wheels. For the further three wheels, TPMS remains operational.

Spare wheel ⇨ 159, Wheel changing ⇨ 158.

Control indicator (⚠) and (depending on version) a corresponding message appears at each ignition cycle until the tyres are inflated to the correct tyre pressure.

Driver Information Centre (DIC) ⇨ 86.

## Temperature dependency

Tyre pressure depends on the temperature of the tyre. During driving, tyre temperature and pressure increase.

Tyre pressure values provided on the tyre information label and tyre pressure chart are valid for cold tyres, which means at 20 °C. The pressure increases by nearly 10 kPa (0.1 bar) for a 10 °C temperature increase. This must be considered when warm tyres are checked.

## Relearn function

After changing wheels, TPMS needs to recalculate. The relearn process takes up to 20 minutes of driving with a minimum speed of 24 km/h.

If problems occur during the relearn process, control indicator (⚠) flashes for several seconds then illuminates continuously and (depending on version) a warning message is displayed in the DIC.

Driver Information Centre (DIC) ⇨ 86.

### General information

The use of tyre chains or commercially available liquid tyre repair kits can impair the function of the system. Factory-approved tyre repair kits can be used.

Tyre repair kit ⇨ 155, Tyre chains ⇨ 155.

External high-power radio equipment could disrupt the TPMS.

Each time the tyres are replaced, TPMS sensors must be dismantled and serviced by a workshop.

### Tread depth

Check tread depth at regular intervals.

Tyres should be replaced for safety reasons at a tread depth of 2-3 mm (4 mm for winter tyres).

For safety reasons, it is recommended that the tread depth of the tyres on one axle should not vary by more than 2 mm.



The legally permissible minimum tread depth (1.6 mm) has been reached when the tread has worn down as far as one of the tread wear indicators (TWI). Their position is indicated by markings on the sidewall.

If there is more wear at the front than the rear, swap round front wheels and rear wheels periodically. Ensure that the direction of rotation of the wheels is the same as before.

Tyres age, even if they are not used. We recommend tyre replacement every 6 years.

### Changing tyre and wheel size

If tyres of a different size than those fitted at the factory are used, it may be necessary to reprogramme the speedometer as well as the nominal tyre pressure and make other vehicle modifications.

After converting to a different tyre size, have the label with tyre pressures replaced.

#### **⚠ Warning**

Use of unsuitable tyres or wheels may lead to accidents and will invalidate the vehicle type approval.

## Wheel covers

Wheel covers and tyres that are factory approved for the respective vehicle and comply with all of the relevant wheel and tyre combination requirements must be used.

If the wheel covers and tyres used are not factory approved, the tyres must not have a rim protection ridge.

Wheel covers must not impair brake cooling.

### **⚠ Warning**

Use of unsuitable tyres or wheel covers could lead to sudden pressure loss and thereby accidents.

## Tyre chains



Tyre chains are only permitted on the front wheels.

Always use fine mesh chains that add no more than 10 mm to the tyre tread and the inboard sides (including chain lock).

Do not exceed 50 km/h when tyre chains are fitted.

### **⚠ Warning**

Damage may lead to tyre blowout.

## Tyre repair kit

Minor damage to the tyre tread can be repaired with the tyre repair kit.

Do not remove foreign bodies from the tyres.

Tyre damage exceeding 4 mm or that is at tyre's sidewall cannot be repaired with the tyre repair kit.


### **⚠ Warning**

Do not drive faster than 80 km/h.  
Do not use for a lengthy period.  
Steering and handling may be affected.


If you have a flat tyre:

Apply the parking brake and engage first or reverse gear.

The tyre repair kit may be located under the front seat, in the glovebox, or on the right side of the load compartment behind a cover.




1. Take the tyre repair kit from the vehicle.
2. Remove the compressor.
3. Set the compressor upright near the tyre.
4. Unscrew valve cap from defective tyre.



5. Screw the flexible filler hose onto the tyre valve.
6. The switch on the compressor must be set to **O**.
7. Connect the compressor plug to the power outlet or cigarette lighter socket.

To avoid discharging the battery, we recommend running the engine.




8. Set the rocker switch on the compressor to **I**. The tyre is filled with sealant.
9. All of the sealant is pumped into the tyre. Then the tyre is inflated. Tyre pressure  $\varnothing$  180. When the correct pressure is obtained, switch off the compressor.
10. If a pressure of 1.5 bar is not obtained within 5 minutes, remove the tyre repair kit. Move the vehicle one tyre rotation. Reattach the tyre repair kit and continue the filling procedure for 5 minutes. If a pressure of 1.8 bar is still not obtained within 5 minutes, the tyre is too badly

damaged. Seek the assistance of a workshop.

Do not run the compressor longer than 20 minutes.

11. Detach the tyre repair kit.
12. Remove any excess sealant using a cloth.
13. Take the label indicating maximum permitted speed from the sealant bottle and affix in the driver's field of view.
14. Continue driving immediately so that sealant is evenly distributed in the tyre. After driving approx. 10 km (but no more than 10 minutes), stop and check tyre pressure. Screw compressor air hose directly onto tyre valve and compressor when doing this.



If tyre pressure is more than 1.8 bar, set it to the correct value. Repeat the procedure until there is no more loss of pressure.

If the tyre pressure has fallen below 1.8 bar, the vehicle must not be used. Seek the assistance of a workshop.

15. Stow away tyre repair kit in load compartment.

#### Note

The driving characteristics of the repaired tyre are severely affected, therefore have this tyre replaced.

If unusual noise is heard or the compressor becomes hot, turn compressor off and allow to cool.

Note the expiry date of the kit. After this date its sealing capability is no longer guaranteed. Pay attention to storage information on sealant bottle.

Replace the used sealant bottle. Dispose of the bottle as prescribed by applicable laws.

The compressor and sealant can be used from approx. -20 °C.

#### Replacing the sealant canister

To replace the sealant canister:

1. Disconnect the compressor air hose.



2. Turn the canister anticlockwise to lift it out.
3. Insert the new canister and turn it clockwise.
4. Connect the compressor air hose to the canister and fit the flexible filler tube into its allocated space.

## Wheel changing

Some vehicles are equipped with a tyre repair kit instead of a spare wheel ↪ 155.

Make the following preparations and observe the following information:

- Park the vehicle on a level, firm and non-skid surface. The front wheels must be in the straight-ahead position.
- Apply the parking brake and engage first or reverse gear.
- Remove the spare wheel ↪ 159.
- Never change more than one wheel at once.
- Use the jack only to change wheels in case of puncture, not for seasonal winter or summer tyre change.


- The jack is maintenance-free.
- If the ground on which the vehicle is standing is soft, a solid board (max. 1 cm thick) should be placed under the jack.
- No people or animals may be in the vehicle when it is jacked-up.
- Never crawl under a jacked-up vehicle.
- Do not start the vehicle when it is raised on the jack.
- Clean wheel nuts and thread with a clean cloth before mounting the wheel.

### Warning


Do not grease wheel bolt, wheel nut and wheel nut cone.



1. Disengage wheel nut caps with a screwdriver and remove. Pull off the wheel cover using a suitable tool.
2. Attach wheel wrench securely and loosen each wheel nut by half a turn.




3. Vehicle jacking points are located at the front and rear.



4. Set the jack to the necessary height. Position it directly below

the jacking point in a manner that prevents it from slipping.



With the jack correctly aligned, rotate until wheel is clear of the ground.

5. Unscrew the wheel nuts.
6. Change the wheel. Spare wheel  $\diamond$  159.
7. Screw on the wheel nuts.
8. Lower vehicle.
9. Install the wheel wrench ensuring that it locates securely and tighten each nut in a crosswise sequence. Tightening torque is 85 Nm (steel wheel) or 120 Nm (alloy wheel).

10. Align the valve hole in the wheel cover with the tyre valve before installing.

Install wheel nut caps.

11. Stow the replaced wheel  $\diamond$  159 and the vehicle tools  $\diamond$  150.
  12. Check the tyre pressure of the installed tyre and the wheel torque as soon as possible.
- Have the defective tyre renewed or repaired as soon as possible.


## Spare wheel

Some vehicles are equipped with a tyre repair kit  $\diamond$  155 instead of a spare wheel.

If mounting a spare wheel which is different from the other wheels, this wheel might be classified as a temporary spare wheel and the corresponding speed limits apply, even though no label indicates this. Seek the assistance of a workshop to check the applicable speed limit.


**Caution**

The use of a spare wheel that is smaller than the other wheels or in combination with winter tyres could affect driveability. Have the defective tyre replaced as soon as possible.



Depending on model variant, the spare wheel is stored beneath the floor or in the load compartment.


1. Attach the extension bar 2 to the wheel wrench 1. Vehicle tools ⇨ 150.




2. Insert the wheel wrench into the aperture in the load compartment floor.
3. Rotate the wheel wrench to lower the spare wheel to the floor.



4. Withdraw spare wheel from beneath the vehicle.



5. Unscrew knob 2 and release cable attachment 1 from spare wheel.
6. Change the wheel.
7. Position the replaced wheel at the rear of the vehicle with the outside of the wheel facing downwards.



8. Pass the retainer 1 through the hole in the rim, inserting the locating pin into one of the bolt holes and secure with knob 2.
9. Insert the wheel wrench into the aperture in the load compartment floor and rotate to fully raise the spare wheel.

Have the defective tyre renewed or repaired as soon as possible.

### CNG vehicles

Vehicles with CNG; the spare wheel is located in the load compartment.



1. Unscrew two bolts using the wheel wrench and remove spare wheel from bracket. Vehicle tools  $\triangleright$  150.
2. Change the wheel.



3. Position the replaced spare wheel onto the bracket ensuring correct alignment of the locating pin.
4. Secure spare wheel by tightening two bolts using the wheel wrench.

Have the defective tyre renewed or repaired as soon as possible.

### Directional tyres

Fit directional tyres such that they roll in the direction of travel. The rolling direction is indicated by a symbol (e.g. an arrow) on the sidewall.

The following applies to tyres fitted opposing the rolling direction:

- Driveability may be affected. Have the defective tyre renewed or repaired as soon as possible.
- Drive particularly carefully on wet and snow-covered road surfaces.

## Jump starting

Do not start with quick charger.

A vehicle with a discharged battery can be started using jump leads and the battery of another vehicle.

### ⚠ Warning

Be extremely careful when starting with jump leads. Any deviation from the following instructions can lead to injuries or damage caused by battery explosion or damage to the electrical systems of both vehicles.


### ⚠ Warning

Avoid contact of the battery with eyes, skin, fabrics and painted surfaces. The fluid contains sulphuric acid which can cause injuries and damage in the event of direct contact.

- Never expose the battery to naked flames or sparks.

- A discharged battery can already freeze at a temperature of 0 °C. Defrost the frozen battery before connecting jump leads.
- Wear eye protection and protective clothing when handling a battery.
- Use a booster battery with the same voltage (12 Volts). Its capacity (Ah) must not be much less than that of the discharged battery.
- Use jump leads with insulated terminals and a cross section of at least 16 mm<sup>2</sup> (25 mm<sup>2</sup> for diesel engines).
- Do not disconnect the discharged battery from the vehicle.
- Switch off all unnecessary electrical consumers.
- Do not lean over the battery during jump starting.
- Do not allow the terminals of one lead to touch those of the other lead.

- The vehicles must not come into contact with each other during the jump starting process.
- Apply the parking brake, transmission in neutral.



Lead connection order:

1. Connect the red lead to the positive terminal of the booster battery.
2. Connect the other end of the red lead to the positive terminal of the discharged battery.

3. Connect the black lead to the negative terminal of the booster battery.
4. Connect the other end of the black lead to a vehicle grounding point, such as the engine block or an engine mounting bolt. Connect as far away from the discharged battery as possible, however at least 60 cm.

Route the leads so that they cannot catch on rotating parts in the engine compartment.


To start the engine:

1. Start the engine of the vehicle providing the jump.
2. After 5 minutes, start the other engine. Start attempts should be made for no longer than 15 seconds at an interval of 1 minute.
3. Allow both engines to idle for approx. 3 minutes with the leads connected.

4. Switch on electrical consumers (e.g. headlights, heated rear window) of the vehicle receiving the jump start.
5. Reverse above sequence exactly when removing leads.

## Towing

### Towing the vehicle



Release the cap by carefully lifting with a screwdriver. To prevent damage, it is recommended to place a cloth between the screwdriver and the frame.

The towing eye is stowed with the vehicle tools ⇨ 150.

Screw in the towing eye as far as it will go until it stops in a horizontal position.

Attach a tow rope – or better still a tow rod – to the towing eye.

**Caution**

The towing eye must only be used for towing and not for recovering the vehicle.

Switch on ignition to release steering wheel lock and to permit operation of brake lights, horn and windscreen wiper.

Transmission in neutral.

**Note**

If neutral cannot be selected on vehicles with manual transmission automated (MTA), the vehicle must only be towed with the drive wheels raised off the ground.

**Caution**

Drive slowly. Do not drive jerkily. Excessive tractive force can damage the vehicle.


When the engine is not running, considerably more force is needed to brake and steer.

To prevent the entry of exhaust gases from the towing vehicle, switch on the air recirculation and close the windows.

Seek the assistance of a workshop.

After towing, unscrew the towing eye and replace the cap.

**Towing another vehicle**



Insert a screwdriver in the slot at the side of the cap. Release the cap by carefully levering the screwdriver. To prevent damage it is recommended to place a cloth between the screwdriver and the frame.

The towing eye is stowed with the vehicle tools ⇨ 150.

Screw in the towing eye as far as it will go until it stops in a horizontal position.

Attach a tow rope – or even better a tow bar – to the towing eye.

The towing eye must only be used for towing and not for recovering a vehicle.

**Caution**

Drive slowly. Do not drive jerkily. Excessive tractive force can damage the vehicle.

After towing, unscrew the towing eye. Insert cap.

## Appearance care

### Exterior care

#### Locks

The locks are lubricated at the factory using a high quality lock cylinder grease. Use de-icing agent only when absolutely necessary, as this has a degreasing effect and impairs lock function. After using a de-icing agent, have the locks regreased by a workshop.

#### Washing

The paintwork of your vehicle is exposed to environmental influences. Wash and wax your vehicle regularly. When using automatic vehicle washes, select a programme that includes waxing.

Bird droppings, dead insects, resin, pollen and the like should be cleaned off immediately, as they contain aggressive constituents which can cause paint damage.

If using a vehicle wash, comply with the vehicle wash manufacturer's instructions. The windscreen wiper and rear window wiper must be switched off. Remove antenna and external accessories such as roof racks etc.

If you wash your vehicle by hand, make sure that the insides of the wheel housings are also thoroughly rinsed out.

Clean edges and folds on opened doors and the bonnet as well as the areas they cover.

Caution
<p>Always use a cleaning agent with a pH value of 4 to 9.</p> <p>Do not use cleaning agents on hot surfaces.</p>

Have the door hinges of all doors greased by a workshop.

Do not clean the engine compartment with a steam-jet or high-pressure jet cleaner.

Thoroughly rinse and leather-off the vehicle. Rinse leather frequently. Use separate leathers for painted and glass surfaces: remnants of wax on the windows will impair vision.

Do not use hard objects to remove spots of tar. Use tar removal spray on painted surfaces.

#### Exterior lights

Headlight and other light covers are made of plastic. Do not use any abrasive or caustic agents, do not use an ice scraper, and do not clean them dry.

#### Polishing and waxing

Wax the vehicle regularly (at the latest when water no longer beads). Otherwise, the paintwork will dry out.

Polishing is necessary only if the paint has become dull or if solid deposits have become attached to it.

Paintwork polish with silicone forms a protective film, making waxing unnecessary.

Plastic body parts must not be treated with wax or polishing agents.

## Windows and windscreen wiper blades

Use a soft lint-free cloth or chamois leather together with window cleaner and insect remover.

When cleaning the rear window from inside, always wipe in parallel to the heating element to prevent damage.

For mechanical removal of ice, use a sharp-edged ice scraper. Press the scraper firmly against the glass so that no dirt can get under it and scratch the glass.

Clean smearing wiper blades with a soft cloth and window cleaner.

Remove dirt residues from smearing wiper blades by using a soft cloth and window cleaner. Also make sure to remove any residues such as wax, insect residues and similar from the window.

Ice residues, pollution and continuous wiping on dry windows will damage or even destroy the wiper blades.

## Glass panel

Never clean with solvents or abrasive agents, fuels, aggressive media (e.g. paint cleaner, acetone-containing solutions etc.), acidic or highly alkaline media or abrasive pads. Do not apply wax or polishing agents to the glass panel.

## Wheels and tyres

Do not use high-pressure jet cleaners.

Clean rims with a pH-neutral wheel cleaner.

Rims are painted and can be treated with the same agents as the body.

## Paintwork damage

Rectify minor paintwork damage with a touch-up pen before rust forms. Have more extensive damage or rust areas repaired by a workshop.

## Underbody

Some areas of the vehicle underbody have a PVC undercoating while other critical areas have a durable protective wax coating.

After the underbody is washed, check the underbody and have it waxed if necessary.

Bitumen/rubber materials could damage the PVC coating. Have underbody work carried out by a workshop.

Before and after winter, wash the underbody and have the protective wax coating checked.

## Natural gas system

Do not direct the steam jet or high-pressure jet towards natural gas system components. It is particularly important to protect the natural gas tank and the pressure valves on the vehicle underbody and the bulkhead in the engine compartment.

These components must not be treated using chemical cleaners or preservatives.

Have components of the natural gas system cleaned by a workshop authorised to carry out maintenance of natural gas vehicles.

## Towing equipment

Do not clean the coupling ball bar with a steam-jet or high-pressure jet cleaner.

## Interior care

### Interior and upholstery

Only clean the vehicle interior, including the instrument panel fascia and panelling, with a dry cloth or interior cleaner.

Clean the leather upholstery with clear water and a soft cloth. In case of heavy soiling, use leather care.

The instrument cluster and the displays should only be cleaned using a soft damp cloth. If necessary, use a weak soap solution.

Clean fabric upholstery with a vacuum cleaner and brush. Remove stains with an upholstery cleaner.

Clothing fabrics may not be colourfast. This could cause visible discolourations, especially on light-

coloured upholstery. Removable stains and discolourations should be cleaned as soon as possible.

Clean seat belts with lukewarm water or interior cleaner.

### Caution

Close Velcro fasteners as open Velcro fasteners on clothing could damage seat upholstery.

The same applies to clothing with sharp-edged objects, like zips or belts or studded jeans.

### Plastic and rubber parts

Plastic and rubber parts can be cleaned with the same cleaner as used to clean the body. Use interior cleaner if necessary. Do not use any other agent. Avoid solvents and petrol in particular. Do not use high-pressure jet cleaners.

## Service and maintenance

<b>General information</b> .....	<b>168</b>
Service information .....	168
<b>Recommended fluids, lubricants and parts</b> .....	<b>169</b>
Recommended fluids and lubricants .....	169

## General information

### Service information

In order to ensure economical and safe vehicle operation and to maintain the value of your vehicle, it is of vital importance that all maintenance work is carried out at the proper intervals as specified.

The detailed, up-to-date service schedule for your vehicle is available at the workshop.

Service display ⇨ 74.

### Service intervals - petrol and CNG engines

Maintenance of your vehicle is required every 30,000 km or 2 years, whichever occurs first.

### Service intervals - diesel engines

Maintenance of your vehicle is required every 35,000 km or 2 years, whichever occurs first, unless otherwise indicated in the Driver Information Centre (DIC) ⇨ 86.

A shorter service interval can be valid for severe driving behaviour, e.g. for taxis and police vehicles.

Service display ⇨ 74.

### International service intervals

Maintenance of your vehicle is required every 20,000 km or after 1 year, whichever occurs first, unless otherwise indicated by the service display.

The international service intervals are valid for:

Albania, Belarus, Bosnia-Herzegovina, Georgia, Macedonia, Moldova, Montenegro, Serbia, Ukraine.

Service display ⇨ 74.

### Confirmations

Confirmation of service is recorded in the Service and Warranty Booklet. The date and mileage is completed with the stamp and signature of the servicing workshop.

Make sure that the Service and Warranty Booklet is completed correctly as continuous proof of

service is essential if any warranty or goodwill claims are to be met, and is also a benefit when selling the vehicle.

### Service interval with remaining engine oil life duration

The service interval is based on several parameters depending on usage.

When the engine oil requires changing, control indicator  will flash in the instrument cluster ⇨ 83. Depending on version, a message may also appear in the DIC ⇨ 83. Service display ⇨ 74.

## Recommended fluids, lubricants and parts

### Recommended fluids and lubricants

Only use products that meet the recommended specifications. Damage resulting from the use of products not in line with these specifications will not be covered by the warranty.

#### Warning

Operating materials are hazardous and could be poisonous. Handle with care. Pay attention to information given on the containers.

### Engine oil

Engine oil is identified by its quality and its viscosity. Quality is more important than viscosity when selecting which engine oil to use. The oil quality ensures e.g. engine cleanliness, wear protection and oil

ageing control, whereas viscosity grade gives information on the oil's thickness over a temperature range.

Dexos is the newest engine oil quality that provides optimum protection for petrol and diesel engines. If it is unavailable, engine oils of other listed qualities must be used.

Recommendations for petrol engines are also valid for Compressed Natural Gas (CNG) fuelled engines.

Select the appropriate engine oil based on its quality and viscosity ⇨ 172.

### Topping up engine oil

Engine oils of different manufacturers and brands can be mixed as long as they comply with the required engine oil quality and viscosity.

Use of engine oil with only ACEA A1/B1 or only A5/B5 quality is prohibited, since it can cause long-term engine damage under certain operating conditions.

Select the appropriate engine oil based on its quality and viscosity ⇨ 172.

### **Additional engine oil additives**

The use of additional engine oil additives could cause damage and invalidate the warranty.

### **Engine oil viscosity**

The SAE viscosity grade gives information on the thickness of the oil.

Multigrade oil is indicated by two figures, e.g. SAE 5W-30. The first figure, followed by a W, indicates the low temperature viscosity and the second figure the high temperature viscosity.

Select the appropriate viscosity grade  
⇨ 172.

All of the recommended viscosity grades are suitable for high ambient temperatures.

### **Coolant and antifreeze**

Use only antifreeze approved for the vehicle. Consult a workshop.

The system is factory filled with coolant designed for excellent corrosion protection and frost protection down to approx. -28 °C. In northern countries with very low temperatures the factory filled coolant

provides frost protection down to approx. -37 °C. This concentration should be maintained all year round.

The use of additional coolant additives that intend to give additional corrosion protection or seal against minor leaks can cause function problems. Liability for consequences resulting from the use of additional coolant additives will be rejected.

### **Brake and clutch fluid**


Over time, brake fluid absorbs moisture which will reduce braking effectiveness. The brake fluid should therefore be replaced at the specified interval.

## Technical data

<b>Vehicle identification</b> .....	<b>171</b>
Vehicle Identification Number ..	171
Identification plate .....	171
Engine identification .....	172
<b>Vehicle data</b> .....	<b>172</b>
Recommended fluids and lubricants .....	172
Engine data .....	174
Performance .....	176
Vehicle weight .....	177
Vehicle dimensions .....	178
Capacities .....	179
Tyre pressures .....	180

## Vehicle identification

### Vehicle Identification Number




The Vehicle Identification Number is visible through the windscreen



and in the floor on the front passenger side behind a cover.

### Identification plate

The identification plate is in the engine compartment.



Information on identification label:

- 1 : type approval number
- 2 : vehicle Identification Number
- 3 : vehicle type identification code
- 4 : permissible gross vehicle weight rating in kg
- 5 : permissible gross train weight in kg
- 6 : maximum permissible front axle load in kg
- 7 : maximum permissible rear axle load in kg
- 8 : engine type
- 9-11 : vehicle-specific or country-specific data

The combined total of front and rear axle loads must not exceed the permissible gross vehicle weight. For example, if the front axle is bearing its maximum permissible load, the rear axle can only bear a load that is equal to the gross vehicle weight minus the front axle load.

The technical data is determined in accordance with European Community standards. We reserve the right to make modifications. Specifications in the vehicle documents always have priority over those given in this manual.

### Engine identification

The technical data tables show the engine identifier code. Engine data  $\varnothing$  174.

To identify the respective engine, refer to the engine power in the EEC Certificate of Conformity provided with your vehicle or other national registration documents.

## Vehicle data

### Recommended fluids and lubricants

#### Required engine oil quality

##### Engine oil quality: Europe

**dexos 2** ✓

For countries with International service interval  $\varnothing$  168, you may use the oil qualities listed below:

##### Engine oil quality: International

**dexos 2** ✓

ACEA C3 ✓

ACEA A3/B4 ✓

## Engine oil viscosity grades

### Ambient temperature

down to -25 °C SAE 5W-30 or  
SAE 5W-40

below -25 °C SAE 0W-30 or  
SAE 0W-40

**Engine data**

<b>Sales designation</b>	<b>1.4</b>	<b>1.4</b>	<b>1.4</b>
<b>Engine identifier code</b>	<b>1.4i</b>	<b>1.4Turbo</b>	<b>1.4CNG</b>
Number of cylinders	4	4	4
Piston displacement [cm <sup>3</sup> ]	1368	1368	1368
Engine power [kW]	70	88	88
at rpm	6000	5000	5000
Torque [Nm]	127	206	206
at rpm	4500	3000	3000
Fuel type	Petrol	Petrol	Compressed Natural Gas/Petrol
Octane rating RON			
recommended	<b>95</b>	<b>95</b>	<b>95</b>
possible	98	98	98
Gas	–	–	CNG
Oil consumption [l/1000 km]	0.6	0.6	0.6

<b>Sales designation</b>	<b>1.3 Turbo</b>	<b>1.6 Turbo</b>	<b>1.6 Turbo</b>	<b>2.0 Turbo</b>
<b>Engine identifier code</b>	<b>1.3CDTI</b>	<b>1.6CDTI</b>	<b>1.6CDTI</b>	<b>2.0CDTI</b>
Number of cylinders	4	4	4	4
Piston displacement [cm <sup>3</sup> ]	1248	1598	1598	1956
Engine power [kW]	66	66 / 77 <sup>1)</sup>	70 / 88 <sup>2)</sup>	99
at rpm	4000	4000	4000	3500
Torque [Nm]	200	290	290	320
at rpm	1500	1500	1500	1500
Fuel type	Diesel	Diesel	Diesel	Diesel
Oil consumption [l/1000 km]	0.6	0.6	0.6	0.6

1) Euro 5+ Low output / High output.

2) Euro 6 Low output / High output.

## Performance

The maximum speed indicated is achievable at kerb weight (without driver) plus 200 kg payload. Optional equipment could reduce the specified maximum speed of the vehicle.

Engine	1.4i	1.4Turbo	1.4CNG	1.3CDTI
Maximum speed [km/h]	161	172/167 <sup>3)</sup>	172	158/153 <sup>3)</sup>

3) H1/H2.

Engine	1.6CDTI Low output	1.6CDTI High output	2.0CDTI
Maximum speed [km/h]	158/153 <sup>4)5)</sup>	164/159 <sup>4)5)</sup>	179/174 <sup>4)</sup>
	163/158 <sup>4)6)</sup>	177/172 <sup>4)6)</sup>	
	167/162 <sup>4)7)</sup>	181/176 <sup>4)7)</sup>	

4) H1/H2.

5) Euro 5+.

6) Euro 6.

7) Euro 6 Eco-Pack.

## Vehicle weight

### Kerb weight, basic model without any optional equipment

The maximum permissible loads must not be exceeded. These weights are specified in the vehicle documents or on the identification plate ⇨ 171.

Length	Roof height	Van	Combi	Combo Tour
L1	H1	1355-1535	1485-1605	1445-1555
	H2	1365-1565	-	1505-1615
L2	H1	1395-1505	1505-1615	1600-1615
	H2	1535-1575	1715	1615-1675

Optional equipment and accessories increase the kerb weight. The EC certificate of conformity states the kerb weight for a specific vehicle.

Loading information ⇨ 63.

## Vehicle dimensions

Type	Van		Combi / Combo Tour	
	L1	L2	L1	L2
Wheelbase				
Length [mm]	4390	4740	4390	4740
Width without exterior mirrors [mm]	1850	1850	1850	1850
Width with exterior mirrors [mm]	2119	2119	2119	2119
Height [mm]; Standard roof <sup>8)</sup>	1895	1927	1895	1927
Height [mm]; High roof <sup>9)</sup>	2125	2125	2125	2125/2115 <sup>9)</sup>
Length of load compartment floor [mm]	1820	2170	1400/991 <sup>10)</sup>	1750/1341 <sup>10)</sup>
Load compartment width [mm]	1230	1230	1230/1166 <sup>11)</sup>	1230/1166 <sup>11)</sup>
Load compartment height [mm]; Standard roof	1305	1305	1305	1305
Load compartment height [mm]; High roof	1550	1550	1550	1550
Wheelbase [mm]	2755	3105	2755	3105
Turning circle kerb to kerb [m]	11.2	12.5	11.2	12.5

8) Without antenna.

9) Combi/Combo Tour.

10) With/without folded rear seats (5-seater version only).

11) Combo Tour only.

## Capacities

### Engine oil

Engine	1.4i	1.4Turbo	1.4CNG	1.3CDTI	1.6CDTI	2.0CDTI
including Filter [l]	2.7	2.9	2.9	3.2	4.9	4.9
between MIN and MAX [l]	1.0	1.0	1.0	1.0	1.0	1.0

### Fuel tank

Petrol/diesel, nominal capacity [l]	60
Natural gas CNG, nominal capacity [kg]	16.15 / 22.1 <sup>12)</sup>
Petrol, nominal capacity [l]	22

<sup>12)</sup> L1 / L2.

## Tyre pressures

Adjust tyre pressure to the value specified for full load when driving at speeds of 160 km/h.

Engine	Tyres	Comfort		With full load	
		front [kPa/bar] ([psi])	rear [kPa/bar] ([psi])	front [kPa/bar] ([psi])	rear [kPa/bar] ([psi])
All	185/65 R15 88T	250/2.5 (36)	250/2.5 (36)	290/2.9 (42)	290/2.9 (42)
	185/65 R15 92T	250/2.5 (36)	260/2.6 (38)	290/2.9 (42)	300/3.0 (44)
	195/65 R15 95T	240/2.4 (35)	240/2.4 (35)	260/2.6 (38)	270/2.7 (39)
					300/3.0 (44) <sup>13)</sup>
195/60 R16 C 99/97T	270/2.7 (39)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38) <sup>14)</sup>	
				330/3.3 (48)	
				360/3.6 (52) <sup>13)15)</sup>	
				280/2.8 (41) <sup>16)</sup>	

<sup>13)</sup> Combi.

<sup>14)</sup> Combo Tour.

<sup>15)</sup> L2 Van, all variants with CNG, and Combo Tour with 7 seats.

<sup>16)</sup> Combo Tour with 5 seats.

## Customer information

<b>Customer information</b> .....	<b>181</b>
Declaration of conformity .....	181
<b>Vehicle data recording and privacy</b> .....	<b>181</b>
Event data recorders .....	181
Radio Frequency Identification (RFID) .....	182

## Customer information

### Declaration of conformity

#### Transmission systems

This vehicle has systems that transmit and/or receive radio waves subject to Directive 1999/5/EC.

These systems are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Copies of the original Declarations of Conformity can be obtained on our website.

## Vehicle data recording and privacy

### Event data recorders

#### Data storage modules in the vehicle

A large number of electronic components of your vehicle contain data storage modules temporarily or permanently storing technical data about the condition of the vehicle, events and errors. In general, this technical information documents the condition of parts, modules, systems or the environment:

- operating conditions of system components (e.g. filling levels)
- status messages of the vehicle and its single components (e.g. number of wheel revolutions / rotational speed, deceleration, lateral acceleration)
- dysfunctions and defects in important system components

- vehicle reactions in particular driving situations (e.g. inflation of an airbag, activation of the stability regulation system)
- environmental conditions (e.g. temperature)

This data is exclusively technical and helps identifying and correcting errors as well as optimizing vehicle functions.

Motion profiles indicating travelled routes cannot be created with this data.

If services are used (e.g. repair works, service processes, warranty cases, quality assurance), employees of the service network (manufacturer included) are able to read out this technical information from the event and error data storage modules applying special diagnostic devices. If required, you will receive further information at these workshops. After an error has been corrected, the data is deleted from the error storage module or it is constantly overwritten.

When using the vehicle, situations may occur in which technical data related to other information (accident report, damages on the vehicle, witness statements etc.) may be associated with a specific person - possibly, with the assistance of an expert.

Additional functions contractually agreed upon with the client (e.g. vehicle location in emergency cases) allow the transmission of particular vehicle data from the vehicle.

## Radio Frequency Identification (RFID)

RFID technology is used in some vehicles for functions such as tyre pressure monitoring and ignition system security. It is also used in connection with conveniences such as radio remote controls for door locking/unlocking and starting, and in-vehicle transmitters for garage door openers. RFID technology in Opel vehicles does not use or record personal information or link with any other Opel system containing personal information.



# Index

## A

Accessories and vehicle modifications .....	133
Adjustable air vents .....	106
Airbag activation.....	86
Airbag and belt tensioners .....	78
Airbag deactivation .....	50, 79, 86
Airbag label.....	45
Airbag system .....	45
Air conditioning regular operation .....	107
Air conditioning system .....	103
Air intake .....	107
Air vents.....	106
Alert.....	91
Antilock brake system .....	120
Antilock brake system (ABS) .....	80
Anti-Slip Regulator (ASR).....	122
Anti-theft locking system .....	27
Anti-theft security lock.....	22
Appearance care.....	165
Armrest.....	37
Ashtrays .....	71
ASR (Anti-Slip Regulator).....	122
Audible warning chimes.....	91
Autoclose.....	86
Automatic fuel cut-off.....	92, 110
Automatic locking.....	86

## B

Battery discharge protection .....	101
Belts.....	42
Bonnet .....	135
Brake and clutch fluid.....	169
Brake assist .....	121
Brake fluid .....	138
Brake pad wear.....	80
Brakes .....	120, 138
Brake system .....	80
Breakdown.....	163
Bulb replacement .....	141

## C

Capacities .....	179
Car Pass .....	21
Catalytic converter .....	115
Central locking system .....	22
Centre high-mounted brake light	144
Change engine oil .....	83
Changing tyre and wheel size ...	154
Charging system .....	79
Child locks .....	24
Child restraint installation locations .....	53
Child restraints.....	52
Child restraint systems .....	52
Child safety system for rear windows.....	30
Chimes.....	91

Cigarette lighter .....	70
Climate control .....	16
Climate control systems.....	102
Clock.....	68, 86
CNG.....	179
Control indicators.....	74
Control of the vehicle .....	108
Controls.....	66
Convex shape .....	28
Coolant and antifreeze.....	169
Cruise control .....	85, 123
Cupholders .....	58

## D

Danger, Warnings and Cautions ...	4
Date.....	86
Daytime running lights.....	86, 96
Declaration of conformity.....	181
DIC.....	86
Diesel particle filter.....	82, 114
Distance to next service.....	86
Door locks.....	22
Door open .....	85
Doors.....	24, 26
Drain fuel filter .....	84
Driver assistance systems.....	123
Driver Information Centre.....	86
Driving characteristics and towing tips .....	131
Driving hints.....	108

## E

Eco mode (E).....	119
Electric adjustment .....	28
Electrical system.....	147
Electronic climate control system	104
Electronic driving programmes ..	119
Electronic Stability Control . .	81, 122
Electronic Stability Control (ESC).	81
End-of-life vehicle recovery .....	134
Engine compartment fuse box ...	148
Engine coolant .....	137
Engine coolant temperature .....	82
Engine coolant temperature gauge .....	73
Engine data .....	174
Engine exhaust .....	114
Engine identification.....	172
Engine oil .....	136, 169, 172, 179
Engine oil pressure .....	83
ESC (Electronic Stability Control)	122
Event data recorders.....	181
Exit lighting .....	100
Extendable load compartment cover.....	59, 63
Exterior care .....	165
Exterior light .....	85
Exterior lighting .....	13, 95
Exterior mirrors.....	28

## F

Fault .....	119
Fixed air vents .....	106
Fog light .....	85
Fog lights .....	143
Folding front passenger seat.....	36
Folding mirrors .....	29
Folding seats.....	38, 40
Front airbag system .....	49
Front fog lights .....	97
Front passenger seat Folding.....	36
Table position.....	36
Front seats.....	34
Front turn signal light.....	141
Fuel.....	126
Fuel consumption.....	86
Fuel consumption - CO <sub>2</sub> - Emissions .....	130
Fuel cut-off system.....	77, 92, 110
Fuel for diesel engines .....	127
Fuel for natural gas operation ...	127
Fuel for petrol engines .....	126
Fuel gauge .....	72
Fuel selector .....	73
Fuel system messages.....	92, 110
Fuel tank.....	179
Fuses .....	147

**G**

Gauges.....	71
General information .....	131
Generic warning.....	77, 92, 110
Glovebox .....	58
Gross Vehicle Weight.....	63

**H**

Halogen headlights .....	141
Hand brake.....	120
Hazard warning flashers .....	96
Headlamp washer.....	68
Headlight flash .....	95
Headlight range adjustment .....	96
Headlights.....	95
Headlights when driving abroad ..	96
Head restraint adjustment .....	8
Head restraints .....	33
Heated mirrors .....	29
Heated rear window .....	32
Heating .....	38
Heating and ventilation system .	102
High beam .....	85, 95
Hill start assist.....	81, 121
Horn .....	14, 66

**I**

Identification plate .....	171
Ignition switch positions .....	109
Immobiliser .....	27, 84
Indicators.....	71

Information displays.....	86
Initial drive information.....	6
Installing seats.....	40
Instrument cluster .....	71
Instrument panel fuse box .....	149
Instrument panel illumination .....	146
Instrument panel illumination control .....	98
Instrument panel overview .....	10
Instrument panel storage.....	57
Interior care .....	167
Interior lighting.....	86, 98
Interior lights .....	98, 145
Interior mirrors.....	29
Introduction .....	3
ISOFIX child restraint systems .....	56

**J**

Jump starting .....	162
---------------------	-----

**K**

Kerb weight.....	63
Key number.....	20
Keys .....	20
Keys, locks.....	20

**L**

Language.....	86
Lashing eyes .....	62, 63
Light switch .....	95
Load compartment .....	26, 59

Load compartment cover .....	59
Load compartment grille.....	62
Load compartment lighting.....	99
Loading.....	36, 38, 40
Loading information .....	63
Lock cylinders.....	20
Low engine oil level .....	84
Low fuel .....	84
Lumbar support.....	35

**M**

Malfunction indicator light .....	79
Manual adjustment .....	28
Manual anti-dazzle .....	29
Manual mode .....	118
Manual transmission .....	115
Manual transmission automated	116
Manual windows .....	30
Mirror adjustment .....	8
Misted light covers .....	98
Multifunction display.....	86

**N**

Natural gas.....	179
New vehicle running-in .....	109
Number plate light .....	144

**O**

Object detection systems.....	125
Odometer .....	71
Oil, engine.....	169, 172

Operating windows from outside ..	30
Outside temperature .....	68
Overhead console .....	58
Overrun cut-off .....	111

## P

Parking .....	19, 113
Parking assist .....	125
Parking brake .....	120
Particulate filter.....	114
Payload.....	63
Pedals.....	108
Performance .....	176
Performing work .....	135
Pollen filter .....	107
Power outlets .....	69
Power steering fluid.....	137
Power windows .....	30
Preheating .....	82
Puncture.....	158

## R

Radio Frequency Identification (RFID).....	182
Radio info.....	86
Radio remote control .....	21
Rear doors .....	24
Rear fog light .....	85
Rear fog lights .....	97
Rear parcel shelf.....	59
Rear seats.....	38

Rear storage.....	59
Rear windows .....	32
Rear window wiper/washer .....	67
Recommended fluids and lubricants .....	169, 172
Refuelling .....	128
Removing seats.....	40
Reversing lights .....	97
Ride control systems.....	122
Roof bars.....	59
Roof load.....	63
Roof rack .....	63
Roof racks.....	63

## S

Safety belts.....	42
Seat adjustment .....	7, 35
Seat belt .....	8
Seat belt reminder .....	78
Seat belt reminder warning chime	86
Seat belts .....	42
Seat folding .....	36
Seat heating.....	38
Seat position .....	34
Second row seats .....	38
Selector lever .....	117
Service .....	107, 168
Service display .....	74, 86
Service information .....	168
Settings menu.....	86

Side airbag system .....	50
Sidelights.....	95
Side turn signal lights .....	144
Sliding door .....	24
Sliding side door.....	24
Spare wheel .....	159
Speed limit warning chime.....	86
Speedometer .....	71
Standard display.....	86
Starting and operating.....	109
Starting off .....	17
Starting the engine .....	110, 116
Steering.....	108
Steering wheel adjustment .....	9, 66
Steering wheel controls .....	66
Stop engine.....	77
Stop-start system.....	85, 111
Storage.....	57
Storage compartments.....	57
Sun visors .....	32
Symbols .....	4

## T

Tachometer .....	72
Tailgate.....	26
Tail lights .....	143
Temperature.....	86
Third row seats .....	40
Three-point seat belt .....	43
Tools .....	150

Top-tether fastening eyes .....	56
Towing.....	131, 163
Towing another vehicle .....	164
Towing the vehicle .....	163
Traction Control system .....	122
Trailer coupling.....	131
Trailer towing .....	131
Transmission .....	17, 80
Transmission display .....	74, 116
Tread depth .....	154
Trip computer.....	86, 92
Trip odometer .....	71
Turn and lane-change signals .....	97
Turn signal .....	78
Tyre chains .....	155
Tyre designations .....	151
Tyre pressure .....	152
Tyre pressure monitoring system.....	83, 152
Tyre pressures .....	180
Tyre repair kit .....	155

## U

Ultrasonic parking assist .....	81, 125
Underseat storage .....	58
Unit of measurement.....	86
Upholstery.....	167
Upshift.....	81
Using this manual .....	3

## V

Vehicle battery .....	138
Vehicle checks.....	135
Vehicle data.....	172
Vehicle data recording and privacy.....	181
Vehicle dimensions .....	178
Vehicle Identification Number ....	171
Vehicle jack.....	150
Vehicle security.....	27
Vehicle shutdown.....	77, 92, 110
Vehicle specific data .....	3
Vehicle storage.....	134
Vehicle tools.....	150
Vehicle unlocking .....	6
Vehicle weight .....	177
Ventilation.....	102
Volume.....	86

## W

Warning chime.....	86
Warning chimes .....	91
Warning lights.....	71
Washer and wiper systems .....	15
Washer fluid .....	138
Wheel changing .....	158
Wheel covers .....	155
Wheels and tyres .....	151
Windows.....	30
Windscreen.....	30

Windscreen wiper/washer .....	67
Winter tyres .....	151
Wiper blade replacement .....	140

[www.opel.com](http://www.opel.com)

Copyright by ADAM OPEL AG, Rüsselsheim, Germany.

The information contained in this publication is effective as of the date indicated below. Adam Opel AG reserves the right to make changes to the technical specifications, features and design of the vehicles relative to the information in this publication as well as changes to the publication itself.

Edition: May 2015, ADAM OPEL AG, Rüsselsheim.

Printed on chlorine-free bleached paper.

**KTA-2730/4-en**

**05/2015**

