

# Contents

Introduction	2
In brief	6
Keys, doors and windows	20
Seats, restraints	45
Storage	73
Instruments and controls	88
Lighting	136
Climate control	150
Driving and operating	162
Vehicle care	239
Service and maintenance	285
Technical data	289
Customer information	310
Index	322

# Introduction

Fuel	Designation			
Engine oil	Grade			
	Viscosity			
Tyre pressure		Tyre size	Front	Rear
	Summer tyres			
	Winter tyres			
Weights				
	Gross vehicle weight rating			
	- Kerb weight, basic model			
	= Loading			

### Vehicle specific data

Please enter your vehicle's data on the previous page to keep it easily accessible. This information is available in the sections "Service and maintenance" and "Technical data" as well as on the identification plate.

#### Introduction

Your vehicle is a designed combination of advanced technology, safety, environmental friendliness and economy.

This Owner's Manual provides you with all the necessary information to enable you to drive your vehicle safely and efficiently.

Make sure your passengers are aware of the possible risk of accident and injury which may result from improper use of the vehicle.

You must always comply with the specific laws and regulations of the country that you are in. These laws may differ from the information in this Owner's Manual.

Disregarding the description given in this manual may affect your warranty.

When this Owner's Manual refers to a workshop visit, we recommend your Opel Service Partner. For gas vehicles, we recommend an Opel Repairer authorised for servicing gas vehicles.

All Opel Service Partners provide first-class service at reasonable prices. Experienced mechanics trained by Opel work according to specific Opel instructions.

The customer literature pack should always be kept ready to hand in the vehicle.

# Using this manual

- This manual describes all options and features available for this model. Certain descriptions, including those for display and menu functions, may not apply to your vehicle due to model variant, country specifications, special equipment or accessories.
- The "In brief" section will give you an initial overview.

- The table of contents at the beginning of this manual and within each section shows where the information is located.
- The index will enable you to search for specific information.
- This Owner's Manual depicts lefthand drive vehicles. Operation is similar for right-hand drive vehicles.
- The Owner's Manual uses the engine identifier code. The corresponding sales designation and engineering code can be found in the section "Technical data".
- Directional data, e.g. left or right, or front or back, always relate to the direction of travel.
- Displays may not support your specific language.
- Display messages and interior labelling are written in **bold** letters.

# Danger, Warnings and Cautions

### ⚠Danger

Text marked  $\triangle$  **Danger** provides information on risk of fatal injury. Disregarding this information may endanger life.

# **△**Warning

Text marked **AWarning** provides information on risk of accident or injury. Disregarding this information may lead to injury.

#### Caution

Text marked **Caution** provides information on possible damage to the vehicle. Disregarding this information may lead to vehicle damage.

# **Symbols**

Page references are indicated with ⋄. 
⋄ means "see page".

Chronological order to select menu entries in the vehicle personalisation is indicated with •.

Page references and index entries refer to the indented headings given in the section table of content.

We wish you many hours of pleasurable driving.

## Your Opel Team

# In brief

# Initial drive information

# Vehicle unlocking



Press to unlock the doors and load compartment. Open the doors by pulling the handles. To open the tailgate, push the brand emblem and open the tailgate.

# Seat adjustment

# Longitudinal adjustment



Pull handle, slide seat, release handle. Try to move the seat back and forth to ensure that the seat is locked in place.

Seat position ❖ 47, Manual seat adjustment ❖ 48, Power seat adjustment ❖ 50.

#### **Backrest inclination**



Turn handwheel. Do not lean on backrest when adjusting. 

adjustment \$ 50.

# Seat height



Lever pumping motion

: seat higher down: seat lower

adjustment \$ 50.

#### Seat inclination



Press switch

top : front end higher bottom: front end lower

adjustment \$ 50.

# Head restraint adjustment



Press release button, adjust height, engage.

Head restraints \$ 45.

# Seat belt



Pull out the seat belt and fasten in belt buckle. The seat belt must not be twisted and must fit close against the body. The backrest must not be tilted back too far (maximum approx. 25°).

To unfasten belt, press red button on belt buckle.

Seat position \$\phi\$ 47, Seat belts \$\phi\$ 56, Airbag system \$\phi\$ 58.

# Mirror adjustment

#### Interior mirror



To adjust the mirror, move the mirror housing in the desired direction.

#### **Exterior mirrors**



Select the relevant exterior mirror by pushing left or right mirror button. LED in button indicates the selection.

Then swivel the control to adjust the mirror.


Convex exterior mirrors ▷ 37, Electric adjustment ▷ 37, Folding exterior mirrors ▷ 37, Heated exterior mirrors ▷ 38.

# Steering wheel adjustment



Unlock lever, adjust steering wheel, then engage lever and ensure it is fully locked. Do not adjust steering wheel unless vehicle is stationary and steering wheel lock has been released.


# Instrument panel overview



1	Power windows 40
2	Exterior mirrors 37
3	Central locking system 25
4	Side air vents 159
5	Cruise control189
	Speed limiter 190
	Adaptive cruise control 192
	Forward collision alert 200
6	Turn and lane-change signals, headlight flash, low/high beam, high beam
	assist 143
	Exit lighting147
	Parking lights 144
	Buttons for Driver
_	Information Centre
7	Instruments 103
	Driver Information Centre 114
8	Buttons for Driver Information Centre 114
9	
9	Head-up display 122

10	Windscreen wiper and washer, headlight washer,
	rear wiper and washer 90
11	Centre air vents 159
12	Hazard warning flashers 143
13	Info-Display121
14	Anti-theft alarm system status LED34
15	Electronic Stability Control . 185
	Traction Control system 184
16	Glovebox73
17	Controls for Info-Display operation 121
18	Climate control system 150
19	Power outlet95
20	Sport/Tour mode 186
	Parking assist/Advanced parking assist
	Lane keep assist229
21	Eco button for stop-start system
	Automatic transmission 175

22	Electric parking brake 181
23	Power switch 164
24	Steering wheel adjustment89
25	Horn90
26	Bonnet release lever 241
27	Fuse box261
28	Light switch136
	Headlight range
	adjustment
	Front/rear fog lights144
	Instrument illumination 145
29	Head-up display 122



# **Exterior lighting**

### Automatic light control



**AUTO**: automatic light control

switches automatically between daytime running

light and headlight

⇒ ≤ : sidelights≦D : headlights

Automatic light control \$\Display\$ 137.

# Fog lights

∮D : front fog lights

O∮ : rear fog light

# Headlight flash, high beam and low beam



headlight flash: pull lever high beam: push lever

low beam : push or pull lever

High beam ⊅ 137.

Headlight flash ♦ 139.

High beam assist ♦ 140.

### Turn and lane-change signals



lever up : right turn signal lever down : left turn signal

# Hazard warning flashers




# Horn



Press 🗠.

# Washer and wiper systems Windscreen wiper



HI : fast LO : slow

INT : interval wiping or automatic

wiping with rain sensor

OFF : off

For a single wipe when the windscreen wiper is off, press the lever down to position 1x.

Windscreen wiper ♥ 90, Wiper blade replacement ♥ 246.

#### Windscreen washer



Pull lever.

Windscreen and headlight washer system ♀ 90, Washer fluid ♀ 244.

### Rear window wiper



Turn outer cap to activate the rear window wiper:

OFF: off

INT : intermittent operationON : continuous operation

#### Rear window washer



Push lever.

Washer fluid is sprayed on the rear window and the wiper wipes a few times.

umes.

Rear window wiper/washer ♀ 92.

#### Climate control

#### Heated rear window



Heating is operated by pressing  $\blacksquare$ . Heated rear window  $\diamondsuit$  42.

#### Heated windscreen



Heating is operated by pressing #. Heated windscreen  $\diamondsuit$  42.

#### Heated exterior mirrors

Pressing also activates the heated exterior mirrors.

Heated exterior mirrors \$\infty\$ 38.

# Demisting and defrosting the windows, air conditioning system



- Press : fan automatically switches to higher speed, the air distribution is directed towards the windscreen.
- Set temperature control to warmest level.
- Switch on air conditioning A/C if required.
- Open side air vents as required and direct them towards the door windows.

Air conditioning system \$\triangle\$ 150.

# Demisting and defrosting the windows, electronic climate control



- Press 

  . Temperature and air distribution are set automatically and the fan runs at high speed.
- Switch on air conditioning A/C ON in Climate setting menu by pressing CLIMATE, if required.
- Switch on heated rear window .....

#### **Transmission**

#### Manual transmission



Reverse: with the vehicle stationary, depress clutch pedal, press the release button on the selector lever and engage the gear.

#### **Automatic transmission**



P: park positionR: reverseN: neutral modeD: automatic mode

M : manual mode+ : upshift

- : downshift

The selector lever can only be moved out of P when the ignition is on and the brake pedal is applied. To engage P or R, press the release button.

# Starting off

#### Check before starting off

- Tyre pressure and condition
   ⇒ 264, ⇒ 304.
- Engine oil level and fluid levels

   ⇒ 242.
- All windows, mirrors, exterior lighting and number plates are free from dirt, snow and ice and are operational.
- Brake function at low speed, particularly if the brakes are wet.

#### Starting the engine



- Manual transmission: operate clutch and brake pedal.
- Automatic transmission: operate brake pedal and move selector lever to P or N.
- Do not operate accelerator pedal.
- Press Engine Start/Stop button.
- Release button after starting procedure begins.

#### Stop-start system



If the vehicle is at a low speed or at a standstill and certain conditions are fulfilled, an Autostop is activated.

An Autostop is indicated by the needle at the **AUTOSTOP** position in the tachometer.

A restart is indicated by the needle at the idle speed position in the tachometer.

# **Parking**

### **△**Warning

- Do not park the vehicle on an easily ignitable surface. The high temperature of the exhaust system could ignite the surface.
- Always apply the parking brake. Pull switch (P) for approx. one second and check if the control indicator (P) illuminates.
  - The electric parking brake is applied when control indicator 

    ⊚ illuminates 

    109.
- Switch off the engine.
- If the vehicle is on a level surface or uphill slope, engage first gear or set the selector lever to position P before switching off ignition. On an uphill slope, turn the front wheels away from the kerb.
   If the vehicle is on a downhill slope, engage reverse gear or

set the selector lever to position **P** before switching off ignition. Turn the front wheels towards the kerb.

- Close the windows and the sunroof.
- Switch off ignition with power button. Turn the steering wheel until the steering wheel lock is felt to engage.
- Lock the vehicle by pressing the button on the door handle.
   Activate the anti-theft alarm system \$\phi\$ 34.

#### Caution

After running at high engine speeds or with high engine loads, operate the engine briefly at a low load or run in neutral for approx. 30 seconds before switching off, in order to protect the turbocharger.

Electronic key system ♦ 22, Laying the vehicle up for a long period of time ♦ 240.

# Keys, doors and windows

Keys, locks	20
Keys	20
Radio remote control	
Electronic key system	22
Memorised settings	25
Central locking system	25
Automatic locking	27
Child locks	28
Doors	28
Load compartment	28
Vehicle security	34
Anti-theft locking system	
Anti-theft alarm system	
Immobiliser	36
Exterior mirrors	37
Convex shape	37
Electric adjustment	37
Folding mirrors	37
Heated mirrors	38
Automatic dimming	38
Parking assist	39

Interior mirrors	. 39
Manual anti-dazzle	39
Automatic anti-dazzle	39
Windows	40
Windscreen	40
Power windows	40
Heated rear window	42
Heated windscreen	42
Sun visors	42
Roof	43
Sunroof	

# Keys, locks

# Keys

### Replacement keys

The key number is specified on a detachable tag.

The key number must be quoted when ordering replacement keys as it is a component of the immobiliser system.

Locks  $\diamondsuit$  281, Central locking  $\diamondsuit$  25, Starting the engine  $\diamondsuit$  165.

Radio remote control \$ 21.

Electronic key \$ 22.

The code number of the adapter for the locking wheel nuts is specified on a card. It must be quoted when ordering a replacement adapter.

# Replacing battery

Replace the battery as soon as the system no longer operates properly or the range is reduced. The need for

battery replacement is indicated by a message in the Driver Information Centre ₱ 125.



Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.

To replace:



 Press button at the back of the electronic key unit and extract the key blade from the housing.



- Insert the key blade again for approx. 6 mm and turn the key to open the housing. Further insertion of the key blade can damage the housing.
- Remove and replace battery. Use CR 2032 or equivalent battery. Pay attention to the installation position.
- 4. Close the housing and insert key blade.

#### Radio remote control



Enables operation of the following functions via the use of the remote control buttons:

- power windows ⇒ 40

The remote control has a range of up to 100 metres, but may also be much less due to external influences. The hazard warning flashers confirm operation.

Handle with care, protect from moisture and high temperatures and avoid unnecessary operation.

#### **Fault**

If the central locking system cannot be operated with the radio remote control, the cause may be one of the following:

- Fault in radio remote control.
- The range is exceeded.
- The battery voltage is too low.
- Frequent, repeated operation of the radio remote control while not in range, which will require resynchronisation.
- Overload of the central locking system by operating at frequent intervals, the power supply is interrupted for a short time.
- Interference from higher-power radio waves from other sources.

# Electronic key system



Enables a keyless operation of the following functions:

The electronic key simply needs to be on the driver's person.

Additionally, the electronic key includes the functionality of the radio remote control:

- central locking system
- anti-theft alarm system
- power windows

The hazard warning flashers confirm operation.

Handle the device with care, protect from moisture and high temperatures and avoid unnecessary operation.

#### Note

Do not put the electronic key in the load compartment.

#### Electronic key system operation



The electronic key must be outside the vehicle, within a range of approx. one metre of the relevant door side.

#### Unlocking



Press the button on the respective exterior door handle and pull the handle.

Unlocking mode can be set in the vehicle personalisation menu in the Info Display. Two settings are selectable:

- All doors, load compartment and fuel filler flap will be unlocked by pressing the button on any exterior handle once.
- Only the driver's door and fuel filler flap will be unlocked by pressing the button on the driver's door exterior handle

once. To unlock all doors and load compartment, press button twice.

The setting can be changed in the menu **Settings** in the Info Display. Vehicle personalisation ♀ 127.

#### Locking



Press the button on any exterior door handle.

All doors, load compartment and fuel filler flap will be locked.

The system locks if any of the following occurs:

- It has been more than five seconds since unlocking.
- The button on an exterior handle has been pressed twice within five seconds to unlock the vehicle.
- Any door has been opened and all doors are now closed.

If the driver's door is not closed properly, the electronic key remains in the vehicle or the ignition is not off, locking will not be permitted.

If there have been two or more electronic keys in the vehicle and the ignition was on once, the doors will be locked even if just one electronic key is taken out of the vehicle.

#### Unlocking and opening the tailgate

The tailgate can be unlocked and opened handsfree via moving the foot below the rear bumper or by pushing the touchpad switch under the brand emblem when the electronic key is in range. The doors remain locked. Load compartment ♀ 28.

# Operation with buttons on the electronic key



The central locking system can also be operated with the buttons on the electronic key.

Unlocking Press . Unlocking mode can be set in the vehicle personalisation menu in the Info Display. Two settings are selectable:

- All doors, load compartment and fuel filler flap will be unlocked by pressing once.
- Only the driver's door and fuel filler flap will be unlocked by pressing donce. To unlock all doors and load compartment, press dtwice.

Select the relevant setting in **Settings**, **Vehicle** in the Info Display.

#### Locking

Close doors, load compartment and fuel filler flap.

Press 0.

If the driver's door is not closed properly, the central locking system will not work.

#### Passive locking

#### Confirmation

Operation of central locking system is confirmed by the hazard warning flashers. A precondition is that the setting is activated in the vehicle personalisation  $\diamondsuit$  127.

#### Fault

If the central locking cannot be operated or the engine cannot be started, the cause may be one of the following:

- Fault in electronic key.
- Electronic key is out of reception range.
- The battery voltage is too low.
- Overload of the central locking system by operating at frequent intervals, the power supply is interrupted for a short time.
- Interference from higher-power radio waves from other sources.

To rectify the cause of the fault, change the position of the electronic key.

# Memorised settings

Whenever the ignition is switched off, the following settings are automatically memorised by the electronic key:

- · automatic climate control
- lighting
- Infotainment system
- central locking system
- Sport mode settings
- comfort settings

The saved settings are automatically used the next time the ignition is switched on with the memorised electronic key ♀ 22.

A precondition is that **Personalisation** by **Driver** is activated in the personal settings of the Info-Display. This must be set for each electronic key which is used. The status change is available only after locking and unlocking the vehicle.

The assigned memory position of the power seat is automatically recalled when switching on ignition and **Auto** 

Memory Recall is activated in the Info-Display for the memorised electronic key.

Power seat \$ 50.

# Central locking system

Unlocks and locks doors, load compartment and fuel filler flap.

A pull on an interior door handle unlocks the respective door. Pulling the handle once more opens the door.

#### Note

In the event of an accident in which airbags or belt pretensioners are deployed, the vehicle is automatically unlocked.

#### Note

A short time after unlocking with the electronic key, the doors are being locked automatically if no door has been opened. A precondition is that the setting is activated in the vehicle personalisation  $\Rightarrow$  127.

#### Central locking buttons

Locks or unlocks all doors, the load compartment and fuel filler flap from the passenger compartment via a switch in the driver's door panel.



Press to lock. LED in button illuminates.

Press of to unlock.

# Operation with the key in case of a central locking system fault

In case of a fault, e.g. vehicle battery or electronic key battery is discharged, the driver's door can be locked or unlocked with the key blade.



Push the button on the electronic key and pull out the key blade.

The lock cylinder in the driver's door is covered by a cap.



Insert the key blade into the recess at the bottom of the cap and swivel the key upward.

#### Manual unlocking



Manually unlock the driver's door by inserting and turning the key blade in the lock cylinder.

The other doors can be opened by pulling the interior handle twice or by pressing  $\widehat{\mathbb{G}}$  in the driver's door panel. The load compartment and fuel filler flap will possibly not be unlocked.

By switching on the ignition, the antitheft locking system is deactivated.

### Manual locking



Push inside locking knob of all doors except driver's door or press  $\ensuremath{\overline{\oplus}}$  in the driver's door panel. Then close the driver's door and lock it from the outside by turning the key in the lock cylinder. The fuel filler flap and tailgate are possibly not locked.



After locking, cover the lock cylinder with the cap: insert the cap with the lower side in the recesses, swivel and push the cap until it engages at the upper side.

# **Automatic locking**

### Automatic locking after driving off

This security feature can be configured to automatically lock all doors, load compartment and fuel filler flap after driving off and exceeding a certain speed.

When at a standstill after driving, the vehicle will be unlocked automatically as soon as the ignition is switched off.

Activation or deactivation of automatic locking can be set in the menu **Settings**, **Vehicle** in the Info-Display.

### Automatic relock after unlocking

This feature can be configured to automatically lock all doors, load compartment and fuel filler flap a short time after unlocking with the electronic key, provided no door has been opened.

Activation or deactivation of automatic relock can be set in the menu **Settings**, **▶ Vehicle** in the Info-Display.

The setting can be saved for each electronic key being used ♦ 25.

#### Passive locking

This feature locks the vehicle automatically after several seconds if an electronic key has been recognised previously inside the vehicle, all doors have then been closed and the electronic key does not remain within the vehicle.

If the electronic key remains in the vehicle or the ignition is not off, passive locking will not be permitted.

If there have been two or more electronic keys in the vehicle and the ignition was on once, the feature locks the vehicle if just one electronic key is taken out of the vehicle.

To prevent passive locking of the vehicle e.g. when refuelling or if passengers remain in the vehicle, the system must be disabled.

To disable the system, press the central locking button  $\widehat{\ \ }$  for a few seconds while one door is open. An acoustic signal sounds three times to confirm deactivation. The function remains disabled until the central locking button  $\widehat{\ \ }$  is pressed or the ignition is switched on.

Activation or deactivation of passive locking can be set in the menu **Settings, ♦ Vehicle** in the Info-Display. Info-Display ♀ 121.

### Child locks



# **△**Warning

Use the child locks whenever children are occupying the rear seats.

Move the pin in the rear door to the front position. The door cannot be opened from the inside.

To deactivate, move the pin to the rear position.

# **Doors**

# Load compartment

**Tailgate** 

Opening Grand Sport



After unlocking, push the brand emblem and open the tailgate.

#### Sports Tourer, Country Tourer



After unlocking, push the touchpad switch under the tailgate moulding and open the tailgate.

Central locking system \$ 25.

#### Closing



### Power tailgate

# **△**Warning

Take care when operating the power tailgate. Risk of injury, particularly to children.

Keep a close watch on the movable tailgate when operating. Ensure that nothing becomes

trapped during operating and no one is standing within the moving area.

The power tailgate can be operated by:

- The electronic key.
- Handsfree operation with motion sensor below the rear bumper.
- The touchpad switch under the exterior tailgate moulding and in the open tailgate.
- The switch on the inside of the driver's door.

On vehicles with automatic transmission, the tailgate can only be operated when the vehicle is stationary and with selector lever in **P**.

The turn signal lights flash and a chime sounds when the power tailgate is operating.

#### Note

Operating the power tailgate does not operate the central locking system. To open the tailgate with the button on the electronic key, or with the touchpad switch under the tailgate moulding or via handsfree operation, it is not necessary to unlock the vehicle. A precondition is that the electronic key is outside the vehicle, within a range of approx. one metre of the tailgate.

Do not leave the electronic key in the load compartment.

Lock the vehicle after closing if it was unlocked previously.

#### Operation with the electronic key



Press 

twice to open or close the tailgate. To prevent unintended opening of the tailgate, 

must be pressed longer than during locking or unlocking.

# Handsfree operation with motion sensor below the rear bumper



To open or close the tailgate, move the foot in the center area below the rear bumper back and forth quickly. Do not hold the foot under the bumper. Depending on light conditions, the area is indicated by a symbol projected on the ground. The electronic key must be outside the vehicle, within a range of approx.

one metre of the tailgate. When foot motion is being detected by the sensor, the system actuates the tailgate after a short delay.

# ⚠Danger

Do not touch any vehicle parts below the vehicle during handsfree operation. There is a risk of injury from hot engine parts.

# Operation with the touchpad switch under the exterior tailgate moulding



To open the tailgate, press the touchpad switch under the tailgate moulding until the tailgate starts to

move. If the vehicle is locked, the electronic key must be outside the vehicle, within a range of approx. one metre of the tailgate.



To close, press in the open tailgate until the tailgate starts to move.

# Operation with the switch on the inside of the driver's door



Press on the inside of the driver's door until the tailgate starts to open or close.

# Stop or change direction of movement

To stop movement of the tailgate immediately:

- press 🔊 once on the electronic key, or
- press the touchpad switch under the exterior tailgate moulding, or

- press on the open tailgate, or
- press on the inside of the driver's door.

Pressing one of the switches again will reverse the direction of movement.

#### Operation modes

The power tailgate has three modes of operation, which are controlled by the switch — in the driver's door. To change the mode, turn the switch:



- Normal mode MAX: Power tailgate opens to full height.
- Intermediate mode 3/4: Power tailgate opens to a reduced height that can be adjusted.
- Mode Off: Tailgate can only be operated manually.

# Adjust reduced opening height in intermediate mode

- 1. Turn operation mode switch to 3/4.
- 2. Open power tailgate with any operation switch.

Stop movement at the desired height by pressing any operation switch. If required, manually move the stopped tailgate to the desired position.



 Press and hold the button on the inside of the open tailgate for three seconds.

#### Note

Adjusting opening height should be programmed at ground level.

A chime sound indicates the new setting and the turn signal lights will flash. The reduced height can only set at an opening angle of above 30°.

When turning the adjuster wheel in the driver's door to intermediate mode 3/4, the power tailgate will stop opening at the newly set position.

The tailgate can only be held open if a minimum height is exceeded (minimum opening angle from 30°). The opening height cannot be programmed below that height.

#### Safety function

If the power tailgate encounters an obstacle during opening or closing, the direction of movement will automatically be reversed slightly. Multiple obstacles in one power cycle will deactivate the function. In this case, close or open the tailgate manually.

The power tailgate has pinch sensors on the side edges. If the sensors detect obstacles between tailgate and chassis, the tailgate will open, until it is activated again or closed manually.

The safety function is indicated by a warning chime.

Remove all obstacles before resuming normal power operation.

If the vehicle is equipped with factoryfitted towing equipment and a trailer is electrically connected, the power tailgate can only be operated manually. Press the touchpad to release the tailgate from its lock, open and close it by hand. Ensure that there are no obstacles in the moving area.

#### Overload

If the power tailgate is repeatedly operated at short intervals, the function is disabled for some time. Move tailgate manually into end position to reset the system.

# General hints for operating tailgate

# **△** Danger

Do not drive with the tailgate open or ajar, e.g. when transporting bulky objects, since toxic exhaust gases, which cannot be seen or smelled, could enter the vehicle. This can cause unconsciousness and even death.

#### Caution

Before opening the tailgate, check overhead obstructions, e.g. a garage door, to avoid damage to the tailgate. Always check the moving area above and behind the tailgate.

#### Note

The installation of certain heavy accessories onto the tailgate may affect its ability to remain open.

#### Note

The operation of the power tailgate is disabled under low vehicle battery conditions. In this case, the tailgate may not even be manually operable.

#### Note

With the power tailgate disabled and all doors unlocked, the tailgate can only be operated manually. In this event, manually closing the tailgate requires significantly greater force.

#### Note

At low outside temperatures the tailgate may not open fully by itself. In this event, lift the tailgate manually to its normal end position.

# Vehicle security Anti-theft locking system

# **△**Warning

Do not use the system if there are people in the vehicle! The doors cannot be unlocked from the inside.

The system deadlocks all the doors. All doors must be closed otherwise the system cannot be activated.

Unlocking the vehicle disables the mechanical anti-theft locking system. This is not possible with the central locking button.

### Activating



Press 🕏 on the electronic key twice within five seconds.

# Anti-theft alarm system

The anti-theft alarm system is combined with the anti-theft locking system.

#### It monitors:

- doors, tailgate, bonnet
- passenger compartment including adjoining load compartment

- vehicle inclination, e.g. if it is raised
- ignition

#### Activation

All doors must be closed and the electronic key of the electronic key system must not remain in the vehicle. Otherwise the system cannot be activated.

 self-activated 30 seconds after locking the vehicle by pressing the button on any exterior door handle.



- directly by pressing twice within five seconds.
- with passive locking enabled: briefly activated after passive locking occurs.

#### Note

Changes to the vehicle interior such as the use of seat covers, and open windows or sunroof, could impair the function of passenger compartment monitoring.

### Activation without monitoring of passenger compartment and vehicle inclination



Switch off the monitoring of passenger compartment and vehicle inclination when animals are being left in the vehicle, because of high volume ultrasonic signals or movements triggering the alarm. Also switch off when the vehicle is on a ferry or train.

- 1. Close tailgate, bonnet, windows and sunroof
- 2. Press 🖎 I FD in the button 🕸 illuminates for a maximum of ten minutes.
- 3. Close doors.
- 4. Activate the anti-theft alarm system.

Status message is displayed in the Driver Information Centre.

#### Status LED



Status LED is integrated in the sensor on top of the instrument panel.

Status during the first 30 seconds of anti-theft alarm system activation:

LED illuminates: test, arming delay I FD flashes quickly

: doors, tailgate or bonnet not

completely closed.

or system fault

Status after system is armed:

LED flashes : system is armed slowly

Seek the assistance of a workshop in the event of faults.

#### Deactivation



Unlocking the vehicle by pressing the button on any exterior door handle deactivates the anti-theft alarm system.

The electronic key must be outside the vehicle, within a range of approx. one metre of the relevant door side.

The system is not deactivated by unlocking the driver's door with the key or with the central locking button in the passenger compartment.

#### Alarm

When triggered, the alarm horn sounds and the hazard warning lights flash simultaneously. The number and duration of alarm signals are stipulated by legislation.

The anti-theft alarm system can be deactivated by pressing  $\widehat{\mathbb{d}}$ , by pressing the switch on the door handle with electronic key system or switching on the ignition.

A triggered alarm, which has not been interrupted by the driver, will be indicated by the hazard warning lights. They will flash quickly three times the next time the vehicle is unlocked with the electronic key. Additionally, a warning message is displayed in the Driver Information Centre after switching on the ignition. Vehicle messages \$\Display\$ 125.

If the vehicle's battery is to be disconnected (e.g. for maintenance work), the alarm siren must be deactivated as follows: switch the ignition on then off, then disconnect the vehicle's battery within 15 seconds.

#### **Immobiliser**

The immobiliser is activated automatically.

If the control indicator வ flashes when the ignition is on, there is a fault in the system; the engine cannot be started. Switch off the ignition and repeat the start attempt. Retry with the key in the transmitter pocket. Operation on vehicles with electronic key system in case of failure ▷ 164.

If the control indicator a continues flashing, attempt to start the engine using the spare key.

Seek the assistance of a workshop.

#### Note

Radio Frequency Identification (RFID) tags may cause interference with the key. Do not have it placed near the key when starting the vehicle.

#### Note

The immobiliser does not lock the doors. You should always lock the vehicle after leaving it and switch on the anti-theft alarm system \$\dip\$ 25, \$\dip\$ 34.

## **Exterior mirrors**

## Convex shape

The shape of the mirror makes objects appear smaller, which will affect the ability to estimate distances.

Side blind spot alert \$\times\$ 215.

## Electric adjustment



Select the relevant exterior mirror by pushing  $\square_i$  for left mirror or  $\square$  for right mirror. LED in button indicates the selection.

Then swivel the control to adjust the mirror.

## **Folding mirrors**



For pedestrian safety, the exterior mirrors will swing out of their normal mounting position if they are struck with sufficient force. Reposition the mirror by applying slight pressure to the mirror housing.

#### Electric folding



Push **□**. Both exterior mirrors will fold.

Push ■ again to return both exterior mirrors to their original position.

If an electrically folded mirror is manually extended, pushing a will only electrically extend the other mirror.

## Folding mirrors with electronic key



Press again after locking for one second to fold in mirrors.

Press again after unlocking for one second to fold out mirrors.

This function can be activated or deactivated in the Vehicle personalisation.

The settings are automatically stored for the key being used  $\diamondsuit$  25.

## **Heated mirrors**



Operated by pressing a together with heated rear window. LED in button illuminates.

Heating works with the engine running and is switched off automatically after a short time.

## Automatic dimming

Dazzling by following vehicles at night is automatically reduced by dimming the exterior mirror on the driver's side.

## Parking assist

For mirrors with position memory, the exterior mirrors are automatically aimed at the rear tyres as a parking aid when reverse gear is selected, except during trailer operation.

Position memory \$\dip\$ 50.

Activation or deactivation of this function can be changed in vehicle personalisation.

# Interior mirrors Manual anti-dazzle



To reduce dazzle, adjust the lever on the underside of the mirror housing.

## Automatic anti-dazzle



Dazzle from following vehicles at night is automatically reduced.

## Windows

#### Windscreen

#### Windscreen stickers

Do not attach stickers such as toll road stickers or similar on the windscreen in the area of the interior mirror. Otherwise the detection zone of the sensor and the view area of the camera in the mirror housing could be restricted.

## Windscreen replacement

#### Caution

If the vehicle has a front-looking camera sensor for the driver assistance systems, it is very important that any windscreen replacement is performed accurately according to Opel specifications. Otherwise, these systems may not work properly and there is a risk of unexpected behaviour and/or messages from these systems.

#### Caution

If the vehicle is equipped with a Head-up display, it is very important that any windscreen replacement is performed accurately according to Opel specifications. Otherwise, the system may not work properly and the image may look out of focus.

#### Power windows

## **△**Warning

Take care when operating the power windows. Risk of injury, particularly to children.

If there are children on the rear seats, switch on the child safety system for the power windows.

Keep a close watch on the windows when closing them. Ensure that nothing becomes trapped in them as they move.

Switch on ignition to operate power windows. Retained power off ▷ 165.



Operate And for the respective window by pushing to open or pulling to close.

Pushing or pulling gently to the first detent: window moves up or down as long as the switch is operated.

Pushing or pulling firmly to the second detent then releasing: window moves up or down automatically with safety function enabled. To stop movement, operate the switch once more in the same direction.

#### Safety function

If the window glass encounters resistance above the middle of the window during automatic closing, it is immediately stopped and opened again.

## Override safety function

In the event of closing difficulties due to frost or the like, switch on the ignition, then pull the switch to the first detent and hold. The window moves up without safety function enabled. To stop movement, release the switch.


## Child safety system for rear windows



Press to deactivate rear door power windows; the LED illuminates. To activate, press again.

#### Operating windows from outside

The windows can be operated remotely from outside the vehicle.



Press and hold for more than two seconds to open windows.

Press and hold for more than two seconds to close windows.

Release button to stop window movement.

If the windows are fully opened or closed, the hazard warning lights will flash twice.

#### Overload

If the windows are repeatedly operated within short intervals, the window operation is disabled for some time.

#### Initialising the power windows

If the windows cannot be closed automatically (e.g. after disconnecting the vehicle battery), a warning message is displayed in the Driver Information Centre.

Activate the window electronics as follows:

- 1. Close doors.
- 2. Switch on ignition.
- Pull the switch until the window is closed and keep pulling for additional two seconds.
- Push the switch until the window is completely open and keep pushing for additional two seconds.
- 5. Repeat for each window.

## Heated rear window



Operated by pressing a together with heated exterior mirrors. LED in button illuminates.

Heating works with the engine running and is switched off automatically after a short time.

#### Heated windscreen



Operated by pressing . LED in button illuminates.

Heating works with the engine running and is switched off automatically after a short time.

Pressing @ once more during the same ignition cycle allows the heating to operate for another three minutes.

#### Sun visors

The sun visors can be folded down or swivelled to the side to prevent dazzling.

The covers of the mirrors should be closed when driving.

A ticket holder is located on the backside of the sun visor.

## Roof

#### Sunroof

## **△**Warning

Take care when operating the sunroof. Risk of injury, particularly to children.

Keep a close watch on the movable parts when operating them. Ensure that nothing becomes trapped in them as they move.

Switch on ignition to operate the sunroof.



#### Open or close

Press or or gently to the first detent: sunroof is opened or closed as long as the switch is operated.

Press or firmly to the second detent then release: the sunroof is opened or closed automatically. During closing the safety function is enabled. To stop movement, operate the switch once more.

#### Raise or close

Press ⊕ or ←: sunroof is raised or closed automatically. During closing the safety function is enabled.

#### Sunblind

The sunblind is manually operated. Close or open the sunblind by sliding. When the sunroof is open, the sunblind is always open.

#### **General hints**

## Safety function

If the sunroof encounters resistance during automatic closing, it is immediately stopped and opened again.

#### Override safety function

In the event of closing difficulties, e.g. due to frost, hold the switch pressed to the second detent. The sunroof closes with safety function disabled. To stop movement, release the switch.

## Closing sunroof from outside

The sunroof can be closed remotely from outside the vehicle.



Press and hold  $\widehat{\,}^{}_{}$  for more than two seconds to close the sunroof. Release the button to stop the movement.

#### Initialising after a power failure

After a power failure, it may only be possible to operate the sunroof to a limited extent. Have the system initialised by your workshop.

## Seats, restraints

Head restraints	45
Front seats	47
Seat position	
Manual seat adjustment	
Power seat adjustment	
Armrest	
Heating	
Ventilating	
Massage	
Rear seats	
Armrest	
Heating	
Seat belts	
Three-point seat belt	57
Airbag system	58
Front airbag system	
Side airbag system	
Curtain airbag system	
Airbag deactivation	
Child restraints	
Child restraint systems	64
Child restraint installation	
locations	67


Pedestrian protection system	7
Active bonnet	71

## Head restraints

#### **Position**

## **△Warning**

Only drive with the head restraint set to the proper position.



The upper edge of the head restraint should be at upper head level. If this is not possible for extremely tall people, set to highest position, and set to lowest position for small people.

# Adjustment Head restraints on front seats Height adjustment



Press release button, adjust height, engage.

## Horizontal adjustment



Press release button, pull bolster of head restraint forwards slowly. It engages in several positions.

#### Head restraints on rear seats



## Height adjustment

Pull the head restraint upwards or press the catch to release and push the head restraint downwards.

## Removal of rear head restraints



Press both catches, pull the head restraint upwards and remove.

## Front seats

## Seat position

## **△**Warning

Only drive with the seat correctly adjusted.

## **⚠** Danger

Do not sit closer than 25 cm to the steering wheel, to permit safe airbag deployment.

## **△**Warning

Never adjust seats while driving as they could move uncontrollably.

## **△**Warning

Never store any objects under the seats.



- Sit with buttocks as far back against the backrest as possible. Adjust the distance between the seat and the pedals so that legs are slightly angled when fully pressing the pedals. Slide the front passenger seat as far back as possible.
- Set seat height high enough to have a clear field of vision on all sides and of all display instruments. There should be at least one hand of clearance between head and the roof frame. Your thighs should rest lightly on the seat without pressing into it.

- Sit with shoulders as far back against the backrest as possible. Set the backrest rake so that it is possible to easily reach the steering wheel with arms slightly bent. Maintain contact between shoulders and the backrest when turning the steering wheel. Do not angle the backrest too far back. We recommend a maximum rake of approx. 25°.
- Adjust seat and steering wheel in a way that the wrist rests on top of the steering wheel while the arm is fully extended and shoulders on the backrest.

- Adjust the thigh support so that there is a space approx. two fingers wide between the edge of the seat and the hollow of the knee.
- Adjust the lumbar support so that it supports the natural shape of the spine.

## Manual seat adjustment

Drive only with engaged seats and backrests.

## Longitudinal adjustment




Pull handle, slide seat, release handle. Try to move the seat back and forth to ensure that the seat is locked in place.

#### **Backrest inclination**



Turn handwheel. Do not lean on backrest when adjusting.

## Seat height



Lever pumping motion

up : seat higher down : seat lower

#### Seat inclination



Press switch

top : front end higher bottom : front end lower

## Lumbar support



Adjust lumbar support using the fourway switch to suit personal requirements.

Moving support up and down: push switch up or down.

Increasing and decreasing support: push switch forwards or backwards.

## Adjustable thigh support



Pull the lever and slide the thigh support.

## Power seat adjustment

## **△**Warning

Care must be taken when operating the power seats. There is a risk of injury, particularly for children. Objects could become trapped.

Keep a close watch on the seats when adjusting them. Vehicle passengers should be informed accordingly.

## Longitudinal adjustment



Move switch forwards/backwards.

## Seat height



Move switch upwards/downwards.

### Seat inclination



Tilt front of switch upwards/downwards.

#### **Backrest inclination**



Tilt switch forwards/backwards.

## Lumbar support



Adjust lumbar support using the four-way switch to suit personal requirements.

Moving support up and down: push switch up or down.

Increasing and decreasing support: push switch forwards or backwards.

## Adjustable thigh support



Pull the lever and slide the thigh support.

#### Side bolster



Adjust seat backrest width to suit personal requirements.

Press & to reduce backrest width.

Press & to increase backrest width.

## Memory function for power seat adjustment and exterior mirrors

Two different driver's seat and exterior mirror settings can be stored. Memorised settings ❖ 25, Vehicle personalisation ❖ 127.



#### Storing memory position

- Adjust driver's seat and then adjust exterior mirrors to desired positions.
- Press and hold MEM and 1 or 2 simultaneously until a chime sounds.

#### Recall of memory positions

Press and hold button1 or 2 until the stored seat and exterior mirror positions have been reached. Releasing the button during seat movement cancels the recall.

#### Automatic recall of memory positions

Memory positions are assigned to the driver (1 or 2) using the respective key and are automatically recalled when the ignition is switched on. In addition, a message in the Driver Information Centre indicates the driver number, identified by the used key. If the ignition is switched on more than three subsequent times with the same key, the message will not be displayed again until another key is being used.

To stop recall movement, press one of the memory-, power mirror- or power seat controls.

Precondition is that **Personalization By Driver** and **Auto Memory Recall** is activated in the personal settings of the Info-Display.

This function can be activated or deactivated in the vehicle personalisation.

Select the relevant setting in the **Vehicle** menu in the Info-Display. Info-Display ♀ 121.

#### Easy exit function

For a convenient exit out of the vehicle, the power driver seat moves rearwards when vehicle is stationary.

To activate the easy exit function:

- set selector lever to position P (automatic transmission)
- apply parking brake (manual transmission)
- switch off ignition
- remove key from the ignition switch
- open the driver's door

If the door is already open, switch off ignition to activate easy exit.

To stop movement, press one of the memory or power seat controls.

This function can be activated or deactivated in the vehicle personalisation.

Select the relevant setting in the **Vehicle** menu in the Info-Display. Info-Display ▷ 121.

#### Safety function

If the driver's seat encounters resistance during movement, the recall may stop. After removing the obstruction, press and hold the appropriate memory position button for two seconds. Try recalling the memory position again. If the recall does not operate, consult a workshop.


#### Overload

If the seat setting is electrically overloaded, the power supply is automatically cut-off for a short time.

#### Note

After an accident in which airbags have been deployed, the memory function for each position button will be deactivated.

#### **Armrest**



Push button and fold armrest upwards. Under the armrest there is a storage compartment and an inductive charger.

## Heating



Adjust heating to the desired setting by pressing # for the respective seat one or more times. The control indicator in the button indicates the setting.

Prolonged use of the highest setting for people with sensitive skin is not recommended.

The seat heating will be reduced automatically from highest level to medium level after 30 minutes.

Seat heating is operational when engine is running and during an Autostop.

#### Automatic seat heating

Depending on the equipment, the automatic seat heating can be enabled in the vehicle personalisation menu in the Info-Display.

When enabled, the heating of the seats will be activated automatically at vehicle start. The activation is based on several parameters such as vehicle interior temperature, intensity and direction of the sun and temperature setting of the electronic climate control system for the driver and passenger side.

As the vehicle's interior warms up, the seat heating level will be reduced automatically until it finally goes off. The seat heating level being provided during the automatic operation is shown by heated seat indicator lights.

If the passenger seat is unoccupied, the automatic seat heating feature will not activate the seat heating for that seat. The seat heating buttons can be pressed at any time to exit the automatic seat heating for the respective seat and control the seat heating manually instead.

## Ventilating



Adjust ventilation to the desired setting by pressing a for the respective seat one or more times. The control indicator in the button indicates the setting.

Ventilated seats are operational when engine is running and during an Autostop.

## Massage




Press at to switch on the back massage function.

To switch off, press ≼ again. The current massage procedure will be ended, this may take a few seconds.

After ten minutes the massage function is switched off automatically.


## Rear seats

#### Armrest



Fold armrest down. The armrest contains cupholders.

## Heating



Activate seat heating by pressing #/
for the respective rear outer seat.
Activation is indicated by the LED in
the button.

Press # once more to deactivate seat heating.

Prolonged use for people with sensitive skin is not recommended.

Seat heating is operational when engine is running and during an Autostop.

## Seat belts



The seat belts are locked during heavy acceleration or deceleration of the vehicle, holding the occupants in the seat position. Thereby the risk of injury is considerably reduced.

## **△**Warning

Fasten seat belt before each trip. In the event of an accident, people not wearing seat belts endanger their fellow occupants and themselves.

Seat belts are designed to be used by only one person at a time. Child restraint system \$\dip\$ 64.

Periodically check all parts of the belt system for damage, soiling and proper functionality.

Have damaged components replaced by a workshop. After an accident, have the belts and triggered belt pretensioners replaced by a workshop.

#### Note

Make sure that the belts are not damaged by shoes or sharp-edged objects or trapped. Prevent dirt from getting into the belt retractors.

#### Seat belt reminder

Each seat is equipped with a seat belt reminder, indicated for front seats by control indicators ♣ and ♣², or for rear seats by the symbol ♣ in the Driver Information Centre ▷ 107.

#### Belt force limiters

Stress on the body is reduced by the gradual release of the belt during a collision.

#### Belt pretensioners

In the event of a head-on, rear-end or side-on collision of a certain severity, the front and rear seat belts are tightened. The front seat belts and the outer rear seat belts are tightened by one pretensioner per seat.

## **△**Warning

Incorrect handling (e.g. removal or fitting of belts) can trigger the belt pretensioners.

Deployment of the belt pretensioners is indicated by continuous illumination of control indicator № ▷ 108.

Triggered belt pretensioners must be replaced by a workshop. Belt pretensioners can only be triggered once.

#### Note

Do not affix or install accessories or other objects that may interfere with the operation of the belt pretensioners. Do not make any modifications to belt pretensioner components as this will invalidate the operating permit of your vehicle.

## Three-point seat belt

#### Fasten



Withdraw the belt from the retractor, guide it untwisted across the body and insert the latch plate into the buckle. Tighten the lap belt regularly whilst driving by pulling the shoulder belt.



Loose or bulky clothing prevents the belt from fitting snugly. Do not place objects such as handbags or mobile phones between the belt and your body.

## **△**Warning

The belt must not rest against hard or fragile objects in the pockets of your clothing.

Seat belt reminder ♣, ♣² ♦ 107.

#### Unfasten



To release belt, press red button on belt buckle.

## Using the seat belt while pregnant



## **△Warning**

The lap belt must be positioned as low as possible across the pelvis to prevent pressure on the abdomen.

## Airbag system

The airbag system consists of a number of individual systems depending on the scope of equipment.

When triggered, the airbags inflate within milliseconds. They also deflate so quickly that it is often unnoticeable during the collision.

## **△**Warning

The airbag system deploys in an explosive manner, repairs must be performed by skilled personnel only.

## **△**Warning

Adding accessories that change the vehicle's frame, bumper system, height, front end or side sheet metal, may keep the airbag system from working properly. The operation of the airbag system can also be affected by changing any parts of the front seats, seat belts,

airbag sensing and diagnostic module, steering wheel, instrument panel, inner door seals including the speakers, any of the airbag modules, ceiling or pillar trim, front sensors, side impact sensors or airbag wiring.

#### Note

The airbag systems and belt pretensioner control electronics are located in the centre console area. Do not put any magnetic objects in this area.

Do not affix any objects onto the airbag covers and do not cover them with other materials. Have damaged covers replaced by a workshop.

Each airbag is triggered only once. Have deployed airbags replaced by a workshop. Furthermore, it may be necessary to have the steering wheel, the instrument panel, parts of the panelling, the door seals, handles and the seats replaced.

Do not make any modifications to the airbag system as this will invalidate the vehicle operating permit.

## Child restraint systems on front passenger seat with airbag systems

Warning according to ECE R94.02:



**EN:** NEVER use a rearward-facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it; DEATH or SERIOUS INJURY to the CHILD can occur.

**DE:** Nach hinten gerichtete Kindersitze NIEMALS auf einem Sitz verwenden, der durch einen davor befindlichen AKTIVEN AIRBAG geschützt ist, da dies den TOD oder SCHWERE VERLETZUNGEN DES KINDES zur Folge haben kann.

FR: NE JAMAIS utiliser un siège d'enfant orienté vers l'arrière sur un siège protégé par un COUSSIN GONFLABLE ACTIF placé devant lui, sous peine d'infliger des BLESSURES GRAVES, voire MORTELLES à l'ENFANT.

ES: NUNCA utilice un sistema de retención infantil orientado hacia atrás en un asiento protegido por un AIRBAG FRONTAL ACTIVO. Peligro de MUERTE o LESIONES GRAVES para el NIÑO.

RU: ЗАПРЕЩАЕТСЯ устанавливать детское удерживающее устройство лицом назад на сиденье автомобиля, оборудованном фронтальной подушкой безопасности, если ПОДУШКА НЕ ОТКЛЮЧЕНА! Это

может привести к СМЕРТИ или СЕРЬЕЗНЫМ ТРАВМАМ РЕБЕНКА.

**NL:** Gebruik NOOIT een achterwaarts gericht kinderzitje op een stoel met een ACTIEVE AIRBAG ervoor, om DODELIJK of ERNSTIG LETSEL van het KIND te voorkomen.

**DA:** Brug ALDRIG en bagudvendt autostol på et forsæde med AKTIV AIRBAG, BARNET kan komme i LIVSFARE eller komme ALVORLIGT TIL SKADE.

SV: Använd ALDRIG en bakåtvänd barnstol på ett säte som skyddas med en framförvarande AKTIV AIRBAG. DÖDSFALL eller ALLVARLIGA SKADOR kan drabba BARNET.

FI: ÄLÄ KOSKAAN sijoita taaksepäin suunnattua lasten turvaistuinta istuimelle, jonka edessä on AKTIIVINEN TURVATYYNY, LAPSI VOI KUOLLA tai VAMMAUTUA VAKAVASTI.

NO: Bakovervendt barnesikringsutstyr må ALDRI brukes på et sete med AKTIV KOLLISJONSPUTE foran, da det kan føre til at BARNET utsettes for LIVSFARE og fare for ALVORLIGE SKADER.

PT: NUNCA use um sistema de retenção para crianças voltado para trás num banco protegido com um AIRBAG ACTIVO na frente do mesmo, poderá ocorrer a PERDA DE VIDA ou FERIMENTOS GRAVES na CRIANÇA.

IT: Non usare mai un sistema di sicurezza per bambini rivolto all'indietro su un sedile protetto da AIRBAG ATTIVO di fronte ad esso: pericolo di MORTE o LESIONI GRAVI per il BAMBINO!

EL: ΠΟΤΕ μη χρησιμοποιείτε παιδικό κάθισμα ασφαλείας με φορά προς τα πίσω σε κάθισμα που προστατεύεται από μετωπικό ΕΝΕΡΓΟ ΑΕΡΟΣΑΚΟ, διότι το παιδί μπορεί να υποστεί ΘΑΝΑΣΙΜΟ ή ΣΟΒΑΡΟ ΤΡΑΥΜΑΤΙΣΜΟ.

PL: NIE WOLNO montować fotelika dziecięcego zwróconego tyłem do kierunku jazdy na fotelu, przed którym znajduje się WŁĄCZONA PODUSZKA POWIETRZNA. Niezastosowanie się do tego

zalecenia może być przyczyną ŚMIERCI lub POWAŻNYCH OBRAŻEŃ u DZIECKA.

TR: Arkaya bakan bir çocuk emniyet sistemini KESİNLİKLE önünde bir AKTİF HAVA YASTIĞI ile korunmakta olan bir koltukta kullanmayınız. ÇOCUK ÖLEBİLİR veya AĞIR ŞEKİLDE YARALANABİLİR.

**UK**: НІКОЛИ не використовуйте систему безпеки для дітей, що встановлюється обличчям назад, на сидінні з УВІМКНЕНОЮ ПОДУШКОЮ БЕЗПЕКИ, інакше це може призвести до СМЕРТІ чи СЕРЙОЗНОГО ТРАВМУВАННЯ ДИТИНИ.

HU: SOHA ne használjon hátrafelé néző biztonsági gyerekülést előlről AKTÍV LÉGZSÁKKAL védett ülésen, mert a GYERMEK HALÁLÁT vagy KOMOLY SÉRÜLÉSÉT okozhatja.

HR: NIKADA nemojte koristiti sustav zadržavanja za djecu okrenut prema natrag na sjedalu s AKTIVNIM ZRAČNIM JASTUKOM ispred njega, to bi moglo dovesti do SMRTI ili OZBILJNJIH OZLJEDA za DIJETE.

SL: NIKOLI ne nameščajte otroškega varnostnega sedeža, obrnjenega v nasprotni smeri vožnje, na sedež z AKTIVNO ČELNO ZRAČNO BLAZINO, saj pri tem obstaja nevarnost RESNIH ali SMRTNIH POŠKODB za OTROKA.

SR: NIKADA ne koristiti bezbednosni sistem za decu u kome su deca okrenuta unazad na sedištu sa AKTIVNIM VAZDUŠNIM JASTUKOM ispred sedišta zato što DETE može da NASTRADA ili da se TEŠKO POVREDI.

**МК:** НИКОГАШ не користете детско седиште свртено наназад на седиште заштитено со АКТИВНО ВОЗДУШНО ПЕРНИЧЕ пред него, затоа што детето може ДА ЗАГИНЕ или да биде ТЕШКО ПОВРЕДЕНО.

ВG: НИКОГА не използвайте детска седалка, гледаща назад, върху седалка, която е защитена чрез АКТИВНА ВЪЗДУШНА ВЪЗГЛАВНИЦА пред нея - може да се стигне до СМЪРТ или СЕРИОЗНО НАРАНЯВАНЕ на ДЕТЕТО.

RO: Nu utilizați NICIODATĂ un scaun pentru copil îndreptat spre partea din spate a mașinii pe un scaun protejat de un AIRBAG ACTIV în fața sa; acest lucru poate duce la DECESUL sau VĂTĂMAREA GRAVĂ a COPILULUI.

CS: NIKDY nepoužívejte dětský zádržný systém instalovaný proti směru jízdy na sedadle, které je chráněno před sedadlem AKTIVNÍM AIRBAGEM. Mohlo by dojít k VÁŽNÉMU PORANĚNÍ nebo ÚMRTÍ DÍTĚTE.

SK: NIKDY nepoužívajte detskú sedačku otočenú vzad na sedadle chránenom AKTÍVNYM AIRBAGOM, pretože môže dôjsť k SMRTI alebo VÁŽNYM ZRANENIAM DIEŤAŤA.

LT: JOKIU BŪDU nemontuokite atgal atgręžtos vaiko tvirtinimo sistemos sėdynėje, prieš kurią įrengta AKTYVI ORO PAGALVĖ, nes VAIKAS GALI ŽŪTI arba RIMTAI SUSIŽALOTI.

LV: NEKĀDĀ GADĪJUMĀ neizmantojiet uz aizmuguri vērstu bērnu sēdeklīti sēdvietā, kas tiek aizsargāta ar tās priekšā uzstādītu AKTĪVU DROŠĪBAS SPILVENU, jo pretējā gadījumā BĒRNS var gūt SMAGAS TRAUMAS vai IET BOJĀ.

ET: ÄRGE kasutage tahapoole suunatud lapseturvaistet istmel, mille ees on AKTIIVSE TURVAPADJAGA kaitstud iste, sest see võib põhjustada LAPSE SURMA või TÕSISE VIGASTUSE.

MT: QATT tuża trażżin għat-tfal li jħares lejn in-naħa ta' wara fuq sit protett b'AIRBAG ATTIV quddiemu; dan jista' jikkawża I-MEWT jew GRIEĦI SERJI lit-TFAL.

**GA:** Ná húsáid srian sábháilteachta linbh cúil RIAMH ar shuíochán a bhfuil mála aeir ag feidhmiú os a chomhair. Tá baol BÁIS nó GORTÚ DONA don PHÁISTE ag baint leis.


Beyond the warning required by ECE R94.02, for safety reasons a forward-facing child restraint system must only be used subject to the instructions and restrictions in the table ♀ 67.

The airbag label is located on both sides of the front passenger sun visor. Airbag deactivation ♦ 63.

## Front airbag system

The front airbag system consists of one airbag in the steering wheel and one in the instrument panel on the front passenger side. These can be identified by the word **AIRBAG**.

The front airbag system is triggered in the event of a front-end impact of a certain severity. The ignition must be switched on.



The inflated airbags cushion the impact, thereby reducing the risk of injury to the upper body and head of the front seat occupants considerably.

## **△**Warning

Optimum protection is only provided when the seat is in the proper position.

Keep the area in which the airbag inflates clear of obstructions.

Fit the seat belt correctly and engage securely. Only then is the airbag able to protect.

## Side airbag system



The side airbag system consists of an airbag in each front seat backrest and in the rear outboard seat backrests. This can be identified by the word **AIRBAG**.

The side airbag system is triggered in the event of a side impact of a certain severity. The ignition must be switched on.



The inflated airbags cushion the impact, thereby reducing the risk of injury to the upper body and pelvis in the event of a side-on collision considerably.

## **△**Warning

Keep the area in which the airbag inflates clear of obstructions.


#### Note

Only use protective seat covers that have been approved for the vehicle. Be careful not to cover the airbags.

## Curtain airbag system

The curtain airbag system consists of an airbag in the roof frame on each side. This can be identified by the word **AIRBAG** on the roof pillars.

The curtain airbag system is triggered in the event of a side-on impact of a certain severity. The ignition must be switched on.



The inflated airbags cushion the impact, thereby reducing the risk of injury to the head in the event of a side-on impact considerably.

## **△**Warning

Keep the area in which the airbag inflates clear of obstructions.

The hooks on the handles in the roof frame are only suitable for hanging up light articles of clothing, without coat hangers. Do not keep any items in these clothes.

## Airbag deactivation

The front passenger airbag system must be deactivated for child restraint system on the passenger seat according to the instructions in the table ⋄ 67. The side airbag and curtain airbag systems, the belt pretensioners and all driver airbag systems will remain active.



The front passenger airbag system can be deactivated via a keyoperated switch on the passenger side of the instrument panel.



Use the key blade, located in the electronic key, to choose the position:

%₂ OFF : front passenger airbag is deactivated and will not inflate in the event of a collision. Control indicator OFF illuminates continuously in the centre console

**№**2 ON : front passenger airbag is

l active

## **⚠** Danger

Deactivate passenger airbag only in combination with the use of a child restraint system, subject to the instructions and restrictions in the table ▷ 67.

Otherwise, there is a risk of fatal injury for a person occupying a seat with a deactivated front passenger airbag.



If the control indicator  $\Re$  illuminates for approx. 60 seconds after the ignition is switched on, the front passenger airbag system will inflate in the event of a collision.

If the control indicator \* illuminates after the ignition is switched on, the front passenger airbag system is deactivated. It stays on while the airbag is deactivated.

If both control indicators are illuminated at the same time, there is a system failure. The status of the system is not discernible, therefore no person is allowed to occupy the front passenger seat. Contact a workshop immediately.

Consult a workshop immediately if neither of the two control indicators are illuminated.

Change status only when the vehicle is stopped with the ignition off.

Status remains until the next change.

# Child restraints Child restraint systems

## **△**Danger

If using a rear-facing child restraint system on the front passenger seat, the airbag system for the front passenger seat must be deactivated. This also applies to certain forward-facing child restraint systems as indicated in the tables ⋄ 67.

Airbag deactivation ♦ 63, Airbag label ♦ 58.

We recommend a child restraint system which is tailored specifically to the vehicle. For further information, contact your workshop.

When a child restraint system is being used, pay attention to the following usage and installation instructions and also those supplied with the child restraint system.

Always comply with local or national regulations. In some countries, the use of child restraint systems is forbidden on certain seats.

Child restraint systems can be fastened with:

- Three-point seat belt
- ISOFIX brackets
- Top-tether

## Three-point seat belt

Child restraint systems can be fastened by using a three-point seat belt. Depending on the size of the used child restraint systems, up to three child restraint systems can be attached to the rear seats. After fastening the child restraint system, the seat belt has to be tightened 

♦ 67

#### ISOFIX brackets



Fasten vehicle-approved ISOFIX child restraint systems to the ISOFIX brackets. Specific vehicle ISOFIX child restraint system positions are marked in the ISOFIX table ♀ 67.

ISOFIX brackets are indicated by a label on the backrest.

An i-size child restraint system is an universal ISOFIX child restraint system according UN Regulation No. 129.

All i-size child restraint systems can be used on any vehicle seat suitable for i-size, i-size table ♀ 67.

Either a Top-tether strap or a support leg must be used in addition to the ISOFIX brackets.



i-size child seats and vehicle seats with i-size approval are marked with i-size symbol, see illustration.

#### Top-tether anchors

Top-tether anchors are marked with the symbol & for a child seat.



In addition to the ISOFIX mounting brackets, fasten the Top-tether strap to the Top-tether anchors.

## Selecting the right system

The rear seats are the most convenient location to fasten a child restraint system.

Children should travel facing rearwards in the vehicle as long as possible. This makes sure that the child's backbone, which is still very weak, is under less strain in the event of an accident.

Suitable are restraint systems that comply with valid UN ECE regulations. Check local laws and regulations for mandatory use of child restraint systems.

The following child restraints are recommended for the following weight classes:

Maxi Cosi Cabriofix for children up to 13 kg for group 0, group 0+ and Duo Plus for children from 13 kg to 18 kg in group I.

Ensure that the child restraint system to be installed is compatible with the vehicle type.

Ensure that the mounting location of the child restraint system within the vehicle is correct, see following tables.

Allow children to enter and exit the vehicle only on the side facing away from the traffic.

When the child restraint system is not in use, secure the seat with a seat belt or remove it from the vehicle.

#### Note

Do not affix anything on the child restraint systems and do not cover them with any other materials.

A child restraint system which has been subjected to stress in an accident must be replaced.

#### Child restraint installation locations

#### Permissible options for fastening a child restraint system with a three-point seat belt

#### On front passenger seat

Weight class	activated airbag	deactivated airbag	On rear outboard seats	On rear centre seat
Group 0: up to 10 kg	X	U <sup>1,2</sup>	U/L <sup>3</sup>	U
Group 0+: up to 13 kg	X	U <sup>1,2</sup>	U/L <sup>3</sup>	U
Group I: 9 to 18 kg	X	U <sup>1,2</sup>	U/L <sup>3,4</sup>	$U^4$
Group II: 15 to 25 kg	U <sup>1,2</sup>	X	U/L <sup>3,4</sup>	$U^4$
Group III: 22 to 36 kg	U <sup>1,2</sup>	Х	U/L <sup>3,4</sup>	U <sup>4</sup>

U: universal suitability in conjunction with three-point seat belt

L: suitable for particular child restraint systems of the 'specific-vehicle', 'restricted' or 'semi-universal' categories. The child restraint system must be approved for the specific vehicle type (refer to the vehicle type list of the child restraint system)

X: no child restraint system permitted in this weight class

1 : move seat forwards as far as necessary and adjust seat backrest as far as necessary to a vertical position to ensure that the belt runs forwards from the upper anchorage point

2 : move seat upwards as far as necessary and adjust seat backrest as far as necessary to a vertical position to ensure that the belt is tight on the buckle side

3 : move the respective front seat ahead of the child restraint system forwards as far as necessary

4 : adjust the respective headrest as necessary or remove if required

## Permissible options for fitting an ISOFIX child restraint system with ISOFIX brackets

			On front passenger seat		On rear outboard	On rear centre
Weight class	Size class	Fixture	activated airbag	deactivated airbag		seat
Group 0: up to 10 kg	G	ISO/L2	X	X	X	X
	F	ISO/L1	X	X	X	X
	E	ISO/R1	X	X	IL <sup>3</sup>	X
	E	ISO/R1	X	X	IL <sup>3</sup>	X
	D	ISO/R2	X	X	IL <sup>3</sup>	X
	С	ISO/R3	Х	Х	IL <sup>3</sup>	Х
Group I: 9 to 18 kg	D	ISO/R2	Х	Х	IL <sup>3,4</sup>	Х
	С	ISO/R3	Х	Х	IL <sup>3,4</sup>	Х
	В	ISO/F2	Х	Х	IL, IUF <sup>3,4</sup>	Х
	B1	ISO/F2X	X	X	IL, IUF <sup>3,4</sup>	Х
	A	ISO/F3	X	X	IL, IUF <sup>3,4</sup>	Х
Group II: 15 to 25 kg			Х	X	IL <sup>3,4</sup>	Х
Group III: 22 to 36 kg			X	X	IL <sup>3,4</sup>	Х

On front nacconder coat

IL : suitable for particular ISOFIX restraint systems of the 'specific-vehicle', 'restricted' or 'semi-universal' categories. The ISOFIX restraint system must be approved for the specific vehicle type (refer to the vehicle type list of the child restraint system)

IUF: suitable for ISOFIX forward-facing child restraint systems of universal category approved for use in this weight class

X : no ISOFIX child restraint system approved in this weight class

- 1 move seat forwards as far as necessary and adjust seat backrest inclination as far as necessary to a vertical position to ensure that the belt runs forwards from the upper anchorage point
- 2 : move seat height adjustment upwards as far as necessary and adjust seat backrest inclination as far as necessary to a vertical position to ensure that the belt is tight on the buckle side
- 3 : move the respective front seat ahead of the child restraint system forwards as far as necessary
- 4 : adjust the respective headrest as necessary or remove if required

#### ISOFIX size class and seat device

A – ISO/F3 : forward-facing child restraint system for children of maximum size in the weight class 9 to 18 kg

B – ISO/F2 : forward-facing child restraint system for smaller children in the weight class 9 to 18 kg B1 – ISO/F2X : forward-facing child restraint system for smaller children in the weight class 9 to 18 kg

C – ISO/R3 : rear-facing child restraint system for children of maximum size in the weight class up to 18 kg

D – ISO/R2 : rear-facing child restraint system for smaller children in the weight class up to 18 kg E – ISO/R1 : rear-facing child restraint system for young children in the weight class up to 13 kg

F– ISO/L1 : left lateral facing position child restraint system (carry-cot) G – ISO/L2 : right lateral facing position child restraint system (carry-cot)

### Permissible options for fitting an i-Size child restraint system with ISOFIX brackets

	On front passenger seat						
	activated airbag	deactivated airbag	On rear outboard seats	On rear centre seat			
i-Size child restraint systems	X	X	i - U	X			

## 70 Seats, restraints

i - U : suitable for i-Size 'universal' forward and rearward facing child restraint systems

X : seating position not suitable for i-Size 'universal' child restraint systems

# Pedestrian protection system

#### **Active bonnet**

Pedestrian protection system can help to reduce the injury of pedestrians in case of a front collision.

When the sensors in the front bumper detect a certain impact within the speed range of 25 km/h to 50 km/h, the rear part of the bonnet will be lifted to reduce pedestrians head injuries.

In addition the front bumper is designed to reduce leg injuries of pedestrians.

The active bonnet can be triggered only once and remains in the raised position. A message is displayed in the Driver Information Centre.

Seek the assistance of a workshop as soon as possible, thereby adapting the driving style, to have the actuators, hinges and bonnet replaced.

#### **△**Warning

Do not drive with the bonnet raised.

#### **△**Warning

After any frontal accident the front bumper may appear to be intact, however, the sensors may be damaged. Consult a workshop to verify proper functionality of the sensors.

The system may not trigger under the following conditions:

- The impact is out of sensor range.
- The sensors are damaged or blocked by accessory parts.
- The bonnet is blocked by snow or ice.
- The vehicle speed is not within the range.
- The object is too small.

#### Manually bonnet lowering

#### **⚠**Warning

After the system has triggered, the hinges of the bonnet are hot. Do not touch.

To manually lower the triggered bonnet for driving to the next workshop:

- 1. Pull the bonnet release lever.
- 2. Push the safety catch to left vehicle side
- Open the bonnet approx. 20 cm and lower it slowly without engaging.
- Push down bonnet with both hands at rear corners in small steps alternating between right and left side.

#### **△**Warning

Be sure to keep away from the edge of the bonnet to prevent injuries.

# 72 Seats, restraints

- 5. Check that the bonnet is engaged at the rear.
- 6. Close bonnet at the front and check that it is engaged \$\dip\$ 241.

# Storage

Storage compartments	73
Glovebox	73
Cupholders	73
Front storage	
Sunglasses storage	74
Armrest storage	74
Centre console storage	74
Load compartment	75
Load compartment cover	
Rear floor storage cover	80
Rear storage	80
Lashing eyes	81
Cargo management system	81
Safety net	81
Warning triangle	
First aid kit	
Roof rack system	85
Roof rack	
Loading information	86

# Storage compartments

### **△**Warning

Do not store heavy or sharp objects in the storage compartments. Otherwise, the storage compartment lid could open and vehicle occupants could be injured by objects being thrown around in the event of hard braking, a sudden change in direction or an accident.

#### Glovebox




The glovebox should be closed whilst driving.

# Cupholders



Cupholders are located in the centre console behind a cover. Open the cover.



Additional cupholders are located in the rear armrest. Fold down armrest.

## Front storage



A storage box is located in the centre console. Push cover to the front.


# Sunglasses storage



Fold down and open.

Do not use for storing heavy objects.

# Armrest storage Storage in the front armrest




Push button to fold up the armrest.

# Centre console storage

The storage container can be used to store small items.

Depending on the version, the storage compartment is located under a cover.



Press cover at the rear to open.

# Load compartment

Depending on the equipment, the rear seat backrest is divided into two or three parts. All parts can be folded down.

Before folding rear seat backrests, execute the following if necessary:

- Remove the rear head restraints to have the backrests fully rest on the seat cushions \$\phi\$ 45.

# Load compartment extension (two-part rear seat backrest)



- Pull the release lever on one or both outer sides and fold down the backrests onto the seat cushion.
- To fold up, raise the backrests and guide them into an upright position until they engage audibly. Make sure that the belts are positioned correctly and stay clear of the folding area.



The backrests are properly engaged when the red mark near the release lever is no longer visible.

### **△**Warning

When folding up, ensure that backrests are securely locked in position before driving. Failure to do so may result in personal injury or damage to the load or vehicle in the event of hard braking or a collision.



The seat belt of the centre seat could be blocked when the backrest is folded up too quickly. To unlock the retractor, push in the seat belt or pull it out by approx. 20 mm then release.

# Load compartment extension (three-part rear seat backrest)

Fold up the rear armrest.



- Pull the loop and fold down the backrest of the centre seat.
- Pull the release lever on one or both outer sides and fold down the backrests onto the seat cushion.

# **⚠**Warning


Take care when folding down the right outer seat backrest if the centre seat backrest is already folded down. Risk of injury due to bolt protruding from the inner side of the backrest.



 Pull the release lever on one or both outer sides and fold down the backrests onto the seat cushion.

#### **△**Warning

Take care when folding down the right outer seat backrest if the centre seat backrest is already folded down. Risk of injury due to bolt protruding from the inner side of the backrest.



 Alternatively fold seat backrests from the load compartment: pull switch on left or right sidewall of the load compartment to fold the corresponding part of the rear seat backrest.

### **△**Warning

Take care when operating the rear backrests from the load compartment. The backrest is folded with considerable force. Risk of injury, particularly to children.

Ensure that nothing is attached to the rear seats or located on the seat cushion.


 To fold up, raise the backrests and guide them into an upright position until they engage audibly. Make sure that the belts are positioned correctly and stay clear of the folding area.



The backrests are properly engaged when the red mark near the release lever is no longer visible.

#### **△**Warning

When folding up, ensure that backrests are securely locked in position before driving. Failure to do so may result in personal injury or damage to the load or vehicle in the event of hard braking or a collision.




The seat belt of the centre seat could be blocked when the backrest is folded up too quickly. To unlock the retractor, push in the seat belt or pull it out by approx. 20 mm then release.

## Load compartment cover

Do not place any objects on the cover.

#### **Grand Sport**

#### Removing cover



Unhook retaining straps from tailgate.



Lift cover at the rear and at the front. Remove the cover.

#### Fitting cover

Engage cover in side guides and fold downwards. Attach the retaining straps to the tailgate.

#### **Sports Tourer, Country Tourer**

#### Closing roller blind

Pull the roller blind using the handle towards the rear and upwards until it engages in the sideward retainers.

#### Opening roller blind



Pull the roller blind handle to the rear and downwards. It rolls up automatically.

#### Opening roller blind in load position



Press the roller blind handle.

The rear of the roller blind is guided

upwards automatically.

# Open the roller blind.


Pull the release lever on the right side up an hold it. Lift the roller blind first on the right side and remove from retrainers.

### Installing roller blind


Insert the left side of the roller blind in recess, then pull release lever up.

Hold and insert the right side of the roller blind in recess and engage.

#### Removing roller blind




# Rear floor storage cover Grand Sport



The rear floor cover can be removed. Raise cover at the loop and remove.

#### Sports Tourer, Country Tourer

The rear floor cover can be removed. Raise cover at the loop and remove.




Pull the handle and fold the rear part of the cover forward.



Set up the folded cover upright behind the rear seat backrests.

# Rear storage

#### Storage box



A storage box is located in the load compartment. Remove the cover to gain access to the storage box.

## Lashing eyes



The lashing eyes are designed to secure items against slippage, e.g. using lashing straps or luggage net.

# Cargo management system


The cargo rail system is a movable system to secure items at the the load compartment floor against slippage.

#### Mounting carriages in the rail



Insert carriages into the rails at the load compartment floor. Thereby use the recess in the rail and press the button on the carriage while inserting it.

#### Using the lashing eyes



Press the button on a carriage and slide it to the required position. Fold up the lashing eyes to use them.

#### Removing


Fold down the lashing eyes. Press the button of a carriage and remove it fromt the rail via recess.

# Safety net

The safety net can be installed behind the rear seats. If the rear seat backrests are folded the safety net can be installed behind the front seats. Passengers must not be transported behind the safety net.


#### Behind the rear seats

#### Installation



 Insert the cassette into retainers on left and right side. Note the signs L (left side) and R (right side) on the cassette as an installation hint.


Turn cassette slightly forward until the arrows face each other, to lock the cassette.



Pull safety net rod out of cassette. Suspend and engage safety net rod into installation opening on one side of the roof frame. Compress rod and suspend and engage at the other side.

#### Removal


- Remove and compress one side of safety net rod from installation opening. Remove other side of safety net rod from installation opening.
- Roll up safety net.



 Turn cassette slightly backwards to unlock and remove from retainers.

#### Behind the front seats

#### Installation




 Suspend and engage safety net rod into installation opening on one side of the roof frame.
 Compress rod, suspend and engage at the other side. Pull safety net rod out of cassette.



- Attach hooks of safety net cassette to lashing eyes in the floor in front of rear seats. To get access to the lashing eyes, push hooks in the perforated parts in the floor cover on both sides.
- Tension both straps by pulling at the loose end.

#### Removal



- Pull the flap at the tightener on both sides to release the straps.
- Remove and compress one side of safety net rod from installation opening. Remove other side of safety net rod from installation opening.
- Roll up safety net.
- Detach hooks from the lashing eyes.

# Warning triangle Grand Sport



Stow the warning triangle in the space at the rear of the load compartment.

## **Sports Tourer, Country Tourer**



Stow the warning triangle with the retaining straps of the tailgate inner panelling.

# First aid kit Grand Sport



Stow the first aid kit on the right side of the load compartment and secure it with the strap.

#### Sports Tourer, Country Tourer



Stow the first aid kit with the retaining straps of the tailgate inner panelling.


# Roof rack system

#### Roof rack

For safety reasons and to avoid damage to the roof, the vehicle approved roof rack system is recommended. For further information, contact your workshop.

#### Mounting roof rack

### **Grand Sport**



Open all doors.

Mounting points are located in each door frame of the vehicle body.

Fasten the roof rack according to the installation instructions delivered with the roof rack.

Remove the roof rack when not in use.

#### Sports Tourer, Country Tourer



Mounting points are located in each roof railing.

Fasten the roof rack on the first two mounting points according to the installation instructions delivered with the roof rack.

Remove the roof rack when not in use.

# Loading information



- Heavy objects in the load compartment should be placed against the seat backrests. Make sure that the backrests are securely engaged, i.e. no longer showing the red markings on the side near the release lever. If objects can be stacked, heavier objects should be placed at the bottom.
- Secure objects with lashing straps attached to lashing eyes

   ⇒ 81.

- Secure loose objects in the load compartment to prevent from sliding.
- When transporting objects in the load compartment, the backrests of the rear seats must not be angled forward.
- Do not allow the load to protrude above the upper edge of the backrests.
- Do not place any objects on the load compartment cover or the instrument panel, and do not cover the sensor on top of the instrument panel.
- The load must not obstruct the operation of the pedals, parking brake and gear selector, or hinder the freedom of movement of the driver. Do not place any unsecured objects in the interior.
- Do not drive with an open load compartment.

## **△**Warning

Always ensure that the load in the vehicle is securely stowed.

Otherwise objects can be thrown around inside the vehicle and cause personal injury or damage to the load or vehicle.

 The payload is the difference between the permitted gross vehicle weight (see identification plate 

≥ 289) and the EC kerb weight.

To calculate the payload, enter the data for your vehicle in the weights table at the front of this manual.

The EC kerb weight includes weights for the driver (68 kg), luggage (7 kg) and all fluids (fuel tank 90% full).

Optional equipment and accessories increase the kerb weight.

 Driving with a roof load increases the sensitivity of the vehicle to cross-winds and has a detrimental effect on vehicle handling due to the vehicle's higher centre of gravity. Distribute the load evenly and secure it properly with retaining straps. Adjust the tyre pressure and vehicle speed according to the load conditions. Check and retighten the straps frequently.

Do not drive faster than 120 km/h.

The permissible roof load is 100 kg. The roof load is the combined weight of the roof rack and the load.

90

Controle

# Instruments and controls

COHUOIS	
Steering wheel adjustment	
Steering wheel controls	89
Heated steering wheel	90
Horn	
Windscreen wiper and washer	
Rear window wiper and	
washer	92
Outside temperature	
Clock	
Power outlets	95
Inductive charging	
Ashtrays	
-	
Warning lights, gauges and indi-	
Warning lights, gauges and indicators	98
Warning lights, gauges and indicators	<b>98</b> 98
Warning lights, gauges and indicators Instrument cluster Speedometer	<b>98</b> 98 103
Warning lights, gauges and indicators	<b>98</b> 98 103
Warning lights, gauges and indicators Instrument cluster Speedometer	<b>98</b> 98 103 104
Warning lights, gauges and indicators Instrument cluster Speedometer Odometer Trip odometer Tachometer	<b>98</b> 98 103 104 105
Warning lights, gauges and indicators Instrument cluster Speedometer Odometer Trip odometer	<b>98</b> 98 103 104 105
Warning lights, gauges and indicators Instrument cluster Speedometer Odometer Trip odometer Tachometer	<b>98</b> 98 103 104 105
Warning lights, gauges and indicators Instrument cluster Speedometer Odometer Trip odometer Tachometer Fuel gauge Engine coolant temperature	<b>98</b> 98 103 104 105
Warning lights, gauges and indicators Instrument cluster Speedometer Odometer Trip odometer Tachometer Fuel gauge	<b>98</b> 98 103 104 105 105

Control indicators	107
Turn lights	107
Seat belt reminder	107
Airbag and belt tensioners	108
Airbag deactivation	
Charging system	109
Malfunction indicator light	109
Brake and clutch system	109
Electric parking brake	109
Electric parking brake fault	
Antilock brake system (ABS)	110
Gear shifting	
Following distance	
Lane keep assist	110
Electronic Stability Control of	
Electronic Stability Control an	
Traction Control system	
Traction Control system off	111
Engine coolant temperature.	
Preheating	
AdBlue	111
Tyre pressure monitoring	
system	
Engine oil pressure	111
Low fuel	112
Immobiliser	112
Exterior light	112
High beam	112
High beam assist	
LED headlights	112

Fog light Rear fog light Cruise control Adaptive cruise control Vehicle detected ahead Pedestrian detection Speed limiter Traffic sign assistant Door open	113 113 113 113 113
Displays	114
Driver Information Centre	
Info Display	121
Head-up display	
Vehicle messages	
Warning chimes	126
Battery voltage	
Vehicle personalisation	
Telematics service	
OnStar	
Onotal	131

#### Controls

# Steering wheel adjustment



Unlock lever, adjust steering wheel, then engage lever and ensure it is fully locked.

Do not adjust steering wheel unless vehicle is stationary and steering wheel lock has been released.

## Steering wheel controls

Driver Information Centre, some driver assistance systems, Infotainment system and a connected mobile phone can be operated via the controls on the steering wheel.



The illustrations show different versions.



Driver Information Centre ❖ 114.

Driver assistance systems ❖ 189.

Further information is available in the Infotainment manual.

# Heated steering wheel



Activate heating by pressing **8**. Activation is indicated by the LED in the button.

Heating is operational when the engine is running and during an Autostop.

Stop-start system \$\phi\$ 167.


#### Horn



Press 🗠.

# Windscreen wiper and washer

Windscreen wiper with adjustable wiper interval



HI : fast LO : slow

INT : interval wiping

**OFF**: off

For a single wipe when the windscreen wiper is off, press the lever downwards to position **1x**.

Do not use if the windscreen is frozen.

Switch off in car washes.

#### Adjustable wiper interval



Wiper lever in position **INT**. Turn the adjuster wheel to adjust the wiping frequency.

# Windscreen wiper with rain sensor



HI : fast LO : slow

**AUTO**: automatic wiping with rain

sensor

OFF : off

In AUTO position, the rain sensor detects the amount of water on the windscreen and automatically regulates the frequency of the windscreen wiper.

For a single wipe when the windscreen wiper is off, press the lever downwards to position 1x.

Do not use if the windscreen is frozen.

Switch off in car washes.

Adjustable sensitivity of the rain sensor



Wiper lever in position AUTO.

Turn the adjuster wheel to adjust the sensitivity of the rain sensor.



Keep the sensor free from dust, dirt and ice.

Rain sensor function can be activated or deactivated in the Vehicle personalisation.

Select the relevant setting in **Settings**, **Vehicle** in the Info-Display.

#### Windscreen washer



Pull lever. Washer fluid is sprayed onto the windscreen and the wiper wipes a few times.

Washer fluid \$\triangle 244.

# Rear window wiper and washer

#### Rear window wiper



Turn outer cap to activate the rear window wiper:

OFF : off

INT : intermittent operationON : continuous operation

Do not use if the rear window is frozen.

Switch off in car washes.

The rear window wiper comes on automatically when the windscreen wiper is switched on and reverse gear is engaged.

Activation or deactivation of this function can be changed in the menu **Settings** in the Info-Display.

#### Rear window washer



Push lever.

Washer fluid is sprayed onto the rear window and the wiper wipes a few times

The rear window washer system is deactivated when the fluid level is low

# Outside temperature

A drop in temperature is indicated immediately and a rise in temperature after a time delay.



Illustration shows an example.



Ice Possible.

Drive

with Care

If outside temperature drops to 3 °C, a warning message is displayed in the Driver Information Centre.

#### **△**Warning

The road surface may already be icy even though the display indicates a few degrees above 0 °C.

#### Clock

Date and time are shown in the Info-Display.

Info-Display \$\price 121.

#### 7" Colour-Info-Display

Press 

and then select **Settings**.

Select **Time and Date** to display the respective submenu.



#### **Set Time Format**

To select the desired time format, touch the screen buttons 12 h or 24 h.

#### Set Date Format

To select the desired date format, select **Set Date Format** and choose between the available options in the submenu.

#### **Auto Set**

To choose whether time and date are to be set automatically or manually, select **Auto Set**.

For time and date to be set automatically, select **On - RDS**.

For time and date to be set manually, select **Off - Manual**. If **Auto Set** is set to **Off - Manual**, the submenu items **Set Time** and **Set Date** become available.

#### Set time and date

To adjust the time and date settings, select **Set Time** or **Set Date**.

Touch + and - to adjust the settings.

#### 8" Colour-Info-Display

Press 

and then select the Settings icon.

Select Time and Date.

#### Set time

Select **Set Time** to enter the respective submenu.



Select **Auto Set** at the bottom of the screen. Activate either **On - RDS** or **Off - Manual**.

If **Off - Manual** is selected, adjust hours and minutes by touching ∧ or ∨.

Touch **12-24 Hr** on the right side of the screen to select a time mode.

If 12-hour mode is selected, a third column for AM and PM setting is displayed. Select the desired option.

#### Set date

Select **Set Date** to enter the respective submenu.

#### Note

If date information is automatically provided, this menu item is not available.

Select **Auto Set** at the bottom of the screen. Activate either **On - RDS** or **Off - Manual**.

If **Off - Manual** is selected, adjust the date by touching ∧ or ∨.

#### Clock display

Select **Clock Display** to enter the respective submenu.

To turn off the digital clock display in the menus, select **Off**.

#### Power outlets



A 12 Volt power outlet is located in the centre console. With ignition off, this power outlet is deactivated.



Sports Tourer, Country Tourer: A 12 Volt power outlet is located at the left sidewall in the load compartment.

With ignition off, this power outlet remains active.


Do not exceed the maximum power consumption of 120 watts.

Electrical accessories that are connected must comply with the electromagnetic compatibility requirements laid down in DIN VDE 40 839.

Do not connect any current-delivering accessories, e.g. electrical charging devices or batteries.


Do not damage the outlets by using unsuitable plugs.

#### USB ports



Depending on the infotainment system, one or two USB ports for charging devices are located below the foldable armrest. These ports have also a data connection to the Infotainment system. For further information, see Infotainment manual.

#### **USB** charging ports



Two USB ports for charging devices only are located in the back of the centre console.

#### Note

The sockets must always be kept clean and dry.

# Inductive charging


#### **△**Warning

Inductive charging can affect the operation of implanted pacemakers or other medical

devices. If applicable, seek medical advice before using the inductive charging device.

### **△**Warning

Remove any metal objects from the charging device before charging a mobile device, as these objects could become very hot.



To charge a device, the ignition must be switched on.

The charging slot is located below the front armrest.

To charge a mobile device:

- Remove all objects from the charging slot otherwise the system may not charge.
- Insert the mobile device with the display facing to the rear in the charging slot. Charging status is indicated in the Info display \(\forall \) and shows if mobile device is properly positioned.

If ⋠ is not displayed, remove mobile device from the slot. Turn mobile device 180 degrees and wait three seconds before inserting mobile device again.

PMA or Qi compatible mobile devices can be charged inductively.

A back cover with an integrated coil (e.g. Samsung 4 and 5) or a jacket (e.g. some iPhone models) may be required to charge a mobile device

The mobile device must be smaller than 8 cm in width and 15 cm in length to fit into the charging device.

Protective cover for the mobile device could have impact on the inductive charging.

## **Ashtrays**

#### Caution

To be used only for ash and not for combustible rubbish.



A portable ashtray can be placed in the cupholders.

# Warning lights, gauges and indicators


#### Instrument cluster

Depending on the version, three instrument clusters are available:


- Baselevel
- Midlevel
- Uplevel

Uplevel instrument cluster can be displayed as Sport mode or Tour mode.


#### Baselevel instrument cluster



#### Midlevel instrument cluster



### Uplevel instrument cluster, Sport mode



### Uplevel instrument cluster, Tour mode



#### Overview

- Seat belt reminder 

  □ 107

- Brake and clutch system 

   109
- Electric parking brake 

   109

- ▲ Gear shifting \$\times\$ 110
- Following distance 

   110

- ₱ Electronic Stability Control and Traction Control system 

  > 110
- ✓ Traction Control system off⇒ 111
- **™** Preheating ⊅ 111
- AdBlue 
   111
- ① Tyre pressure monitoring system ♀ 111
- 📂 Engine oil pressure 🗘 111
- Immobiliser 
   □ 112
- > € Exterior light \$\infty\$ 112
- ≣O High beam \$ 112
- High beam assist 
   112
- LED headlights 
   □ 112
- Fog light ▷ 112
- O Rear fog light \$\triangle\$ 113
- ☼ Cruise control ☼ 113

- Adaptive cruise control 
   ↑ 113
- ⇒ Vehicle detected ahead ⇒ 113

- Poor open ⇒ 113

# Speedometer



Indicates vehicle speed.

#### Odometer



The total recorded distance is displayed in km.

# Trip odometer

The recorded distance since the last reset is displayed on the trip computer page.

Trip odometer counts up to 9,999 km and then restarts at 0.

Two trip odometer pages are selectable for different trips.

#### Baselevel instrument cluster



Select /i\ by pressing Menu on the turn signal lever. Turn adjuster wheel on turn signal lever and select /i\1 or /i\2. Each trip odometer page can be reset separately by pressing SET/CLR on the turn signal lever for a few seconds on the respective menu.


#### Midlevel instrument cluster



Select **Info** page **⋒** on main menu. Choose page **Trip A** or **Trip B** by pressing **∨** on the steering wheel.

Each trip odometer can be reset separately when ignition is on: select respective page, press >. Confirm by pressing **√**.

#### Uplevel instrument cluster



Select Info page on main menu. Choose page Trip A or Trip B by pressing ✓ on the steering wheel.

Each trip odometer can be reset separately when ignition is on: select respective page, press >. Confirm by pressing **▼**.

#### **Tachometer**



Displays the engine speed.

Drive in a low engine speed range for each gear as much as possible.

#### Caution

If the needle is in the red warning zone, the maximum permitted engine speed is exceeded. Engine at risk.

# Fuel gauge



Displays the level in the fuel tank.

The arrow indicates the vehicle side where the fuel filler flap is located.

Control indicator In illuminates if the level in the tank is low. Refuel immediately if it flashes.

Never run the fuel tank dry.

Because of the fuel remaining in the tank, the top-up quantity may be less than the specified fuel tank capacity.

# Engine coolant temperature gauge



Displays the coolant temperature.

50°

 engine operating temperature not yet

reached

90° (central

: normal operating temperature

area) 130°

: temperature too high

#### Note

If engine coolant temperature is too high, stop vehicle, idle engine. Danger to engine. Check coolant level.

# Service display

The engine oil life system informs when to change the engine oil and filter. Based on driving conditions, the interval at which an engine oil and filter change will be indicated can vary considerably.

Remaining Oil Life

100%

The remaining oil life duration menu is displayed in the Driver Information Centre ♥ 114.



On Baselevel display select by pressing **MENU** on the turn signal lever. Turn the adjuster wheel to select the **Remaining Oil Life** page.



On Mid- and Uplevel display select **Info** Menu by pressing **◄** on steering wheel. Press **▼** to select **Remaining Oil Life** page.

Remaining oil life duration is indicated in percentage.

#### Reset

On Baselevel display press **SET/CLR** on turn signal lever for several seconds to reset. The ignition must be switched on but engine not running.

On Mid- and Uplevel display press 
➤ on steering wheel to open the subfolder. Select **Reset** and confirm by pressing **v** for several seconds. The ignition must be switched on but engine not running.

The system must be reset every time the engine oil is changed to allow proper functionality. Seek the assistance of a workshop.

#### Next service

When the system has calculated that engine oil life has been diminished, Change Engine Oil Soon appears in

the Driver Information Centre. Have engine oil and filter changed by a workshop within one week or 500 km (whichever occurs first).

Service information \$\triangle\$ 285.

#### Control indicators

The control indicators described are not present in all vehicles. The description applies to all instrument versions. Depending on the equipment, the position of the control indicators may vary. When the ignition is switched on, most control indicators will illuminate briefly as a functionality test.

The control indicator colours mean:

red : danger, important reminder yellow : warning, information, fault green : confirmation of activation blue : confirmation of activation white : confirmation of activation

# Turn lights

⇒ illuminates or flashes green.

### Illuminates briefly

The parking lights are switched on.

#### **Flashes**


A turn signal or the hazard warning flashers are activated.

Rapid flashing: failure of a turn signal light or associated fuse, failure of turn signal light on trailer.

## Seat belt reminder

### Seat belt reminder on front seats

for driver's seat illuminates or flashes red in the instrument cluster.



\$2 for front passenger seat illuminates or flashes red in the roof console, when seat is occupied.

#### Illuminates

After the ignition has been switched on until the seat belt has been fastened.

#### **Flashes**

After having started the engine for a maximum of 100 seconds until the seat belt has been fastened.

# Seat belt status on rear seats (vehicles with Baselevel display)

A illuminates or flashes white or grey in the Driver Information Centre, after having started the engine.

#### Illuminates white

Seat belt is unfastened.

#### Illuminates grey

Seat belt has been fastened.

### Flashes white or grey

Fastened seat belt has been unfastened.

Fastening the seat belt \$ 57.

# Seat belt status on rear seats (vehicles with Mid- or Uplevel display)

# illuminates green or grey or flashes yellow in the Driver Information Centre, after having started the engine.

#### Illuminates grey

Seat belt is unfastened.

#### Illuminates green

Seat belt has been fastened.

#### Flashes yellow

Fastened seat belt has been unfastened.

# Airbag and belt tensioners

illuminates red.

When the ignition is switched on, the control indicator illuminates for approx. four seconds. If it does not illuminate, does not go out after four seconds or illuminates whilst driving, there is a fault in the airbag system. Seek the assistance of a

workshop. The airbags and belt pretensioners may fail to trigger in the event of an accident.

Deployment of the belt pretensioners or airbags is indicated by continuous illumination of **\***.

# **▲**Warning

Have the cause of the fault remedied immediately by a workshop.

# Airbag deactivation



illuminates yellow.

The front passenger airbag is activated.

₹ illuminates yellow.

The front passenger airbag is deactivated.

Airbag deactivation \$\dip\$ 63.

# Charging system

illuminates red.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

# Illuminates when the engine is running

Stop, switch off engine. Vehicle battery is not charging. Engine cooling may be interrupted. The brake servo unit may cease to be effective. Seek the assistance of a workshop.

# Malfunction indicator light

illuminates or flashes yellow.
Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

# Illuminates when the engine is running

Fault in the emission control system. The permitted emission limits may be exceeded.

On diesel engines, the cleaning process of the diesel particle filter is potentially not possible.

Seek the assistance of a workshop immediately.

# Flashes when the engine is running

Fault that could lead to catalytic converter damage. Ease up on the accelerator until the flashing stops. Seek the assistance of a workshop immediately.

# Brake and clutch system

(1) illuminates red.

The brake and clutch fluid level is too low.

# **△**Warning

Stop. Do not continue your journey. Consult a workshop.

# Electric parking brake

(P) illuminates or flashes red.

#### Illuminates

#### **Flashes**

Electric parking brake is not fully applied or released. Depress the brake pedal and attempt to reset the system by first releasing then applying the electric parking brake. If (P) remains flashing, do not drive and seek the assistance of a workshop.

# Electric parking brake fault

illuminates or flashes yellow.

#### Illuminates

#### **Flashes**

Electric parking brake is in service mode. Stop vehicle, apply and release the electric parking brake to reset.

# **△**Warning

Have the cause of the fault remedied immediately by a workshop. Avoid parking on inclines until the cause of the fault has been remedied.

# Antilock brake system (ABS)

(89) illuminates yellow.

Illuminates for a few seconds after the ignition is switched on. The system is ready for operation when the control indicator extinguishes.

If the control indicator does not go out after a few seconds, or if it illuminates while driving, there is a fault in the ABS. The brake system remains operational but without ABS regulation.

# Gear shifting

▲ or ▼ with the number of a higher or lower gear is indicated, when up- or downshifting is recommended for fuel saving reasons.

# Following distance

 indicates the following distance setting of the alert timing sensitivity for the forward collision alert using filled distance bars.

# Lane keep assist

★ illuminates green or yellow, or flashes yellow.

## Illuminates green

The system is switched on and ready to operate.

## Illuminates yellow

The system approaches a detected lane marking without using the turn signal in that direction.

# Flashes yellow

The system recognizes that the lane is departed significantly.

# Electronic Stability Control off

illuminates yellow.

The system is deactivated.

# Electronic Stability Control and Traction Control system

illuminates or flashes yellow.

#### Illuminates

A fault in the system is present. Continued driving is possible. Driving stability, however, may deteriorate depending on road surface conditions. Have the cause of the fault remedied by a workshop.

#### **Flashes**

The system is actively engaged. Engine output may be reduced and the vehicle may be braked automatically to a small degree.

Electronic Stability Control ❖ 185, Traction Control system ❖ 184.

# Traction Control system off

illuminates yellow.

The system is deactivated.

# Engine coolant temperature

- **₺** illuminates red.

# Illuminates when the engine is running

Stop, switch off engine.

#### Caution

Coolant temperature too high.

If there is sufficient coolant, consult a workshop.

# Preheating

**100** illuminates yellow.

Preheating of Diesel engine is activated. Only activates when outside temperature is low. Start the engine when control indicator extinguishes.

## **AdBlue**

AdBlue level is low. Refill AdBlue soon to avoid prevention of the engine start.

AdBlue \$ 172.

# Tyre pressure monitoring system

(!) illuminates or flashes yellow.

#### Illuminates

Tyre pressure loss. Stop immediately and check tyre pressure.

#### **Flashes**

Fault in system or tyre without pressure sensor mounted (e.g. spare wheel). After 60 to 90 seconds the control indicator illuminates continuously. Consult a workshop.

# Engine oil pressure

red.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

# Illuminates when the engine is running

#### Caution

Engine lubrication may be interrupted. This may result in damage to the engine and/or locking of the drive wheels.

- 1. Depress clutch.
- 2. Select neutral gear.
- Move out of the flow of traffic as quickly as possible without impeding other vehicles.
- 4. Switch off ignition.

# **△**Warning

When the engine is off, considerably more force is needed to brake and steer.

During an Autostop, the brake servo unit will still be operational.

Do not remove key until vehicle is stationary, otherwise the steering wheel lock could engage unexpectedly.

## Low fuel

lluminates or flashes yellow.

#### Illuminates

Level in fuel tank is too low.

#### Flashes

Fuel used up. Refuel immediately. Never run the tank dry.

## **Immobiliser**

flashes yellow.

Fault in the immobiliser system. The engine cannot be started.

Immobiliser \$ 36.

# **Exterior light**

⇒ illuminates green.

The exterior lights are on  $\diamondsuit$  136.

# High beam

**≣**O illuminates blue.

Illuminated when high beam is on or during headlight flash ♀ 137.

# High beam assist

■ illuminates green.

The high beam assist is activated, see LED headlights \$\displays 140\$.

# LED headlights

illuminates or flashes yellow.

#### Illuminates

Fault in the system.

Seek the assistance of a workshop.

#### **Flashes**

System is switched to symmetrical low beam.

Control indicator ₹ flashes for approx. four seconds after the ignition is switched on as a reminder for symmetrical headlight ▷ 139.

# Fog light

≱D illuminates green.

The front fog lights are on ♦ 144.

# Rear fog light

# illuminates yellow.

# Cruise control

illuminates white or green.

#### Illuminates white

The system is on.

## Illuminates green

Cruise control is active. Set speed is indicated in the Driver Information Centre.

# Adaptive cruise control

\* illuminates in the Driver Information Centre.

#### ★ illuminates white

The system is on.

# 

Adaptive cruise control is active.

## Vehicle detected ahead

# Illuminates green

A vehicle ahead is detected in the same lane.

### Illuminates yellow

The distance to a preceding moving vehicle gets too small or when approaching another vehicle too rapidly.

# Pedestrian detection

オ illuminates yellow.

A pedestrian ahead is detected.

# Speed limiter

@ illuminates white or green.

#### Illuminates white

The system is on.

### Illuminates green

Speed limiter is active. Set speed is indicated near @ symbol.

# Traffic sign assistant

displays detected traffic signs as control indicator.

Traffic sign assistant ♦ 224.

# Door open

illuminates red.

A door or the tailgate is open.

# **Displays**

## **Driver Information Centre**


The Driver Information Centre is located in the instrument cluster.

Depending on the version and the instrument cluster, the Driver Information Centre is available as Baselevel display, Midlevel display or Uplevel display.

Driver Information Centre indicates depending on the equipment:

- overall and trip odometer
- · vehicle information and settings
- trip/fuel information
- driving economic information
- driver assistance alerts
- warning messages
- audio and infotainment information
- phone information
- navigation information

## Baselevel display



Depending on the version, the menu pages of the Baselevel display are selected by pressing:

- MENU on the turn signal lever or
- and ▼ on the steering wheel.

Main menu symbols are indicated in the top line of the display:

- Trip/fuel information, displayed by /i\, see description below.
- Vehicle information, displayed by , see description below.
- Eco information, displayed by
   see description below.

Some of the displayed functions differ when the vehicle is being driven or at a standstill. Some functions are only available when the vehicle is being driven.

Selecting menus and functions
Turn signal lever with MENU button
The menus and functions can be
selected via the buttons on the left
steering wheel stalk.



Press **MENU** to switch between the main menus or to return from a submenu to the next higher menu level.

Turn the adjuster wheel to select a submenu of the main menu or to set a numeric value.

Press **SET/CLR** to select and confirm a function.

Vehicle and service messages are popped-up in the Driver Information Centre when required. Confirm messages by pressing **SET/CLR**. Vehicle messages ▷ 125.

# Steering wheel controls

The menus and functions can be selected via the buttons on the right side of the steering wheel.




Press  $\nabla$  or  $\Delta$  to select a submenu of the main menu or to set a numeric value.

Press **✓** to select and confirm a function.

Vehicle and service messages are popped-up in the Driver Information Centre if required. Confirm messages by pressing **√**. Vehicle messages ⇒ 125.

# Midlevel display



#### Main menus are:

- Trip/fuel information, displayed by Info, see description below.
- Audio information, displayed by Audio, see description below.
- Phone information, displayed by Phone, see description below.
- Navigation information, displayed by Navigation, see description below.
- Vehicle information, displayed by Options, see description below.

Some of the displayed functions differ when the vehicle is being driven or at a standstill and some functions are only active when the vehicle is being driven.

#### Selecting menus and functions

The menus and functions can be selected via the buttons on the right side of the steering wheel.



Press  $\triangleleft$  to open main menu page. Select a main menu page with  $\Delta$  or  $\nabla$ . Confirm a main menu page with  $\checkmark$ . Once a main menu page is selected, press  $\Delta$  or  $\nabla$  to select subpages. Press **▶** to open a next folder of the selected subpage.


Press  $\Delta$  or  $\nabla$  to select functions or to set a numeric value, if required.

Press **✓** to select and confirm a function.

Once a main menu page is selected, this selection remains stored until another main menu page is selected. Subpages are changed by pressing  $\nabla$  or  $\Delta$ .

Vehicle and service messages are popped-up in the Driver Information Centre if required. Confirm messages by pressing **√**. Vehicle messages ⇒ 125.

# Uplevel display



#### Main menus are:

- Trip/fuel information, displayed by Info, see description below.
- Audio information, displayed by Audio, see description below.
- Phone information, displayed by Phone, see description below.
- Navigation information, displayed by Navigation, see description below.
- Vehicle information, displayed by Options, see description below.

Some of the displayed functions differ when the vehicle is being driven or at a standstill and some functions are only active when the vehicle is being driven.

Uplevel instrument cluster can be displayed as Sport mode or Tour mode. See below: Settings Menu, Display Themes.

#### Selecting menus and functions

The menus and functions can be selected via the buttons on the right side of the steering wheel.



Press  $\triangleleft$  to open main menu page. Select a main menu page with  $\Delta$  or  $\nabla$ . Confirm a main menu page with  $\checkmark$ .

Once a main menu page is selected, press  $\Delta$  or  $\nabla$  to select subpages.

Press > to open the next folder of the selected subpage.

Press  $\Delta$  or  $\nabla$  to select functions or to set a numeric value, if required.

Press **✓** to select and confirm a function.

Once a main menu page is selected, this selection remains stored until another main menu page is selected. Subpages are changed by pressing  $\nabla$  or  $\Delta$ .

Vehicle and service messages are popped-up in the Driver Information Centre if required. Confirm messages by pressing **√**. Vehicle messages ⇒ 125.

# Trip/fuel information menu, /:\ or Info

The following list contains all possible Info Menu pages. Some may not be available for your particular vehicle. Depending on the display some functions are symbolised.

Turn the adjuster wheel or press ∆ or ▼ to select a page:

- trip odometer 1 or A average fuel consumption 1 or A average speed 1 or A
- trip odometer 2 or B average fuel consumption 2 or B average speed 2 or B
- digital speed
- fuel range
- instantaneous fuel consumption
- remaining oil life
- tyre pressure
- timer
- traffic sign assistant
- following distance
- blank page

On Baselevel display, the pages Remaining Oil Life, Tyre Pressure, Traffic Sign Assistant and Following Distance are displayed in the Vehicle information menu, select by pressing **MENU**.

#### Trip odometer 1/A or 2/B

Trip odometer displays the current distance since a certain reset.

Trip odometer counts up to a distance of 9,999 km then restarts at 0.

To reset on Baselevel display, press **SET/CLR** for a few seconds, on Midlevel and Uplevel display, press **▶** and confirm with **√**.

The information of trip odometer page 1 and 2 can be reset separately for odometer, average consumption and average speed while the respective display is active.

# Average fuel consumption 1/A or 2/B

Display of average consumption. The measurement can be reset at any time and starts with a default value.

To reset on Baselevel display, press SET/CLR for a few seconds, on Midlevel and Uplevel display, press 
▶ and confirm with ✔.

#### Average speed 1/A or 2/B

Display of average speed. The measurement can be reset at any time.

To reset on Baselevel display, press **SET/CLR** for a few seconds, on Midlevel and Uplevel display, press **▶** and confirm with **√**.

## Digital speed

Digital display of the instantaneous speed.

#### Fuel range

Range is calculated from current fuel tank level and current consumption. The display shows average values.

After refuelling, the range is updated automatically after a brief delay.

When the fuel level in the tank is low, a message appears on the display and control indicator  $\blacksquare$  in the fuel gauge illuminates.

When the tank must be refuelled immediately, a warning message appears and remains on the display. Additionally, control indicator ▶ in the fuel gauge flashes ▷ 112.

# Instantaneous fuel consumption

Display of the instantaneous consumption.

#### Remaining oil life

Indicates an estimate of the oil's useful life. The number in % means the remaining of current oil life ♀ 106.

#### Tyre pressure

#### Timer

To start and stop press **✓**. To reset, press **⊳** and confirm Reset.

### Traffic sign assistant

Displays the detected traffic signs for the current route section  $\diamondsuit$  224.

#### Following distance

Displays the distance in seconds to a preceding moving vehicle ♥ 202. If Adaptive cruise control is active this page shows the following distance setting instead.

### Blank page

A blank page can be selected when no DIC information is requested.

### Eco information menu.



- Top consumers
- Economy trend
- Fco index

On Mid- and Uplevel display the pages Top Consumers, Economy Trend and Eco index, are displayed in the Trip/fuel information menu, select Info.

#### **Top Consumers**

List of top comfort consumers currently switched on is displayed in descending order. Fuel saving potential is indicated.

During sporadic driving conditions, the engine will activate the heated rear window automatically to increase the engine load. In this event, the heated rear window is indicated as one of the top consumers, without activation by the driver.

# **Economy Trend**



Displays the average consumption development over a distance of 50 km. Filled segments display the consumption in 5 km steps and shows the effect of topography or driving behaviour on fuel consumption.

## **Economy index**

The average fuel consumption is indicated on an economic scale. For economical driving, adapt driving style to keep the indicator within the green area. The more the indicator moves towards red, the higher is the fuel consumption. Simultaneously the average consumption value is indicated.

Depending on vehicle version, the Eco Index shows values referring to trip odometer page A/1 or the current driving cycle. In the last case, the indicator is reset when ignition is switched on the next time

#### Audio menu

Audio menu enables browsing for music, selecting from favourites or changing the audio source.

See Infotainment manual.

#### Phone menu

Phone menu enables managing and performing of phone calls, scrolling through contacts or operating handsfree phoning.

See Infotainment manual.

# Navigation menu

Navigation menu enables route guidance.

See Infotainment manual.

# Vehicle information menu, *⇐* or Options

The following list contains all possible Options Menu pages. Some may not be available for your particular vehicle. Depending on the display some functions are symbolised.

Turn the adjuster wheel or press  $\Delta$  or  $\nabla$  to select a page and follow the instructions given in the submenus:

- units
- display themes
- info pages
- speed warning
- tyre loading
- pocket gauges
- software information

#### Units

Press ➤ while units page is displayed. Select imperial or metric units by pressing **v**.

### Display themes

Press ➤ while display themes is displayed. Select Sport or Touring mode by pressing **v**. Sport mode

includes more vehicle information, Tour mode includes more media information.

This setting is only available with Uplevel display.

#### Info pages

Press ➤ while Info pages is displayed. A list of all items in the Info Menu is displayed. Select the functions to be displayed in the Info page by pressing ✓. Selected pages have a ✓ in a checkbox. Non viewable functions have a blank checkbox. See Info Menu above.


### Speed warning

The speed warning display allows you to set a speed that you do not want to exceed.

To set the speed warning, press ► while the page is displayed. Press Δ or ∇ to adjust the value. Press ✔ to set the speed. Once the speed is set, this feature can be turned off by pressing ✔ while viewing this page. If the selected speed limit is exceeded, a pop-up warning is displayed with a chime.

#### Tyre loading

## Pocket gauges



### Battery voltage

Displays the vehicle battery voltage. During engine running voltage can vary between 12 V and 15.5 V. Temporary voltage below 12 V is possible when high electrical load is used.

#### Engine oil temperature

Displays engine oil temperature in degrees Celsius.

#### Software information

Displays the open source software information.

# Info Display

The Info-Display is located in the instrument panel near the instrument cluster.

Depending on the vehicle configuration the vehicle has a

- 7" Colour-Info-Display with touchscreen functionality or
- 8" Colour-Info-Display with touchscreen functionality

The Info displays can indicate:

- outside temperature ⇒ 93
- Infotainment system, see description in the Infotainment manual

- parking assist instructions
   ⇒ 209

- navigation, see description in the Infotainment manual
- system messages

## 7" Colour-Info-Display

#### Selecting menus and settings

Menus and settings are accessed via the display.



Press  $\odot$  to switch on the display.

Press  $\stackrel{\scriptscriptstyle d}{\hookrightarrow}$  to display the homepage.

Touch required menu display icon with the finger.

Touch a respective icon to confirm a selection.

Touch to return to the next higher menu level.

Press degree to return to the homepage.

For further information, see Infotainment manual.

# 8" Colour-Info-Display

#### Selecting menus and settings

There are three options to operate the display:

- via buttons below the display
- by touching the touchscreen with the finger
- via speech recognition

### **Button operation**



Press  $\odot$  to switch on the display.

Press  $\stackrel{\scriptscriptstyle d}{\scriptscriptstyle 
m \square}$  to display the homepage.

Press **BACK** to exit a menu without changing a setting.

For further information, see Infotainment manual.

### Touchscreen operation

Display must be switched on by pressing ∅. Press ຝ to select homepage.

Touch required menu display icon or select a function with the finger.

Scroll a longer submenu list with the finger up or down.

Confirm a required function or selection by touching.

Touch • on the display to exit a menu without changing a setting.

Press  $\stackrel{\triangle}{=}$  to return to the homepage.

For further information, see Infotainment manual.

### Speech recognition

Description see Infotainment manual.

## Valet mode

If activated, some functions of the Driver Information Centre and the Info-Display are limited. The load compartment is being locked and cannot be unlocked.

For more information, see Infotainment manual.

# Head-up display

The head-up display shows driver information concerning the instrument cluster onto the windscreen on the driver's side.

The information appears as an image projected from a lense in the instrument panel onto the windscreen directly ahead in driver's view. The image appears focused out toward the front of the vehicle.

Depending on the equipment headup display can indicate:

- general driving information
- alerts from driver assistance systems
- automatic transmission selector lever position
- gear shift indication
- audio/phone information
- turn-by-turn navigation information if equipped with navigation infotainment.



There are three controls above the light switch to operate the head-up display.

# Display views

Different views are selectable in the head-up display by pressing INFO button. Each press will change the display view.



# Speed view

Indicates

- speedometer: digital indication of speed
- traffic signs: indication of speed limits

#### Performance View

Indicates

- speedometer: digital indication of speed
- tachometer: engine speed in round per minute

- automatic transmission: selector lever position
- manual/automatic transmission: gear shift indication

#### Audio view

Indicates

- speedometer: digital indication of speed
- actual audio playing information

# Navigation view

Indicates

- speedometer: digital indication of speed
- turn-by-turn navigation information

## Active safety control indicators

On all views control indicators of following Driver assistance systems are indicated in the top line of the display

- vehicle detected ahead 
   ←:
   vehicle recognition
- lane keep assist A: status and warning

- adaptive cruise control 701: set speed and status
- pedestrian detected ahead ★: pedestrian recognition

#### Pop-up alerts

The following list contains just an extract of possible alerts. Some may not be available for your particular vehicle, others can appear depending on vehicle configuration.

Alerts pop-up on each page if required

- pedestrian protection alert
- forward collision alert
- up-/downshift alert
- incoming call

Alerts with lower priority can be reset by pressing  $\checkmark$ , high priority alerts appear as long as danger continues. System messages or vehicle warnings may require immediately action. Seek the assistance of a workshop.

# Adjust position of head-up display image

- 1. Adjust the driver's seat.
- 2. Start the engine.
- Press down or lift up button 
   <sup>®</sup> to centre the image. It can only be adjusted up and down, not side to side.

# **△**Warning

If the head-up display image is too bright or too high in your field of view, it may obstruct your view when it is dark outside. Be sure to keep the head-up display image dim and placed low in your field of view.

# Adjust brightness

The head-up display image will automatically dim and brighten to compensate for outside lighting. Brightness can also be adjusted manually as needed:

Lift up to and hold to brighten the display. Press down and hold to dim the display.

The image can temporarily light up depending on angel and position of sunlight.

## Switching off

Hold down ± to turn the head-up display off.

## Language

Preferred language can be set in vehicle personalisation menu \$\display\$ 127.

#### Units

Units can be changed in the settings menu of the Driver Information Centre 

⇒ 114.

# Care of head-up display

Clean the inside of the windscreen as needed to remove any dirt or film that could reduce the sharpness or clarity of the head-up image.

Clean the head-up display lens in the instrument panel with a soft cloth sprayed with glass cleaner. Wipe the lens gently, then dry it.

## **System limitations**

Head-up display may not operate properly when:

- The lens in the instrument panel is covered by objects or windscreen and lens are not clean.
- Display brightness is too dim or bright.
- Image is not adjusted to the proper height.
- The driver wears polarised sunglasses.

If the head-up image is not correct for other reasons, contact a workshop.

The windscreen is part of the head-up display system. Windscreen replacement ♦ 40.

# Vehicle messages

Messages are indicated in the Driver Information Centre, in some cases together with a warning and signal buzzer.



On Baselevel display press **SET/CLR** on the turn signal lever to confirm a message.



On Midlevel and Uplevel display, press **✓** to confirm a message.

## Vehicle and service messages

The vehicle messages are displayed as text. Follow the instructions given in the messages.

# Messages in the Colour-Info-Display

Some important messages may appear additionally in the Colour-Info-Display. Press the multifunction knob to confirm a message. Some messages only popup for a few seconds.

# Warning chimes

# When starting the engine or whilst driving

Only one warning chime will sound at a time.

The warning chime regarding not fastened seat belts has priority over any other warning chime.

- If seat belt is not fastened.
- If a door or the tailgate is not fully closed when starting off.
- If a certain speed is exceeded with parking brake applied.
- If adaptive cruise control deactivates automatically.
- If approaching a vehicle ahead too closely.
- If approaching a pedestrian ahead too closely.
- If a programmed speed or speed limit is exceeded.
- If a warning message appears in the Driver Information Centre.
- If the electronic key is not in the passenger compartment.

- If the parking assist detects an object.
- If an unintended lane change occurs.
- If the diesel particle filter has reached the maximum filling level.

# When the vehicle is parked and/or the driver's door is opened

- With exterior lights on.
- If the trailer hitch is not engaged.

# **During an Autostop**

- If the driver's door is opened.
- If any condition for an Autostop is not fulfilled.

# Battery voltage

When the vehicle battery voltage is running low, a warning message will appear in the Driver Information Centre.

- Switch off any electrical consumers which are not required for a safe ride, e.g. seat heating, heated rear window or other main consumers.
- Charge the vehicle battery by driving continuously for a while or by using a charging device.

The warning message will disappear after the engine has been started twice without a voltage drop.

If the vehicle battery cannot be recharged, have the cause of the fault remedied by a workshop.

# Vehicle personalisation

The vehicle's behaviour can be personalised by changing the settings in the Info-Display.

Some of the personal settings for different drivers can be memorised individually for each vehicle key. Memorised settings ▷ 25.

Depending on vehicle equipment and country-specific regulations some of the functions described below may not be available.

Some functions are only displayed or active when the engine is running.

## Personal settings

## 7" Colour-Info-Display

Press ♣, select **Settings** and then **Vehicle** on the touch-screen.



In the corresponding submenus the following settings can be changed:

#### Vehicle

Climate & Air Quality

**Auto Fan Max Speed**: Modifies the level of the cabin airflow of the climate control in automatic mode.

#### **Auto Heated Seats:**

Automatically activates the seat heating.

Auto Defog: Supports windscreen dehumidification by automatically selecting the necessary settings and automatic air conditioning mode. **Auto Rear Defog**: Automatically activates heated rear window.

Collision / Detection Systems

Rear View Camera Guidelines: Activates or deactivates the rear view camera guidelines on the Info Display.

#### Forward Collision Alert:

Activates or deactivates forward collision alert.

## **Auto Collision Preparation:**

Activates or deactivates the automatic brake functionality of the vehicle in the event of imminent collision danger. The following is selectable: the system will take over brake control, warn by chimes only or is deactivated completely.

## Forward Collision System:

Changes the settings of forward collision alert.

#### Front pedestrian protection:

Activates or deactivates and changes the settings of the front pedestrian protection.

#### Rear Cross Traffic Alert: Activates or deactivates rear cross traffic alert.

Park Assist: Activates or deactivates the ultrasonic parking assist. Activation is selectable with or without attached trailer coupling.

**Go Notifier**: Activates or deactivates the reminder to drive off when the adaptive cruise control holds the vehicle at standstill.

Side Blind Zone Alert: Activates or deactivates side blind zone alert.

#### Comfort and Convenience

**Auto Memory Recall**: Changes the settings to the recall of memorised settings for power seat adjustment.

Easy Exit Driver Seat: Activates or deactivates easy exit function of the power seat.

**Chime Volume**: Changes the volume of warning chimes.

**Reverse Tilt Mirror**: Activates or deactivates the parking assist function of the exterior mirrors.

**Auto Mirror Folding**: Activates or deactivates folding of the exterior mirrors with the remote control.

Personalization By Driver: Activates or deactivates the personalisation function.

Rain Sense Wipers: Activates or deactivates automatic wiping with rain sensor.

Auto Wipe in Reverse Gear: Activates or deactivates automatic switching on of the rear window wiper when reverse gear is engaged.

Extended Hill Start Assist: Toggles between hill start assist and extended hold hill start assist

## Lighting

**Vehicle Locator Lights**: Activates or deactivates the entry lighting.

Exit Lighting: Activates or deactivates and changes the duration of exit lighting.

**Left or Right Hand Traffic**: Changes between lighting for left or right-hand traffic.

Adaptive Forward Lighting: Changes the settings of the functions of the LED headlights.

#### Power Door Locks

Unlocked Door Anti Lock Out: Activates or deactivates the door locking function while a door is open.

**Auto Door Lock**: Activates or deactivates the automatic door locking function after switching on ignition.

**Delayed Door Lock**: Activates or deactivates the delayed door locking function. This feature delays the actual locking of the doors until all doors are closed.

Remote Lock, Unlock, Start
 Remote Unlock Light Feedback:
 Activates or deactivates the hazard warning flasher feedback whilst unlocking.

Remote Lock Feedback: Changes what kind of feedback is given when locking the vehicle. Remote Door Unlock: Changes the configuration to unlock only the driver's door or the whole vehicle whilst unlocking.

Relock Remotely Unlocked Doors: Activates or deactivates the automatic relock function after unlocking without opening the vehicle

Remote Window Operation: Activates or deactivates the operation of power windows with electronic key.

Passive Door Unlock: Changes the configuration to unlock only the driver's door or the whole vehicle whilst unlocking.

Passive Door Lock: Activates or deactivates the passive locking function. This feature locks the vehicle automatically after several seconds if all doors have been closed and an electronic key has been removed from the vehicle.

Remote Left in Vehicle Alert: Activates or deactivates the warning chime when the electronic key remains in the vehicle.

# Personal settings

## 8" Colour-Info-Display

Press  $\stackrel{\triangle}{=}$  then select the **SETTINGS** icon.



In the corresponding submenus the following settings can be changed:

#### Vehicle

Climate and Air Quality

Auto Fan Speed: Modifies the level of the cabin airflow of the climate control in automatic mode.

#### **Auto Heated Seats:**

Automatically activates the seat heating.

Auto Demist: Supports windscreen dehumidification by automatically selecting the necessary settings and automatic air conditioning mode.

**Auto Rear Demist**: Automatically activates heated rear window.

Collision / Detection Systems

Forward Collision Alert: Activates or deactivates forward collision alert.

### **Auto Collision Preparation:**

Activates or deactivates the automatic brake functionality of the vehicle in the event of imminent collision danger. The following is selectable: the system will take over brake control, warn by chimes only or is deactivated completely.

Forward Collision System: Changes the settings of forward collision alert.

Front pedestrian protection: Activates or deactivates and

changes the settings of the front pedestrian protection.

Rear Cross Traffic Alert: Activates or deactivates rear cross traffic alert.

Park Assist: Activates or deactivates the ultrasonic parking assist. Activation is selectable with or without attached trailer coupling.

**Go Notifier**: Activates or deactivates the reminder function of the adaptive cruise control.

Side Blind Zone Alert: Activates or deactivates side blind zone alert.

#### Comfort and Convenience

Auto Memory Recall: Changes the settings to the recall of memorised settings for power seat adjustment.

Easy Exit Driver Seat: Activates or deactivates easy exit function of the power seat.

**Chime Volume**: Changes the volume of warning chimes.

**Reverse Tilt Mirror**: Activates or deactivates the parking assist function of the exterior mirrors.

**Auto Mirror Folding**: Activates or deactivates folding of the exterior mirrors with the remote control.

Personalisation by Driver: Activates or deactivates the personalisation function.

Rainsense Wipers: Activates or deactivates automatic wiping with rain sensor.

Auto Wipe in Reverse Gear: Activates or deactivates automatic switching on of the rear window wiper when reverse gear is engaged.

Extended Hill-Start Assist: Toggles between hill start assist and extended hold hill start assist

## Lighting

**Vehicle Locator Lights**: Activates or deactivates the entry lighting.

Exit Lighting: Activates or deactivates and changes the duration of exit lighting.

**Left or Right Hand Traffic:** Changes between lighting for left or right-hand traffic.

Adaptive Forward Lighting: Changes the settings of the functions of the LED headlights.

#### Power Door Locks

**Unlocked Door Anti-Lockout**: Activates or deactivates the door locking function while a door is open.

**Auto Door Lock**: Activates or deactivates the automatic door locking function after switching on ignition.

**Delayed Door Lock**: Activates or deactivates the delayed door locking function. This feature delays the actual locking of the doors until all doors are closed.

Remote Lock, Unlock, Start
 Remote Unlock Light Feedback:
 Activates or deactivates the hazard warning flasher feedback whilst unlocking.

### Remote Lock Feedback: Changes what kind of feedback is given when locking the vehicle.

Remote Door Unlock: Changes the configuration to unlock only the driver's door or the whole vehicle whilst unlocking.

# Relock Remote Unlocked Doors: Activates or deactivates the automatic relock function after

automatic relock function after unlocking without opening the vehicle.

### **Remote Window Operation:**

Activates or deactivates the operation of power windows with electronic key.

Passive Door Unlock: Changes the configuration to unlock only the driver's door or the whole vehicle whilst unlocking.

Passive Door Lock: Activates or deactivates the passive locking function. This feature locks the vehicle automatically after several seconds if all doors have been closed and an electronic key has been removed from the vehicle.

Remote Left in Vehicle Alert: Activates or deactivates the warning chime when the electronic key remains in the vehicle.

## **Telematics** service

### **OnStar**

OnStar is a personal connectivity and service assistant with integrated Wi-Fi hotspot. The OnStar service is available 24 hours a day, seven days a week.

#### Note

OnStar is not available for all markets. For further information, contact your workshop.

#### Note

In order to be available and operational, OnStar needs a valid OnStar subscription, functioning vehicle electrics, mobile service and GPS satellite link.

To activate the OnStar services and set up an account, press 
and speak with an advisor.

Depending on the equipment of the vehicle, the following services are available:

- Emergency services and support in the case of a vehicle breakdown
- Wi-Fi hotspot
- Smartphone application
- Remote control, e.g. location of the vehicle, activation of horn and lights, control of central locking system
- Stolen vehicle assistance
- Vehicle diagnostics
- Destination download

#### Note

The OnStar module of the vehicle is deactivated after ten days without an ignition cycle. Functions requiring a data connection will be available again after switching on the ignition.

#### OnStar buttons



#### Privacy button

Press and hold  $\$  until a message is heard to activate or deactivate the transmission of the vehicle location.

Press ® to answer a call or to end a call to an advisor.

Press ® to access the Wi-Fi settings.

#### Service button

Press 

to establish a connection to an advisor.

#### SOS button

Press 

to establish a priority emergency connection to a specially trained emergency advisor.

#### Status LED

Green: The system is ready with activated transmission of the vehicle location.

Green flashing: The system is on a call.

Red: A problem arose.

Off: The system is ready with deactivated transmission of the vehicle location or the system is in standby mode.

Red / green flashing for a short period of time: The transmission of the vehicle location has been deactivated.

#### OnStar services

#### General services

If you need any information e.g. opening hours, points of interest and destinations or if you need any support e.g. in the case of a vehicle

breakdown, a flat tyre and empty fuel tank, press 

to establish a connection to an advisor.

#### **Emergency services**

In the case of an emergency situation, press ⊕ and talk to an advisor. The advisor then contacts emergency or assistance service providers and directs them to your vehicle.

In the case of an accident with activation of airbags or belt tensioners, an automatic emergency call is established. The advisor is immediately connected to your vehicle to see whether help is needed.

#### Note

Establishing an emergency call may not be possible in areas without sufficient network availability or due to hardware damage during an accident.

#### Wi-Fi hotspot

The Wi-Fi hotspot of the vehicle provides internet connectivity with a maximum speed of 4G/LTE.

#### Note

The Wi-Fi hotspot functionality is not available for all markets.

#### Note

Some mobile devices connect to Wi-Fi hotspots automatically and use mobile data capacity in the background, even if they are not in use. This includes automatic updates, downloads, as well as programme or app synchronisation traffic. The data volume purchased via OnStar might be consumed rapidly. Turn off automatic synchronisations in the settings of your device.

Up to seven devices may be connected.

To connect a mobile device with the Wi-Fi hotspot:

- Press ® and then select Wi-Fi settings on the Info-Display. The settings displayed include the Wi-Fi hotspot name (SSID), password and connection type.
- 2. Start a Wi-Fi network search on your mobile device.

- 3. Select your vehicle hotspot (SSID) when listed.
- 4. When prompted, enter the password on your mobile device.

#### Note

To change the SSID or password, press 
and talk to an advisor or log in to your account.

To switch off the Wi-Fi hotspot functionality, press 
to call an advisor.

## Smartphone app

With the myOpel smartphone app, some vehicle functions can be operated remotely.

The following functions are available:

- Lock or unlock vehicle.
- Honk horn or flash lights.
- Check fuel level, engine oil life and tyre pressure (only with tyre pressure monitoring system).
- Send navigation destination to the vehicle, if equipped with a built-in navigation system.
- Locate vehicle on a map.
- Manage Wi-Fi settings.

134

To operate these functions, download the app from App Store® or Google Play™ Store.

#### Remote control

If desired, use any phone to call an advisor, who can remotely operate specific vehicle functions. Find the respective OnStar phone number on our country-specific website.

The following functions are available:

- Lock or unlock vehicle.
- Provide information on the vehicle location.
- Honk horn or flash lights.

#### Stolen vehicle assistance

If the vehicle is stolen, report the theft to the authorities and request OnStar stolen vehicle assistance. Use any phone to call an advisor. Find the respective OnStar phone number on our country-specific website.

OnStar can provide support in locating and recovering the vehicle.

#### Theft alert

When the anti-theft alarm system is triggered, a notification is sent to OnStar. You are then informed about this event by text message or email.

#### Restart prevention

By sending remote signals, OnStar can prevent the vehicle from restarting once it has been turned off.

### On-demand diagnostics

At any time e.g. if the vehicle displays a vehicle message, press @ to contact an advisor and ask to complete a real-time diagnostic check to directly determine the issue. Depending on the results, the advisor will provide further support.

### Diagnostic report

The vehicle automatically transmits diagnostic data to OnStar which sends a monthly email report to you and your preferred workshop.

#### Note

The workshop notification function can be disabled in your account.

The report contains the status of key operating systems of the vehicle like engine, transmission, airbags, ABS, and other major systems. It also provides information on possible maintenance items and tyre pressure (only with tyre pressure monitoring system).

To look at the information in greater detail, select the link within the email and log in to your account.

#### Destination download

A desired destination can be directly downloaded to the navigation system.

Press @ to call an advisor and describe the destination or point of interest.

The advisor can look up any address or point of interest and directly send the destination to the built-in navigation system.

# OnStar settings

#### **OnStar PIN**

To have full access to all OnStar services, a four-digit PIN is required. The PIN has to be personalised when first talking to an advisor.

To change the PIN, press 
to call an advisor.

#### Account data

An OnStar subscriber has an account where all the data is stored. To request a change of the account information, press 
and talk to an advisor or log in to your account.

If the OnStar service is used on another vehicle, press 
and request that the account be transferred to the new vehicle.

#### Note

In any case, if the vehicle is disposed of, sold or otherwise transferred, immediately inform OnStar about the changes and terminate the OnStar service on this vehicle.

#### Vehicle location

The vehicle location is transmitted to OnStar when service is requested or triggered. A message on the Info-Display informs about this transmission.

To activate or deactivate the transmission of the vehicle location, press and hold ® until an audio message is heard.

The deactivation is indicated by the status light flashing red and green for a short period of time and each time the vehicle is started.

#### Note

If the transmission of the vehicle location is deactivated, some services are no longer available.

#### Note

The vehicle location always remains accessible to OnStar in the case of an emergency.

Find the privacy policy in your account.

#### Software updates

OnStar may remotely carry out software updates without further notice or consent. These updates are to enhance or maintain safety and security or the operation of the vehicle.

These updates may concern privacy issues. Find the privacy policy in your account.

# Lighting

Exterior lighting 136
Light switch 136
Automatic light control 137
High beam 137
High beam assist 137
Headlight flash 139
Headlight range adjustment 139
Headlights when driving
abroad 139
Daytime running lights 140
LED headlights140
Hazard warning flashers 143
Turn lights 143
Front fog lights 144
Rear fog light144
Parking lights 144
Reversing lights 145
Misted light covers 145
•
Interior lighting
Instrument panel illumination
control
Interior lights
Reading lights
Sunvisor lights 147

Lighting features	14
Centre console lighting	14
Entry lighting	14
Exit lighting	14
Battery discharge protection	14

# Exterior lighting

# Light switch



## Turn light switch:

**AUTO**: automatic light control

switches automatically between daytime running

light and headlight

⇒ ≤ : sidelights**§D** : headlights

When switching on the ignition, automatic light control is active.

Control indicator **>**€ ♦ 112.

## Tail lights

Tail lights are illuminated together with low/high beam and sidelights.

# Automatic light control



When the automatic light control function is switched on and the engine is running, the system switches between daytime running lights and headlights automatically depending on the external lighting conditions and information given by the wiper system.

## Automatic headlight activation

During poor lighting conditions headlights are switched on.

Additionally, headlights are switched on if the windscreen wipers have been activated for several wipes.

#### **Tunnel detection**

When a tunnel is entered, headlights are switched on immediately.

# High beam



Push lever to switch from low to high beam.

Pull lever to deactivate high beam. High beam assist \$\displays 140.

# High beam assist

This feature allows the high beam to function as the main driving light at night and when vehicle speed is faster than 40 km/h.


It switches automatically to low beam when:

- A sensor detects the lights of oncoming or preceding vehicles.
- Driving in urban areas.
- The vehicle speed is slower than 20 km/h.
- It is foggy or snowy.
- Front or rear fog lights are switched on.

If there are no restrictions detected, the system switches back to high beam

### Activation

# Turn signal lever with MENU button



The high beam assist is activated by pushing the turn signal lever twice at a speed above 40 km/h.

## Turn signal lever with **≣**® button



The green control indicator **E** illuminates continuously when the assist is activated, the blue one **E** illuminates when high beam is on.

Control indicator **E © ○** 112

#### Deactivation

With high beam on, pull the turn signal lever once to deactivate high beam assist. If a headlight flash is activated when the high beam is off, the high beam assist will remain activated.

Pushing the indicator lever to activate manual high beam will deactivate high beam assist. It is also deactivated when fog lights are switched on.

Turn signal lever with **MENU** button: when high beam is off, push indicator lever twice to deactivate high beam assist.

Turn signal lever with ≣ button: press ≣ once to deactivate high beam assist.

The latest setting of the high beam assist is being stored and remains set when the ignition is switched on again.

# Headlight flash



To activate the headlight flash, pull lever.

Pulling lever deactivates high beam. LED headlights ♦ 140.

# Headlight range adjustment

# Manual headlight range adjustment



To adapt headlight range to the vehicle load to prevent dazzling: push and then turn to to required position.

0: front seats occupied

1: all seats occupied

2: all seats occupied and load compartment laden

3 : driver's seat occupied and load compartment laden

# Headlights when driving abroad

The asymmetrical headlight beam extends visibility at the edge of the road at the passenger side.

However, when driving in countries where traffic drives on the opposite side of the road, adjust the headlights to prevent dazzling of oncoming traffic.

# Vehicles with halogen headlight system

The headlights do not have to be adjusted.

## Vehicles with LED headlight

Headlights can be set for driving on the opposite side of the road in the vehicle personalisation menu via the Info-Display.

Select the relevant setting in **Settings**,

Vehicle.

# 140 Lighting

Every time the ignition is switched on, § flashes for approx. four seconds as a reminder.

To deactivate, use the same procedure as described above. F will not flash when function is deactivated.

Control indicator ₹ \$ 112.

# Daytime running lights

Daytime running lights increase visibility of the vehicle during daylight.

They are switched on automatically during daytime when engine is running.

The system switches between daytime running lights and headlights automatically, depending on the lighting conditions. Automatic light control ▷ 137.

# **LED** headlights

LED headlight system contains a variety of particular LEDs in each headlight which enables the control of different lighting programs.

Light distribution and intensity of light are variably triggered depending on the lighting conditions, road type and driving situation. The vehicle adapts the headlights automatically to the situation to enable optimal light performance for the driver.

Some functions of the LED headlights can be deactivated or activated in the vehicle personalisation menu. Select the relevant setting in **Settings**, **▶ Vehicle** in the Info-Display. Vehicle personalisation ♀ 127.

High beam assist can not be deactivated.

The following lighting functions are available with light switch in position AUTO or **§**D.

## Town light



Activated automatically at a speed up to approx. 55 km/h and in situations with exterior ambient light. The light is wide and symmetrical. A special beam pattern is designed to avoid glare for other road users.

## Country light



Activated automatically at a speed above approx. 55 km/h when driving in rural areas. The illumination of the current lane and the side of the road is improved. Oncoming and preceding vehicles are not dazzled.

# Curve light



Particular LEDs, based on steering angle and speed, are additionally triggered to improve lighting in curves. This function is activated at speeds from 40 km/h to 70 km/h and reacts to steering angle.

## Corner light



When turning off, depending on the steering angle and the turn signal light, particular LEDs are triggered which illuminate the direction of travel. It is activated up to a speed of 40 km/h.

# Reverse parking function

To assist driver's orientation when parking, both corner lights and reversing light illuminate when headlights are on and reverse gear is engaged. They remain illuminated for a short time after disengaging reverse gear or until driving faster than 7 km/h in a forward gear.

# High beam assist

This feature allows the high beam to function as main driving light at night.

The camera in the windscreen detects the lights of oncoming or preceding vehicles. Each LED on right or left side can be triggered or faded out particularly according to the traffic situation. This gives the best light distribution without dazzling other road users. Once activated, high beam assist remains active and switches high beam on and off depending on surrounding conditions. The latest setting of the high beam assist will remain after the ignition is switched on again.



High beam assist includes a special motorway mode. When driving faster than 115 km/h on motorways, the light beam becomes smaller to avoid dazzling of oncoming traffic. When following vehicles ahead or passing, mirror dazzling for these vehicles is reduced.

# Activation Indicator lever with MENU button



# 142 Lighting

Activate high beam assist by pushing the indicator lever twice. High beam is switched on automatically at a speed above 50 km/h. High beam is switched off at a speed below 35 km/h, but high beam assist remains active.

#### Indicator lever with **I** button



Activate high beam assist by pressing once. High beam is switched on automatically at a speed above 50 km/h. High beam is switched off at a speed below 35 km/h, but high beam assist remains active.

The green control indicator **⑤** illuminates continuously when the high beam assist is activated, the blue one **⑤** illuminates when high beam is on.

Control indicator **⑤** ♀ 112, **⑤** ♀ 112.

Pressing indicator lever once switches on manual high beam without high beam assist.

High beam assist switches automatically to low beam when:

- Driving in urban areas.
- Camera detects heavy fog.
- Front or rear fog lights are switched on.

If there are no restrictions detected, the system switches back to high beam.

#### Deactivation

# Indicator lever with or without MENU button

If high beam assist is active and high beam is on, pull indicator lever once to deactivate high beam assist. If high beam assist is active and high beam is off, push indicator lever twice to deactivate high beam assist.

Pushing the indicator lever to activate manual high beam will also deactivate high beam assist.

#### Indicator lever with **■** button

If high beam assist is active and high beam is on, press ≣o once or pull indicator lever once to deactivate high beam assist.

If high beam assist is active and high beam is off, press **■** once to deactivate high beam assist.

Pushing the indicator lever to activate manual high beam will also deactivate high beam assist.

# Headlight flash in conjunction with high beam assist

Headlight flash by pulling indicator lever once will not deactivate high beam assist when high beam is off.

Headlight flash by pulling indicator lever once deactivates high beam assist when high beam is on.

# Dynamic automatic headlight levelling

To prevent oncoming traffic from being dazzled, headlight levelling is automatically adjusted based on inclination information measured by front and rear axle, acceleration or deceleration and vehicle speed.

# 

# Fault in LED headlight system

When the system detects a failure in the LED headlight system, it selects a preset position to avoid dazzling of oncoming traffic. A warning is displayed in the Driver Information Centre.


# Hazard warning flashers

Operated by pressing  $\triangle$ .



In the event of an accident with airbag deployment, the hazard warning flashers are activated automatically.

# Turn lights



lever up : right turn signal lever down : left turn signal

A resistance point can be felt when moving the lever.

Constant flashing is activated when the lever is being moved beyond the resistance point. It is deactivated when the steering wheel is moved in the opposite direction or lever is manually moved back to its neutral position.

# 144 Lighting

Activate temporary flashing by holding the lever just before the resistance point. Turning lights will flash until lever is being released.

To activate three flashes, tap the lever briefly without passing the resistance point. With a trailer connected, the turn signal flashes six times and tone frequency changes.

# Front fog lights



Operated by pressing \$0.
Light switch in position **AUTO**:
switching on front fog lights will switch
headlights on automatically.

# Rear fog light



Operated by pressing 0\$.

Light switch in position **AUTO**: switching on rear fog light will switch headlights on automatically.

Light switch in position **>**€: rear fog light can only be switched on with front fog lights.

The vehicle rear fog light is deactivated when towing a trailer or a plug is connected with the socket, e. g. when a bicycle carrier is used.

# Parking lights



When the vehicle is parked, the parking lights on one side can be activated:

- 1. Switch off ignition.
- Move turn signal lever all the way up (right parking lights) or down (left parking lights).

Confirmed by a signal and the corresponding turn signal control indicator.

# Reversing lights

The reversing light comes on when the ignition is on and reverse gear is selected.

# Misted light covers

The inside of the light housing may mist up briefly in poor, wet and cold weather conditions, in heavy rain or after washing. The mist disappears quickly by itself; to help switch on the headlights.

# Interior lighting

# Instrument panel illumination control



Brightness of the following lights can be adjusted in position AUTO when the light sensor detects night conditions, or in position ≫ or ■D.

- instrument panel illumination
- Info-Display
- illuminated switches and operation elements

Push and then turn of until the desired brightness is obtained.

# Interior lights

During entry and exit of the vehicle, the front and rear courtesy lights automatically switch on and then off after a delay.

#### Note

In the event of an accident with airbag deployment the courtesy lights are turned on automatically.

# Front courtesy light



press 來 on/off : interior lights are switched on or off manually

press ••••off : interior lights are not automatically switched on when a door is opened. Deactivation is indicated by a LED in the switch.



# Rear courtesy lights

Illuminate in conjunction with the front courtesy light.

# Reading lights



Operated by pressing the respective reading light.



Illustration shows rear reading light.

# **Sunvisor lights**

Illuminates when the cover is opened.

# Lighting features

# Centre console lighting

Spotlight incorporated in the interior lighting comes on when headlights are switched on.

# Entry lighting

## Welcome lighting

The following lights are switched on for a short time by unlocking the vehicle with the electronic key:

- headlights
- puddle lights in both outside mirrors
- tail lights
- number plate lights
- instrument panel light
- interior lights

Some functions are only operable when it is dark outside to facilitate locating the vehicle.

The lighting switches off immediately when the ignition is switched on. Starting off  $\diamondsuit$  18.

This function can be activated or deactivated in the vehicle personalisation.

Select the relevant setting in **Settings**,

**♦ Vehicle** in the Info-Display.

The settings can be saved for the key being used  $\diamondsuit$  25.

The following lights will additionally switch on when the driver's door is opened:

- illumination of some switches
- Driver Information Centre
- door pocket lights

# **Exit lighting**

The following lights will switch on when the ignition is switched off:

- interior lights
- instrument panel light
- puddle lights in both outside mirrors

# 148 Lighting

They will switch off automatically after a delay. This function works only in the dark. Theatre lighting is activated if the driver's door is opened during this time.

# Path lighting

Headlights, tail lights and number plate lights illuminate the surrounding area for an adjustable time after leaving the vehicle.

## Activating Halogen headlights



- 1. Switch off the ignition.
- 2. Open the driver's door.

- 3. Pull the turn signal lever.
- 4. Close the driver's door.

If the driver's door is not closed, the lights switch off after two minutes.

Exit lighting is switched off immediately if the turn signal lever is pulled while the driver's door is open.

#### LED headlights

Path lighting is activated, when the ignition is switched off and the driver's door is opened.

This function can be activated or deactivated in the vehicle personalisation.

Select the relevant setting in **Settings**, **Vehicle** in the Info-Display.

The settings can be saved for the key being used ♦ 25.

# Battery discharge protection

# Vehicle battery state of charge function

The function guarantees longest vehicle battery life via a generator with controllable power output and optimised power distribution.

To prevent discharge of the vehicle battery when driving, the following systems are reduced automatically in two stages and finally switched off:

- auxiliary heater
- heated rear and front window
- heated steering wheel
- heated mirrors
- heated seats
- fan

In the second stage, a message which confirms the activation of the vehicle battery discharge protection will be displayed in the Driver Information Centre.

# Switching off electric lights

To prevent discharge of the vehicle battery when the ignition is switched off, some interior lights are switched off automatically after some time.

# Climate control

Climate control systems	
systemAuxiliary heater	
Air vents	159
Maintenance	
operation	

# Climate control systems

# Air conditioning system



Illustration shows functions which may not be available for your particular vehicle.

#### Controls for:

- Fan speed ₩
- Temperature **TEMP**
- Air distribution \*, \* and \*.
- Air conditioning A/C
- Demisting and defrosting
- Air recirculation
- External air ≈

- Heated rear window and exterior mirrors
- Heated windscreen
- Heated seats ₩

Some changes of settings are indicated briefly in the Info-Display. Activated functions are indicated by the LED in the respective button.

# Fan speed %

Adjust the air flow by turning % to the desired speed.

clockwise : increase anti-clockwise : decrease

### **Temperature TEMP**

Adjust the temperature by turning **TEMP** to the desired temperature.

red area : warmer blue area : colder

Heating will not be fully effective until the engine has reached normal operating temperature.

#### Air distribution 🕏 💤 🚧

#### Press:

- : to windscreen and front door windows
- : to head area and rear seats via adjustable air vents
- : to front and rear foot well and windscreen

Combinations are possible.

# Air conditioning A/C



Press **A/C** to switch on cooling. Activation is indicated by the LED in the button. Cooling is only functional when the engine is running and climate control fan is switched on.

Press **A/C** again to switch off cooling.

The air conditioning system cools and dehumidifies (dries) as soon as the outside temperature is slightly above the freezing point. Therefore condensation may form and drip from under the vehicle.

If no cooling or drying is required, switch off the cooling system for fuel saving reasons.

Activated cooling may inhibit Autostops. Stop-start system ▷ 167.

# Demisting and defrosting the windows



- Press :: fan automatically switches to higher speed, the air distribution is directed towards the windscreen.
- Set temperature controller TEMP to warmest level.
- Switch on air conditioning A/C if required.
- Switch on heated rear window .....
- Switch on heated windscreen if available.

- Open side air vents as required and direct them towards the door windows.
- For maximum demisting and defrosting set fan speed to highest level.

#### Note

If m is pressed while the engine is running, an Autostop will be inhibited until m is pressed again.

### Air recirculation system 🖘



Press so to activate air recirculation mode, LED is indicated.

Select air recirculation to assist in cooling the interior or in blocking outside odours or exhaust.

Press again to deactivate air recirculation mode.

On version without heated windscreen, press ≈ to deactivate air recirculation. External air mode is activated.

# **△**Warning

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up from inside. The quality of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

In warm and very humid ambient air conditions, the windscreen may mist up from outside when cold air is directed towards it. If windscreen mists up from outside, activate windscreen wiper and deactivate ♥.

#### External air mode



Press \$\simeta\$ to activate external air mode, LED is indicated.

Press so to activate air recirculation mode. External air mode is deactivated.

### Maximum cooling



Briefly open the windows so that hot air can disperse quickly.

- Switch on air conditioning A/C.
- Press so for air recirculation system on.
- Press \* for air distribution.
- Set temperature control **TEMP** to coldest level.
- Set fan speed \$\mathscr{G}\$ to highest level.
- Open all vents.

# Version with heated windscreen



If the vehicle is equipped with heated windscreen, button so is replaced by button so.

# Heated rear window and exterior mirrors

\$ 42

#### Heated windscreen @

\$ 42.

#### Heated seats ₩

\$ 54.

# Electronic climate control system

The dual zone climate control allows different temperatures for driver side and front passenger side.

In automatic mode, temperature, fan speed and air distribution are regulated automatically.



Illustration shows functions which may not be available for your particular vehicle.

#### Controls for:

- Control dial for temperature on driver side
- Control dial for temperature on passenger side
- CLIMATE enters the Climate setting menu in the Info-Display
- Fan speed increase \* and decrease \*
- Climate control ON/OFF or ♥orr
- Automatic mode AUTO
- Manual air recirculation
- Demisting and defrosting \( \mathbb{Z} \)
- Heated rear window and exterior mirrors
- Heated windscreen
- Heated seats ₩
- Ventilated seats ≝

Activated functions are indicated by the LED in the respective control.

The electronic climate control system is only fully operational when the engine is running.

### Climate setting menu CLIMATE



#### Settings for

- Air distribution 📆 📆 😼
- Fan speed ₩
- Temperature for driver and passenger side 23°/25°
- Dual zone temperature synchronisation SYNC
- Air conditioning ON/OFF

can be triggered manually in the Climate setting menu. Press **CLIMATE** to enter the menu and follow the touch buttons.

Climate setting menu can also be displayed by touching button ● in the Info-Display ▷ 121.

Changes of settings via the controls are indicated as pop up in the Info-Display.

#### Automatic mode AUTO



Basic settings for automatic control with maximum comfort:

- Press AUTO, the air distribution and fan speed are regulated automatically.
- Open all air vents to allow optimised air distribution in automatic mode.

- Cooling must be activated in the climate setting menu for optimal cooling and demisting. Press Climate to enter the menu and follow the touch button to switch on air conditioning A/C.
- Set the preselected temperatures separately for driver and front passenger using the left and right control dials. Recommended temperature is 22 °C. Temperature is indicated briefly in displays beside the control dials and in the climate setting menu.
- Air recirculation mode should be deactivated. When deactivated the LED in the button is not illuminated.

## Manual settings

Climate control system settings can be changed by activating the following functions as described below.

#### Fan speed ê \*



Press upper button  $\hat{*}$  to increase or lower button  $\hat{*}$  to decrease fan speed. The fan speed is indicated as pop-up in the Info Display. Fan speed can also be changed by touch buttons in the climate setting display. Press **Climate** to enter the menu.

Pressing the lower button \* for longer: fan and cooling are switched off.

To return to automatic mode press **AUTO**.

#### Air distribution ♥, ネ, \*,



Press **Climate** to enter the menu. Touch:

: to windscreen and front door windows

: to head area and rear seats via adjustable air vents

: to front and rear foot well and windscreen

To return to automatic air distribution press **AUTO**.

# Temperature preselection



Set the preselected temperatures separately for driver and front passenger to the desired value using the left and right control dials. The knob on the passenger side changes the temperature for the passenger side. The knob on the driver's side changes the temperature for the driver's side or for both sides depending on activation of synchronisation **SYNC**. Recommended temperature is 22 °C.

Temperature is indicated in displays

beside the control dials and as pop-

up in the Info-Display.

If the minimum temperature **Lo** is set, the climate control system runs at maximum cooling, if cooling **A/C** is switched on.

If the maximum temperature **Hi** is set, the climate control system runs at maximum heating.

#### Note

If A/C is switched on, reducing the set cabin temperature can cause the engine to restart from an Autostop or inhibit an Autostop.

# Dual zone temperature synchronisation SYNC

Press **Climate** to enter the menu. Touch SYNC to link passenger side temperature setting to the driver side. When passenger side control dial will be adjusted, synchronisation is deactivated.

## Air conditioning A/C



Press **Climate** to enter the menu and follow the touch button to switch air conditioning A/C ON or A/C OFF.

Cooling is only functional when the engine is running and climate control fan is switched on.

The air conditioning system cools and dehumidifies (dries) when outside temperature is above a specific level. Therefore condensation may form and drip from under the vehicle.

If no cooling or drying is required, switch off the cooling system for fuel saving reasons.

#### Manual air recirculation 🖘



Press so to activate the air recirculation mode. The LED in the button illuminates to indicate activation.

Press again to deactivate recirculation mode.

# **△**Warning

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up from inside.

The quality of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

In warm and very humid ambient air conditions, the windscreen may mist up from outside, when cold air is directed towards it. If windscreen mists up from outside, activate windscreen wiper and deactivate \$\mathbb{F}\$.

#### Automatic air recirculation

An air humidity sensor switches automatically to external air if internal air humidity is too high.

#### 



- Press 

  . The LED in the button illuminates to indicate activation.
- Temperature and air distribution are set automatically and the fan runs at high speed.
- Switch on air conditioning A/C ON in Climate setting menu by pressing Climate, if required.

- Switch on heated windscreen w if available
- To return to previous mode press again, to return to automatic mode press AUTO.

#### Note

If  $\mathbf{x}$  is pressed while the engine is running, an Autostop will be inhibited until m is pressed again.

If a is pressed while the engine is in an Autostop, the engine will restart automatically.

#### Deactivation or activation of Electronic climate control system ON/OFF



Cooling, fan and automatic mode can be switched off by pressing ON/OFF. When the system is deactivated, the LED in the button **ON/OFF** is not illuminated.

Activation by pressing ON/OFF again or **AUTO**. The LED in the button illuminates to indicate activation.

## Version with heated windscreen @



If the vehicle is equipped with heated windscreen, button ON/OFF is 

Climate control system will then switched off by button \$ orf. Switch on by pressing \( \hat{\varphi} \).

### **Basic settings**

Following settings can be changed in the Personalisation menu in the Info-Display:

- fan speed regulation in automatic mode.
- settings of automatic rear window heating.
- settings of automatic windscreen dehumidification
- settings of automatic seat heating

# Heated rear window and exterior mirrors

\$ 42

#### Heated windscreen @

\$ 42.

## Heated seats ₩

\$ 54.

#### Ventilated seats \*/

\$ 54

# **Auxiliary heater**

#### Air heater

Quickheat is an electric auxiliary air heater which automatically warms up the passenger compartment more quickly.

# Air vents

# Adjustable air vents

At least one air vent must be open while cooling is on.



Illustration shows centre air vents in instrument panel.



Illustration shows outer air vents in instrument panel.



Illustration shows air vents for rear passenger.

Direct the flow of air by tilting and swivelling the slats.

To close the vent, swivel the slat sideways.

# **△**Warning

Do not attach any objects to the slats of the air vents. Risk of damage and injury in case of an accident.

# Fixed air vents

Additional air vents are located beneath the windscreen and door windows and in the foot wells.

# Maintenance

### Air intake



The air intake in front of the windscreen in the engine compartment must be kept clear to allow air intake. Remove any leaves, dirt or snow.

#### Cabin air filter

Change filter regulary for maximum effect.

# Air conditioning regular operation

In order to ensure continuously efficient performance, cooling must be operated for a few minutes once a month, irrespective of the weather and time of year. Operation with cooling is not possible when the outside temperature is too low.

## Service

For optimal cooling performance, it is recommended to annually check the climate control system, starting three years after initial vehicle registration, including:

- functionality and pressure test
- heating functionality
- leakage check
- check of drive belts
- cleaning of condenser and evaporator drainage
- performance check
- · cabin air filter check

# Driving and operating

Driving hints	
Control of the vehicle	163
Steering	
Starting and operating	
New vehicle running-in	163
Power button	164
Retained power off	165
Starting the engine	
Overrun cut-off	
Stop-start system	
Parking	169
Engine exhaust	170
Diesel particle filter	170
Catalytic converter	171
AdBlue	172
Automatic transmission	175
Manual transmission	179
Drive systems	180
All-wheel drive	180
Brakes	180
Antilock brake system	
Parking brake	

Brake assist	. 182
Hill start assist	. 183
Ride control systems	. 184
Traction Control system	. 184
Electronic Stability Control	. 185
Interactive driving system	. 186
Driver assistance systems	
Cruise control	. 189
Speed limiter	
Adaptive cruise control	
Forward collision alert	
Following distance indication	
Active emergency braking	
Front pedestrian protection	
Parking assist	
Side blind spot alert	
Lane change alert	
Panoramic view system	. 219
Rear view camera	
Rear cross traffic alert	
Traffic sign assistant	
Lane keep assist	. 229
Fuel	. 231
Fuel for petrol engines	
Fuel for diesel engines	. 232
Refuelling	. 233
Trailer hitch	
General information	. 235

Driving characteristics and	
towing tips	235
Trailer towing	235
Towing equipment	
Trailer stability assist	

# **Driving hints**

#### Control of the vehicle

# Never coast with engine not running

Many systems will not function in this situation (e.g. brake servo unit, power steering). Driving in this manner is a danger to yourself and others.

All systems function during an Autostop.

#### Idle boost

If charging of the vehicle battery is required due to battery condition, the power output of the generator must be increased. This will be achieved by an idle boost which may be audible.

A message appears in the Driver Information Centre.

#### **Pedals**

To ensure the pedal travel is uninhibited, there must be no mats in the area of the pedals.

Use only floor mats, which fit properly and are fixed by the retainers on the driver side.

# Steering

If power steering assist is lost because the engine stops or due to a system malfunction, the vehicle can be steered but may require increased effort.

# Starting and operating

# New vehicle running-in

Do not brake unnecessarily hard for the first few journeys.

During the first drive, smoke may occur because of wax and oil evaporating off the exhaust system. Park the vehicle in the open for a while after the first drive and avoid inhaling the fumes.

During the running-in period, fuel and engine oil consumption may be higher.

Additionally, the cleaning process of the diesel particle filter may take place more often.

Diesel particle filter \$\phi\$ 170.

Autostop may be inhibited to allow for charging of the vehicle battery.

# Power button



Electronic key must be inside the vehicle.

## Accessory power mode

Press Engine Start/Stop once without operating clutch or brake pedal. The yellow LED in the button illuminates. Steering wheel lock is released and some electrical functions are operable, ignition is off.

#### Ignition on power mode

Press and hold **Engine Start/Stop** for six seconds without operating clutch or brake pedal. The green LED in the button illuminates, diesel engine is

preheating. Control indicators illuminate and most electrical functions are operable.

#### Engine start

Press Engine Start/Stop briefly while:

- manual transmission: operating clutch pedal,
- automatic transmission: operating brake pedal with selector lever in P or N.

Starting the engine ♦ 165.

# Ignition off

Press Engine Start/Stop briefly when Autostop is activated or when engine is running and vehicle is stationary. Automatic transmission: apply the parking brake and engage P.

Press **Engine Start/Stop** briefly without operating clutch or brake pedal when in ignition on power mode.

Some functions remain active until driver's door is opened, provided the ignition was on previously.

# Emergency engine shut off during driving

Press Engine Start/Stop for more than two seconds or press twice briefly within five seconds ▷ 165.

# Steering wheel lock

The steering wheel lock activates automatically when:

- The vehicle is stationary.
- The ignition has been switched off.
- The driver's door is opened.

To release steering wheel lock, open and close driver's door and switch on accessory mode or start the engine directly.

# **△**Warning

If the vehicle battery is discharged, the vehicle must not be towed, tow-started or jump-started as the steering wheel lock cannot be disengaged.

# Operation on vehicles with electronic key system in case of failure

If either the electronic key fails or the battery of the electronic key is weak, the Driver Information Centre may display No Remote Detected or Replace Battery in Remote Key when you try to start the vehicle.



Open the cover of the centre console in front of the gear shift lever. Place the electronic key across with buttons upside in the transmitter pocket beside the power outlet, as shown in the illustration. Other objects, e.g. other keys, transponder, tags, coins etc. must be removed from the pocket.

Depress the clutch pedal (manual transmission), the brake pedal and press **Engine Start/Stop**. Release the button after starting procedure begins.

To switch off the engine, press **Engine Start/Stop** again. Remove the electronic key from the transmitter pocket.

This option is intended for emergencies only. Replace the electronic key battery as soon as possible ♀ 22.

# Retained power off

The following electronic systems can work until the driver's door is opened or for 10 minutes after the ignition is switched off:

- power windows
- sunroof
- power outlets

# Starting the engine

# Vehicles with power button



Manual transmission: operate clutch and brake pedal.

Automatic transmission: operate brake pedal and move selector lever to **P** or **N**.

Do not operate accelerator pedal.

Press **Engine Start/Stop** briefly: an automatic procedure operates the starter with a short delay until the engine is running.

To switch off the engine when vehicle is stationary, press

**Engine Start/Stop** briefly. Automatic transmission: apply the parking brake and engage **P**.

To start the engine during an Autostop:

Automatic transmission: during an Autostop, the engine can be started by releasing the brake pedal ▷ 167.

# Emergency engine shut off during driving

If the engine needs to be switched off during driving in case of emergency, press **Engine Start/Stop** for more than two seconds or press twice briefly within five seconds.

# ⚠Danger

Switching off the engine during driving may cause loss of power support for brake and steering systems. Assistance systems and airbag systems are disabled. Lighting and brake lights will extinguish. Therefore power down the engine and ignition while driving only when required in case of emergency.

# Starting the vehicle at low temperatures

Starting the engine without additional heaters is possible down to -25 °C for diesel engines and -30 °C for petrol engines. Required is an engine oil with the correct viscosity, the correct fuel, performed services and a sufficiently charged vehicle battery. With temperatures below -30 °C the automatic transmission requires a warming phase of approx. five minutes. The selector lever must be in position **P**.

#### **Automatic Starter Control**

This function controls the engine starting procedure. The driver does not need to hold **Engine Start/Stop** pressed. Once applied, the system will go on starting automatically until the engine is running. Because of the checking procedure, the engine starts running after a short delay.

Possible reasons for a non-starting engine:

- Clutch pedal not operated (manual transmission).
- Brake pedal not operated or selector lever not in P or N (automatic transmission).
- Timeout occurred.

## Turbo engine warm-up

Upon start-up, engine available torque may be limited for a short time, especially when the engine temperature is cold. The limitation is to allow the lubrication system to fully protect the engine.

## Overrun cut-off

The fuel supply is automatically cut off during overrun, i.e. when the vehicle is driven with a gear engaged but accelerator pedal is released.

Depending on driving conditions, the overrun cut-off may be deactivated.

# Stop-start system

The stop-start system helps to save fuel and to reduce the exhaust emissions. When conditions allow, it switches off the engine as soon as the vehicle is at a low speed or at a standstill, e.g. at a traffic light or in a traffic jam.

#### Activation

The stop-start system is available as soon as the engine is started, the vehicle starts-off and the conditions as stated below in this section are fulfilled.

#### Deactivation



Deactivate the stop-start system manually by pressing . Deactivation is indicated when the LED in the button illuminates.

# Autostop

Vehicles with manual transmission An Autostop can be activated at a standstill or at a low speed up to 14 km/h. Activate a conventional Autostop as follows:

- Depress the clutch pedal.
- Set the lever to neutral.
- Release the clutch pedal.

The engine will be switched off while the ignition stays on.

#### Indication



An Autostop is indicated by the needle at the **AUTOSTOP** position in the tachometer.

After restarting, the idle speed is indicated.

During an Autostop, the heating and brake performance will be maintained.

#### Conditions for an Autostop

The stop-start system checks if each of the following conditions is fulfilled:

- The stop-start system is not manually deactivated.
- The bonnet is fully closed.
- The driver's door is closed or the driver's seat belt is fastened.
- The vehicle battery is sufficiently charged and in good condition.
- The engine is warmed up.
- The engine coolant temperature is not too high.
- The engine exhaust temperature is not too high, e.g. after driving with high engine load.
- The ambient temperature is above -5 °C.
- The climate control system allows an Autostop.
- The brake vacuum is sufficient.

- The self-cleaning function of the diesel particle filter is not active.
- The vehicle was driven at least at walking speed since the last Autostop.

Otherwise an Autostop will be inhibited.

The stop-start system will be deactivated on inclines of 12% or more.

Certain settings of the climate control system may inhibit an Autostop. See Climate control chapter for more details № 150.

Immediately after motorway driving, an Autostop may be inhibited.

New vehicle running-in ♦ 163.

#### Vehicle battery discharge protection

To ensure reliable engine restarts, several battery discharge protection features are implemented as part of the stop-start system.

### Power saving measures

During an Autostop, several electrical features e.g. auxiliary electric heater or heated rear window are disabled or

switched to a power saving mode. The fan speed of the climate control system is reduced to save power.

# Restart of the engine by the driver

# Vehicles with manual transmission Conventional restart

All engines have conventional restart.

Depress the clutch pedal without depressing the brake pedal to restart the engine.

On engines with late restart a conventional restart is only possible without depressed brake pedal.

#### Late restart

All engines have late restart in addition to conventional restart. Late restart is only active on gradients up to 5%.

- Depress the brake pedal.
- Depress the clutch pedal.
- Select first gear.
- Release the brake pedal to restart the engine.

Vehicles with automatic transmission Release the brake pedal or move selector lever out of **D** into **N** or **P** to restart the engine.

# Restart of the engine by the stopstart system

The selector lever must be in neutral to enable an automatic restart.

If one of the following conditions occurs during an Autostop, the engine will be restarted automatically by the stop-start system:

- The stop-start system is manually deactivated.
- The bonnet is opened.
- The driver's seat belt is unfastened and the driver's door is opened.
- The engine temperature is too low.
- The charging level of the vehicle battery is below a defined level.
- The brake vacuum is not sufficient.
- The vehicle is driven at least at walking speed.

- The climate control system requests an engine start.
- The air conditioning is manually switched on.

If the bonnet is not fully closed, a warning message is displayed in the Driver Information Centre.

If an electrical accessory, e.g. a portable CD player, is connected to the power outlet, a brief power drop during the restart might be noticeable.

# **Parking**

## **△**Warning

- Do not park the vehicle on an easily ignitable surface. The high temperature of the exhaust system could ignite the surface.
- Always apply the parking brake. Pull switch (P) for approx. one second and check if the control indicator (P) illuminates.

The electric parking brake is applied when control indicator 
⑤ illuminates ▷ 109.

- Switch off the engine.
- If the vehicle is on a level surface or uphill slope, engage first gear or set the selector lever to position P before switching off ignition. On an uphill slope, turn the front wheels away from the kerb.

If the vehicle is on a downhill slope, engage reverse gear or set the selector lever to position **P** before switching off ignition. Turn the front wheels towards the kerb.

- Close the windows and the sunroof.
- Switch off ignition with power button. Turn the steering wheel until the steering wheel lock is felt to engage.

- Lock the vehicle with button on the door handle.
- Activate the anti-theft alarm system.
- The engine cooling fans may run after the engine has been switched off \$\triangle\$ 241.

#### Caution

After running at high engine speeds or with high engine loads, operate the engine briefly at a low load or run in neutral for approx. 30 seconds before switching off, in order to protect the turbocharger.

#### Note

In the event of an accident with airbag deployment, the engine is turned off automatically if the vehicle comes to a standstill within a certain time.

# Engine exhaust

# **⚠** Danger

Engine exhaust gases contain poisonous carbon monoxide, which is colourless and odourless and could be fatal if inhaled.

If exhaust gases enter the interior of the vehicle, open the windows. Have the cause of the fault rectified by a workshop.

Avoid driving with an open load compartment, otherwise exhaust gases could enter the vehicle.

# Diesel particle filter

# Automatic cleaning process

The diesel particle filter system filters harmful soot particles out of the exhaust gases. The system includes a self-cleaning function that runs automatically during driving without any notification. The filter is cleaned by periodically burning off the soot particles at high temperature. This process takes place automatically under set driving conditions and may take up to 25 minutes. Typically it needs between seven and twelve minutes. Autostop is not available and fuel consumption may be higher during this period. The emission of smells and smoke during this process is normal.

# System requires cleaning process

Under certain driving conditions, e.g. short distances, the system cannot clean itself automatically.

If cleaning of the filter is required and if previous driving conditions did not enable automatic cleaning, it will be

indicated by illumination of 

and a warning message in the Driver Information Centre.

- illuminates along with a warning message illuminates when diesel particle filter is full. Start cleaning process as soon as possible.
- flashes along with a warning message when diesel particle filter has reached the maximum filling level. Start cleaning process immediately to avoid damage to the engine.

# Activate self-cleaning process

To activate cleaning process, continue driving, keep engine speed above 2000 rpm. Shift down if necessary. Diesel particle filter cleaning is then started.

Cleaning takes place quickest at high engine speeds and loads.

Control indicator 
end extinguishes as soon as the self-cleaning operation is complete. Keep on driving until self-cleaning operation is complete.

#### Caution

If possible, do not interrupt cleaning process. Drive until cleaning is completed to avoid the need for service or repair by a workshop.

# Cleaning process not possible

If cleaning is not possible for any reasons, control indicator calculates and a warning message appears in the Driver Information Centre. Engine power may be reduced. Seek the assistance of a workshop immediately.

# Catalytic converter

The catalytic converter reduces the amount of harmful substances in the exhaust gases.

#### Caution

Fuel grades other than those listed on pages \$\phi\$ 231, \$\phi\$ 294 could damage the catalytic converter or electronic components.

Unburnt petrol will overheat and damage the catalytic converter. Therefore avoid excessive use of the starter, running the fuel tank dry and starting the engine by pushing or towing.

In the event of misfiring, uneven engine running, a reduction in engine performance or other unusual problems, have the cause of the fault rectified by a workshop as soon as possible. In an emergency, driving can be continued for a short period, keeping vehicle speed and engine speed low.

#### **AdBlue**

#### General information

The selective catalytic reduction (BlueInjection) is a method to substantially reduce the nitrogen oxides in the exhaust emission. This is achieved by injecting a Diesel Exhaust Fluid (DEF) into the exhaust system. The ammonia released by the fluid reacts with nitrous gases (NO<sub>x</sub>) from the exhaust and turns it into nitrogen and water.

The designation of this fluid is AdBlue <sup>®</sup>. It is a non-toxic, non-flammable, colourless and odourless fluid which consists of 32% urea and 68% water.

# **△**Warning

Avoid contact of your eyes or skin with AdBlue.

In case of eye or skin contact, rinse off with water.

#### Caution

Avoid contact of the paintwork with AdBlue.

In case of contact, rinse off with water.

AdBlue freezes at a temperature of approx. -11 °C. As the vehicle is equipped with an AdBlue pre-heater, the emissions reduction at low temperatures is ensured. The AdBlue pre-heater works automatically.

The typical AdBlue consumption is approx. two litres per 1000 km, but can also be higher depending on driving behaviour (e.g. high load or towing).

#### AdBlue tank

At a remaining volume of approx. five litres, there is a liquid level switch. Warning messages are displayed only below that threshold. Tank volume \$\phi\$ 303.

## Level warnings

Depending on the calculated range of AdBlue, different messages are displayed in the Driver Information Centre. The messages and the restrictions are a legal requirement.

The first possible warning is **AdBlue Range: 2400 km**.

This warning will show up once briefly with the calculated range. Driving is possible without any restrictions.

The next warning level is entered with a range below 1750 km. The message with the current range will always be displayed when ignition is switched on and needs to be confirmed ▷ 114. Refill AdBlue before entering the next warning level.

At an AdBlue range below 900 km, the following warning messages are alternately displayed and cannot be dismissed:

- AdBlue Low Refill Now
- Engine Restart Prevented in 900 km.

Additionally, control indicator  $\stackrel{*}{\simeq}$  flashes continuously.

#### Note

In case of high AdBlue consumption, the Driver Information Centre may display this warning without the previous warning stages.

The last warning level is entered when the AdBlue tank is empty. Restart of the engine is not possible. The following warning messages are alternately displayed and cannot be dismissed:

- AdBlue Empty Refill Now
- Engine Will Not Restart.

Additionally, control indicator \(\text{\text{\text{\text{\text{d}}}}}\) flashes continuously.

With active prevention of an engine start, the following message will be displayed:

#### Refill AdBlue To Start Vehicle.

The tank must be refilled completely with AdBlue, otherwise restarting of the engine is not possible.

\$ 303

# High emission warnings

If the exhaust emission rises above a certain value, warnings similar to the range warnings will be displayed in the Driver Information Centre.

Requests to have the exhaust system checked and finally the announcement of the prevention of an engine restart are displayed. These restrictions are a legal requirement.

Consult a workshop for assistance.

## Refilling AdBlue

#### Caution

Only use AdBlue that complies with European standards DIN 70 070 and ISO 22241-1.

Do not use additives.

Do not dilute AdBlue.

Otherwise the selective catalytic reduction system could be damaged.

#### Note

Whenever a filling pump with a nozzle for passenger cars is not available at a filling station, use only AdBlue bottles or canisters with a sealed refill adapter for refilling, to prevent splashback and overspill, and in order to ensure that the fumes from the tank are captured and do not emerge. AdBlue in bottles or canisters is available in many filling stations and can be purchased e.g. at Opel dealers and other retail outlets

Since AdBlue has a limited durability, check the date of expiry before refilling.

#### Note

The refilling of AdBlue is only detected by the system when the above mentioned liquid level switch in the tank is activated.

In case AdBlue refill is not successfully detected:

- 1. Continuously drive the vehicle for 10 minutes making sure that vehicle speed is always higher than 20 km/h
- 2. If AdBlue refill is detected successfully, AdBlue supplydriven limitations will disappear.

If AdBlue refill is still not detected. seek the assistance of a workshop.

If AdBlue must be refilled at temperatures below -11 °C, the refilling of AdBlue may not be detected by the system. In this event, park the vehicle in a space with a higher ambient temperature until AdBlue is liquefied.

#### Note

When unscrewing the protective cap from the filler neck, ammonia fumes may emerge. Do not inhale as the fumes have a pungent smell. The fumes are not harmful by inhalation.

The AdBlue tank should be filled completely. This must be done if the warning message regarding prevention of an engine restart is already displayed.

The vehicle must be parked on a level surface.

The filler neck for AdBlue is located behind the fuel filler flap, which is located at right rear side of the vehicle

The fuel filler flap can only be opened if the vehicle is unlocked.

- 1. Remove key from ignition switch.
- 2. Close all doors to avoid ammonia fumes entering the interior of the vehicle
- 3. Release the fuel filler flap by pushing the flap \$\infty\$ 233.



4. Unscrew protective cap from the filler neck.

- 5. Open AdBlue canister.
- 6. Mount one end of the hose on the canister and screw the other end on the filler neck.
- 7. Lift the canister until it is empty, or until the flow from the canister has stopped. This can take up to five minutes.
- 8. Place the canister on the ground to empty the hose, wait 15 seconds.
- 9. Unscrew the hose from the filler neck.
- 10. Mount the protective cap and turn clockwise until it engages.

#### Note


Dispose of AdBlue canister according to environmental requirements. Hose can be reused after flushing with clear water before AdBlue dries out

# **Automatic transmission**


The automatic transmission permits automatic gear shifting (automatic mode) or manual gear shifting (manual mode).

Manual shifting is possible in manual mode by tapping the selector lever to + or - or pulling the steering wheel paddles.

# Transmission display



Illustrations show different versions.



The mode or selected gear is shown in the Driver Information Centre.

In automatic mode, the driving programme is indicated by  ${\bf D}$ .

In manual mode,  ${\bf M}$  and the number of the selected gear is indicated.

R indicates reverse gear.

**N** indicates neutral position.

**P** indicates park position.

#### Selector lever



P: park position, wheels are locked, engage only when the vehicle is stationary

R: reverse gear, engage only when the vehicle is stationary

N : neutral

**D**: automatic mode **M**: manual mode

+ : upshift in manual mode

: downshift in manual mode



The selector lever is locked in **P** and can only be moved when the ignition is on, the release button on the selector lever is pushed and the brake pedal is applied.

Without brake pedal applied, control indicator (S) illuminates.

If the selector lever is not in **P** when the ignition is switched off, control indicator (S) flashes.

To engage **P** or **R**, press the release button.

The engine can only be started with lever in position **P** or **N**. When position **N** is selected, press brake pedal or apply parking brake before starting.

Do not accelerate while engaging a gear. Never depress the accelerator pedal and brake pedal at the same time.

When a gear is engaged, the vehicle begins to creep when the brake is released.

# **Engine braking**

To utilise the engine braking effect, select a lower gear in good time when driving downhill, see manual mode.

## Rocking the vehicle


Rocking the vehicle is only permissible if the vehicle is stuck in sand, mud or snow. Move the selector lever between **D** and **R** in a repeat pattern. Do not race the engine and avoid sudden acceleration.

# **Parking**

Apply the parking brake and engage **P**.

#### Manual mode

#### Selector lever



Move selector lever out of position **D** towards the left in position **M**.

Manual mode **M** can be activated from position **D** in each driving situation and speed.

Tap selector lever upwards + to shift to a higher gear.

Tap the selector lever downwards - to shift to a lower gear.

The selected gear is indicated in the instrument cluster.

### Steering wheel paddles



Move selector lever out of position  ${\bf D}$  towards the left in position  ${\bf M}$ .

Manual mode **M** can be activated from position **D** in each driving situation and speed.

Pull steering wheel paddles to select gears manually.

Pull right paddle + to shift to a higher gear.

Pull left paddle - to shift to a lower gear.

Multiple pulls allow gears to be skipped.

The selected gear is indicated in the instrument cluster.

# Temporary manual mode in drive mode D

Manual paddle shifting is also possible in automatic mode **D**. Upon completion of manual shifting operation, transmission changes to automatic mode **D** after a defined time.

To interrupt manual mode and return to **D**, do one of the following:

- Press + paddle for 1 second.
- Move selector lever towards the left to manual mode and back to position D.

If the vehicle is at a standstill and engine is idling, the transmission will remain in temporary manual mode. It changes to automatic mode when accelerator pedal is operated for a defined time, and no paddle shifting at the steering wheel is performed.

#### General

If a higher gear is selected when vehicle speed is too low, or a lower gear when vehicle speed is too high, the shift is not executed. This can cause a message in the Driver Information Centre.

In manual mode, no automatic shifting to a higher gear takes place at high engine revolutions, except activating the kickdown function.

#### Gear shift indication

The symbol ▲ or ▼ with a number beside it is indicated when gear shifting is recommended for fuel saving reasons.

Shift indication appears only in manual mode.

#### Electronic driving programmes

- Following a cold start, the operating temperature programme increases engine speed to quickly bring the catalytic converter to the required temperature.
- When SPORT mode is engaged, the vehicle shifts at higher engine speeds (unless cruise control is on). SPORT mode 

  ↑ 186.

- Special programmes automatically adapt the shifting points when driving up inclines or down hills.
- In snowy or icy conditions or on other slippery surfaces, the electronic transmission control enables the driver to manually select first, second or third gear for starting off.

#### Kickdown

Pressing down the accelerator pedal beyond the kickdown detent will lead to maximum acceleration even in manual mode. The transmission shifts to a lower gear depending on engine speed and shifts to a higher gear at high engine revolutions.

#### Overheat protection

In the event of transmissionoverheating due to high outside temperatures or sporty driving style. the torque and the maximum speed of the engine can be temporarily reduced.

#### Fault

In the event of a fault a vehicle message is displayed in the Driver Information Centre, Vehicle 

6-gear automatic transmission: electronic transmission control enables only fourth gear; 8-gear automatic transmission: electronic transmission control enables only third gear. The transmission no longer shifts automatically.

Have the cause of the fault remedied by a workshop.

## Interruption of power supply

In the event of an interruption of power supply, the selector lever cannot be moved out of the P position.


If the vehicle battery is discharged, start the vehicle using jump leads \$ 278.

If the vehicle battery is not the cause of the fault, release the selector lever.

1. Apply parking brake.



2. Release the selector lever trim. from the centre console. Poke with a finger into the leather socket beside the selector lever and pull the trim up carefully, there is a cable attached to it. Slide trim slightly forward as it is hinged on its rear side. Tilt loose trim to the left side to aviod tensioning the cable.



- Insert a small stick (e.g. a pen or screwdriver) into the opening near the selector lever. Push down the stick vertically and move the selector lever out of P. If this position is engaged again, the selector lever will be locked again. Have the cause of the power supply interruption remedied by a workshop.
- 4. Mount the selector lever trim onto the centre console and refit.

## Manual transmission



To engage reverse, depress the clutch pedal and then press the release button on the selector lever and engage the gear.

If the gear does not engage, set the lever to neutral, release the clutch pedal and depress again; then repeat gear selection.

Do not slip the clutch unnecessarily. When operating, depress the clutch pedal completely. Do not use the pedal as a foot rest.

When clutch slip is detected for a specific time, the engine power will be reduced. A warning is displayed in the Driver Information Centre. Release the clutch.

#### Caution

It is not advisable to drive with the hand resting on the selector lever.

## **Drive systems**

#### All-wheel drive

The All-wheel drive system enhances driving characteristics and stability, and helps to achieve the best possible driveability regardless of ground surface. The system is always active and cannot be deactivated.

The torque is distributed steplessly between the wheels of the front and rear axle up to a torque split of 50% to 50%. Depending on the driving conditions, i.e. steady state driving, All wheel drive system transfers a minimum amount of torque for fuel efficiency. Additionally the torque vectoring between the rear wheels is distributed depending on the vehicle dynamic and surface.

This is possible because the All wheel drive system operates with two clutches, one on each side.

For optimum system performance, the vehicle's tyres should not have varying degrees of wear. If a service message is displayed in the Driver Information Centre, the system may have limited functionality (or be completely disabled in some cases, i.e. the vehicle switches to Front-wheel drive). Seek the assistance of a workshop.

## **Brakes**

The brake system comprises two independent brake circuits.

If a brake circuit fails, the vehicle can still be braked using the other brake circuit. However, braking effect is achieved only when the brake pedal is depressed firmly. Considerably more force is needed for this. The braking distance is extended. Seek the assistance of a workshop before continuing the journey.

When the engine is not running, the support of the brake servo unit disappears once the brake pedal has been depressed once or twice. Braking effect is not reduced, but braking requires significantly greater force. It is especially important to bear this in mind when being towed.

## Antilock brake system

Antilock brake system (ABS) prevents the wheels from locking.

ABS starts to regulate brake pressure as soon as a wheel shows a tendency to lock. The vehicle remains steerable, even during hard braking.

ABS control is made apparent through a pulse in the brake pedal and the noise of the regulation process.

For optimum braking, keep the brake pedal fully depressed throughout the braking process, despite the fact that the pedal is pulsating. Do not reduce the pressure on the pedal.

After starting off, the system performs a self-test which may be audible.



Control indicator (®) \$\Display\$ 110.

## Adaptive brake light

During full braking, all three brake lights flash for the duration of ABS control.

#### Fault

## **∆**Warning

If there is a fault in the ABS, the wheels may be liable to lock due to braking that is heavier than normal. The advantages of ABS are no longer available. During hard braking, the vehicle can no longer be steered and may swerve.

Have the cause of the fault remedied by a workshop.

## Parking brake

## **△**Warning

Before leaving the vehicle, check parking brake status. Control indicator (®) must illuminate constantly.

## Electric parking brake



#### Applying when vehicle is stationary

## **△**Warning

Pull switch ® for a minimum of one second until control indicator ® illuminates constantly and electric parking brake is applied № 109. The electric parking brake operates automatically with adequate force.

Before leaving the vehicle, check the electric parking brake status. Control indicator 

⊕ 

⇔ 109.

The electric parking brake can always be activated, even if the ignition is off.

Do not operate electric parking brake system too often without engine running as this will discharge the vehicle battery.

## Releasing

Switch on ignition. Keep foot brake pedal depressed and then push switch (®).

#### Drive away function

Vehicles with manual transmission: Depressing the clutch pedal and then slightly releasing the clutch pedal and slightly depressing the accelerator pedal releases the electric parking brake automatically. This is not possible when switch (P) is pulled at the same time.

Vehicles with automatic transmission: Engaging **D** and then depressing the accelerator pedal releases the electric parking brake automatically. This is not possible when switch (P) is pulled at the same time.

## Dynamic braking when vehicle is moving

When the vehicle is moving and the switch (2) is kept pulled, the electric parking brake system will decelerate the vehicle, but will not apply statically.

As soon as the switch (P) is released, dynamic braking will be stopped.

#### Automatic applying

If the vehicle is equipped with automatic transmission and adaptive cruise control is active, electric parking brake is applied automatically when vehicle is stopped by the system for more than two minutes. Parking brake releases automatically

#### **Functionality check**

after moving off.

When the vehicle is not moving, the electric parking brake might be applied automatically. This is done to check the system.

#### Fault

Failure mode of electric parking brake is indicated by a control indicator 

and by a vehicle message which is displayed in the Driver Information Centre. Vehicle messages 

125.

Apply electric parking brake: pull and hold the switch (2) for more than five seconds. If control indicator (2) illuminates, electric parking brake is applied.

Release electric parking brake: push and hold the switch (2) for more than two seconds. If control indicator (2) extinguishes, electric parking brake is released.

Control indicator (®) flashes: electric parking brake is not fully applied or released. When continuously flashing, release electric parking brake and retry applying.

#### Brake assist

If brake pedal is depressed quickly and forcefully, maximum brake force is automatically applied. Operation of brake assist might become apparent by a pulse in the brake pedal and a greater resistance when depressing the brake pedal.

Maintain steady pressure on the brake pedal as long as full braking is required. Maximum brake force is automatically reduced when brake pedal is released.

#### Hill start assist

The system helps preventing unintended movement when driving away on inclines.

When releasing the brake pedal after stopping on an incline, brakes remain on for further two seconds. The brakes release automatically as soon as the vehicle begins to accelerate. The hill start assist will not activate if one of the following conditions occurs:

- forward gear is engaged when facing downhill
- reverse gear is engaged when facing uphill

- driver seat belt is unfastened
- driver's door is open

#### Extended hold hill start assist

Vehicles with automatic transmission are additionally equipped with the extended hold hill start assist. This function holds the vehicle stationary for up to five minutes after the brake pedal is released.

The electric parking brake will be automatically activated to prevent vehicle movement when one of the following conditions occurs:

- extended hold hill start assist is deactivated after five minutes
- · ignition is switched off
- · driver's exit is detected

Hill start assist or extended hold hill start assist can be selected in the vehicle personalisation. ▷ 127

#### Note

Hill start assist and extended hold hill start assist will not be activated in neutral gear. If neutral gear is selected during an active hold, assists will deactivate and vehicle may start moving.

## Ride control systems

## **Traction Control system**

The Traction Control system (TC) is a component of the Electronic Stability Control (ESC).

TC improves driving stability when necessary, regardless of the type of road surface or tyre grip, by preventing the drive wheels from spinning.

As soon as the drive wheels starts to spin, engine output is reduced and the wheel spinning the most is braked individually. This considerably improves the driving stability of the vehicle on slippery road surfaces.



TC is operational after each engine start as soon as the control indicator \$\mathcal{z}\$ extinguishes.

When TC operates \$ flashes.

## **△**Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

Control indicator ₽ \$ 110.

#### Deactivation



TC can be switched off when spinning of drive wheels is required: press \$\mathbb{B}\$ briefly.



Control indicator & illuminates.

A status message appears in the Driver Information Centre when TC is deactivated.

When TC is deactivated, ESC remains active but with higher control threshold.

TC is reactivated by pressing & again. A status message pops up in the Driver Information Centre when TC is reactivated.

TC is also reactivated the next time the ignition is switched on.

#### Fault

If there is a fault in the system the control indicator \$\mathcal{B}\$ illuminates continuously and a message appears in the Driver Information Centre. The system is not operational.

Have the cause of the fault remedied by a workshop.

## **Electronic Stability Control**

Electronic Stability Control (ESC) improves driving stability when necessary, regardless of the type of road surface or tyre grip.

As soon as the vehicle starts to swerve (understeer/oversteer), engine output is reduced and the wheels are braked individually.

ESC operates in combination with the Traction Control system (TC). It prevents the drive wheels from spinning.

Torque distribution is a special feature that allocates the torque to the drive wheels before the ESC intervenes. When cornering, the wheels on the inner curve are braked individually. Additionally, engine torque will be delivered to the drive wheel on the outer curve. This reduces the tendency of understeering and improves traction when cornering fast.



ESC is operational after each engine start as soon as the control indicator \$\mathcal{z}\$ extinguishes.

When ESC operates \$ flashes.


## **△**Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

Control indicator ₽ ♦ 110.

#### Deactivation



#### ESC and TC can be deactivated:

 hold pressed for a minimum of five seconds: ESC and TC are both deactivated. and illuminate and status messages appear in the Driver Information Centre.





 To deactivate only Traction control system press button & briefly: TC is inactive but ESC remains active, @ illuminates. A status message appears in the Driver Information Centre when TC is deactivated.

ESC is reactivated by pressing the subtton again. If the TC system was previously disabled, both TC and ESC are reactivated. Substantial extinguishes when TC and ESC are reactivated.

ESC is also reactivated the next time the ignition is switched on.

#### Fault

If there is a fault in the system the control indicator \$\mathcal{B}\$ illuminates continuously and a message appears in the Driver Information Centre. The system is not operational.

Have the cause of the fault remedied by a workshop.

## Interactive driving system

#### Flex Ride

Flex Ride driving system allows the driver to select between three driving modes:

- SPORT mode: press SPORT, LED illuminates.
- TOUR mode: press TOUR, LED illuminates.
- AUTO or Standard / Normal mode: neither SPORT nor TOUR is pressed, no LED illuminates.

Deactivate SPORT mode or TOUR mode by pressing corresponding button once more.

In each driving mode Flex Ride adjusts the following electronic systems:

- electronic damping control
- accelerator pedal control
- electronic power steering control
- automatic transmission

- adaptive cruise control
- all-wheel drive
- engine sound enhancement
- instrument cluster theme

#### SPORT mode



The settings of the systems are adjusted for a sportier driving style:

- Damping of shock absorbers is set up for increased handling and agility.
- The engine reacts more quickly to accelerator pedal changes.
- Steering support is sportier.

- Automatic transmission shift points optimised for sporty driving.
- Adaptive cruise control is adjusted for a sportier driving style.
- All-wheel drive supports active sporty driving of the vehicle.
- Engine sound enhancement intensifies interior engine sound in a sporty manner.
- Cluster theme changes to sport.

#### **TOUR** mode



TOUR mode adjusts the settings of the systems for a comfortable driving style.

- Damping of shock absorbers is adapted for increased driving comfort.
- Steering efforts are reduced.
- Adaptive cruise control is adjusted for a more relaxed driving style.

#### **AUTO** mode

All versions except GSi: All settings of the systems are preset to standard values optimised for daily driving (default mode). This is the fully adaptive mode, adjusting systems to both comfort and sport settings depending on driving style and driving situation.

#### Normal mode

GSi versions only: All settings of the systems are preset to standard values optimised for daily driving (default mode). This mode keeps the standard values independent of driving style or driving situation.

#### Adaptive drive mode control

Within each manually selected driving mode SPORT, TOUR or AUTO, Drive Mode Control (DMC) detects and analyses continuously the driving situation and the driver's driving style. If necessary, DMC automatically adjusts damping and steering for the duration of the occuring situation.

If, for example, normal settings are active in AUTO mode and DMC detects a sporty driving behaviour, it automatically changes systems into sporty settings unless the driver deselects sporty damping or steering in the **Sport Mode Customisation**.

If, for another example, comfort settings are active in TOUR mode and whilst driving on a winding road a sudden hard brake is necessary, DMC will detect the dynamic vehicle condition and changes the settings for suspension back to normal (default) setting to enhance vehicle stability.

When the driving characteristic or the dynamic vehicle state returns to the former state, DMC will change to preselected settings.

#### Flex Ride visualisation menu



On 8" Info Display a Flex Ride visualisation menu can be displayed by touching 🎓 on the screen. On this page the selected drive mode and active setup are displayed.

System settings are highlighted in red for sport, blue for comfort and yellow for normal.

Additionally the personalisation of adaptive AUTO mode sensitivity as well as the personalisation of Sport mode functions can be displayed in the visualisation menu by selecting the respective button on the Info display.

## Personalisation of AUTO mode sensitivity

The driver can change the sensitivity of adaptive AUTO mode in three steps via the Flex Ride visualisation menu.

- Normal: default setting.
- Sport sensitive: systems change to sport settings faster while driving sporty.
- Comfort sensitive: systems change to comfort settings faster while cruising.

Additionally any drive mode control adaption can be deactivated.

Flex Ride visualisation menu will be displayed by touching 🅭 on the 8" Info display.

Select **Auto-Mode Customisation** and change the relevant settings.

The settings can also be changed in the personalisation menu in the Info display, ▶ Settings ▷ 127.

Info display \$\to\$ 121.

## Personalisation of Sport mode settings

The driver can customise the settings of the SPORT mode via the Flex Ride visualisation menu.

Flex Ride visualisation menu will be displayed when SPORT mode is selected or by touching 🏇 on the 8" Info display.

Select **Sport Mode Customisation** and select the relevant settings.

The settings can also be changed in the personalisation menu in the Info Display, **♦ Settings** ♀ 127.

## Driver assistance systems

## **△**Warning

Driver assistance systems are developed to support the driver and not to replace the driver's attention.

The driver stays in full control of the vehicle and accepts full responsibility when driving the vehicle.

When using driver assistance systems, always take care regarding the current traffic situation and follow applicable traffic rules.

#### Cruise control

The cruise control can store and maintain speeds of approx. 30 km/h to maximum vehicle speed. Deviations from the stored speeds may occur when driving uphill or downhill.

Activating in first gear is not possible.



Do not use the cruise control if it is not advisable to maintain a constant speed.



Illustrations show different versions.

Control indicator ♥ \$ 113.

## Switching on



Press (5); control indicator (5) in instrument cluster illuminates white.

#### Activation



80 km/h

Accelerate to the desired speed and turn thumb wheel to **SET/-**, the current speed is stored and maintained. Control indicator in instrument cluster illuminates green. On Mid- and Uplevel display illuminates green and set speed is indicated. Accelerator pedal can be released

Vehicle speed can be increased by depressing the accelerator pedal. When the accelerator pedal is released, the previously stored speed is resumed.

Cruise control remains activated while gearshifting.

## Increase speed

With cruise control active, hold thumb wheel turned to **RES/+** or briefly turn to **RES/+** repeatedly: speed increases continuously or in small increments.

Alternatively accelerate to the desired speed and store by turning to **SET/-**.



### Reduce speed

With cruise control active, hold thumb wheel turned to SET/- or briefly turn to SET/- repeatedly: speed decreases continuously or in small increments.

#### Deactivation

Press ♠; control indicator ♦ in instrument cluster illuminates white.

On Mid- or Uplevel display (%) changes to white.

Cruise control is deactivated, but not switched off. Last stored speed remains in memory for later speed resume.

Automatic deactivation:

- Vehicle speed is below approx. 30 km/h.
- Vehicle speed drops more than 25 km/h below the set speed.
- The brake pedal is depressed.
- The clutch pedal is depressed for a few seconds.
- The selector lever is in N.
- Engine speed is in a very low range.

- The Traction Control system or Electronic Stability Control is operating.
- Parking brake is applied.
- Simultaneous pressing RES/+ and brake pedal deactivates cruise control and will delete stored speed.

## Resume stored speed

Turn thumb wheel to **RES/+** at a speed above 30 km/h. The stored speed will be obtained.

## Switching off

Press  $\mathfrak{D}$ , control indicator  $\mathfrak{D}$  in instrument cluster extinguishes. The stored speed is deleted.

Pressing to activate the speed limiter or switching off the ignition also switches off cruise control and deletes the stored speed.

## **Speed limiter**

The speed limiter prevents the vehicle exceeding a preset maximum speed.

The maximum speed can be set at speeds above 25 km/h up to 200 km/h.

The driver can only accelerate up to the preset speed. Deviations from the limited speed may occur when driving downhill.

The preset speed limit is displayed in the Driver Information Centre when the system is active.

#### Activation



Illustrations show different versions.



Press @, symbol @ illuminates in the Driver Information Centre.

If cruise control has been activated before, it is switched off when speed limiter is activated and the control indicator (%) extinguishes.

## Set speed limit

Accelerate to the desired speed and briefly turn thumb wheel to **SET/-**: the current speed is stored as maximum speed.

On Baselevel display @ and the speed limit is displayed.



On Mid- and Uplevel display @ changes to green.

## Change speed limit

With speed limiter active, hold or briefly turn thumb wheel to RES/+ to increase or SET/- to decrease the desired maximum speed.

## Exceeding the speed limit

When exceeding the limited speed without driver input, the speed will flash in the Driver Information Centre and a chime sounds during this period.

In the event of an emergency, it is possible to exceed the speed limit by depressing the accelerator pedal firmly nearly to the final point. In this case no chime appears.

Release the accelerator pedal and the speed limiter function is reactivated once a speed lower than the limit speed is obtained.

#### Deactivation

Press A: speed limiter is deactivated and the vehicle can be driven without speed limit.



On Baselevel display the stored limited speed is indicated in brackets.

On Mid- or Uplevel display @ changes to white.

Additionally, a corresponding message appears.

Speed limiter is deactivated, but not switched off. Last stored speed remains in memory for later speed resume.

## Resume limit speed

Turn thumb wheel to **RES/+**. The stored speed limit will be obtained and is indicated without brackets in the Driver Information Centre.

## Switching off

Press @, the speed limit indication extinguishes in the Driver Information Centre. The stored speed is deleted.

By pressing (5) to activate cruise control or adaptive cruise control, speed limiter is also deactivated and the stored speed is deleted.

By switching off the ignition, speed limiter is also deactivated, but the speed limit will be stored for next speed limiter activation.

## Adaptive cruise control

Adaptive cruise control is an enhancement to conventional cruise control with the additional feature of maintaining a certain distance behind the vehicle ahead.

Adaptive cruise control automatically decelerates the vehicle when approaching a slower moving vehicle. It then adjusts the vehicle speed to follow the vehicle ahead at the selected following distance. The vehicle speed increases or decreases to follow the vehicle in front, but will not exceed the set speed. It may apply limited braking with activated brake lights.

To facilitate overtaking a vehicle on the motorway, the activation of the turn signal reduces the following distance for a short time. This function is implemented only on the respective driver's side depending on left or right hand drive vehicle configuration.

The adaptive cruise control can store set speed over 30 km/h for manual transmission. On vehicles with automatic transmissions the system can brake until a full stop and drive off from a stop.



Adaptive cruise control uses radar and camera sensors to detect the vehicles ahead. If no vehicle is detected in the driving path, the adaptive cruise control will behave like a conventional cruise control.

Adaptive cruise control is mainly advised to be used on long straight roads like highways or country roads with steady traffic. Do not use the system if it is not advisable to maintain a constant speed.

## **△**Warning

The complete driver attention is always required while driving with adaptive cruise control. The driver stays fully in control of the vehicle because the brake pedal, the

accelerator pedal and the cancel switch have priority over any adaptive cruise control operation.

## Switching on the system



Illustrations show different versions.



Press 

to switch on adaptive cruise control. 

appears in the Driver Information Centre.

## Activation of the functionality by setting the speed

Adaptive cruise control can be activated at speeds above 25 km/h on vehicles with automatic transmission or 30 km/h on vehicles with manual transmission. The upper speed limit is 180 km/h.

Accelerate to the desired speed and turn thumb wheel to **SET/-**, the current speed is stored and maintained



The accelerator pedal can be released. Adaptive cruise control remains activated during gear shifting.

## Overriding set speed

It is always possible to drive faster than the selected set speed by depressing the accelerator pedal. When the accelerator pedal is released, the vehicle returns to the desired distance if a slower vehicle is ahead. Otherwise it returns to the stored speed.

Once the system is activated, adaptive cruise control decelerates or brakes if it detects a vehicle ahead, which is slower or closer than the desired following distance.

## **△**Warning

Accelerating by the driver deactivates automatic braking by the system. This is indicated as a pop-up warning in the Driver Information Centre or by the adaptive cruise control symbol turning blue.

## Take over current speed

If the accelerator pedal is pressed, the current vehicle speed is taken over as stored speed. This is also valid, if the current vehicle speed is lower than the Set Speed.

#### Increase speed

With adaptive cruise control active, hold RES/+ to increase speed continuously. Push RES/+ repeatedly to increase speed in small increments.

## Reduce speed

With adaptive cruise control active, hold **SET/-** to decrease speed continuously. Push **SET/-** repeatedly to decrease speed in small increments.

#### Resume stored speed

If the system is switched on but inactive and a speed was stored before, turn thumb wheel to **RES/+** at a speed above 5 km/h (with automatic transmission) or above 30 km/h (with manual transmission) to resume the stored speed.

## Full speed range adaptive cruise control on vehicles with automatic transmission

Full speed range adaptive cruise control will maintain a following distance behind a detected vehicle and slow your vehicle to a stop behind that vehicle.

When the vehicle ahead accelerates after a brief stop, the adaptive cruise control will drive off automatically without driver action. If necessary,

press **RES/+** or the accelerator pedal to resume adaptive cruise control. Pressing the accelerator pedal allows more control over the acceleration after driving off. Note that automatic braking is disabled during usage of the accelerator pedal.

If the stopped vehicle ahead stands for a longer time and then begins to move forward, the green illuminated vehicle ahead control indicator  $\rightleftharpoons$  will flash and a warning chime will sound as a reminder to check traffic before resuming.

## **∆**Warning

When full speed range adaptive cruise control is deactivated or cancelled, the vehicle will no longer be held at a stop and can start moving. Always be prepared to manually apply the brake pedal to hold the vehicle stationary.

Do not leave the vehicle while it is being held at a stop by the full speed range adaptive cruise control. Always move selector lever to park position **P** and switch off the ignition before leaving the vehicle.

## Setting the following distance


When adaptive cruise control detects a slower moving vehicle in the driving path, it will adjust the vehicle speed to maintain the following distance selected by the driver.

The following distance can be set to near, medium or far.



Press সু, the current setting is shown in the Driver Information Centre. Press সু again to change the

following distance. The setting is also displayed in the Driver Information Centre.



The selected following distance is indicated by filled distance bars in the adaptive cruise control page.

Note that the following distance setting is shared with the sensitivity setting of forward collision alert 

⇒ 200.

Example: If setting 3 (far) is selected, then the driver is warned sooner before a possible collision, also if adaptive cruise control is inactive or switched off.

## **△**Warning

The Driver accepts full responsibility to drive with the appropriate following distance based on traffic, weather, visibility and regional regulation. Following distance must be adjusted or the system switched off when required by the prevailing conditions.

## Adaptive cruise control in Sport mode



On vehicles with Flex Ride driving modes, the driver can slightly increase the Adaptive cruise control

acceleration when Sport mode is selected. This function can be deactivated in the Flex Ride visualisation menu ▷ 186

## Detecting the vehicle ahead



The green illuminated vehicle ahead control indicator ☐ is displayed when the system detects a vehicle in the driving path. The range of the sensors is between 25 and 150 metres depending on vehicle speed.

If this symbol does not display, or displays briefly, adaptive cruise control will not respond to vehicles ahead.

#### Deactivation of the functionality

Adaptive cruise control is deactivated by the driver when:

- Brake pedal is applied.
- Clutch pedal is depressed for more than four seconds.
- Selector lever of automatic transmission is moved to N.

The system is also automatically deactivated when:

- Vehicle speed accelerates above 190 km/h or slows down below 25 km/h. Vehicles with automatic transmission slows down to a stop without deactivating within five minutes.
- The Traction Control system is deactivated or operating.
- The Electronic Stability Control is deactivated or operating.
- There is no traffic and nothing detected on the road sides for approx. one minute. In this case there are no radar echoes and the sensor may report that it is blocked.

- The active emergency braking system is applying the brakes.
- Driving on steep inclines.
- The radar sensor is blocked by an ice or water film.
- A fault is detected in the radar, camera, engine or brake system.
- The brakes need to cool down.

Additionally, the system is automatically deactivated on vehicles with automatic transmission (full speed range adaptive cruise control) when:

- The incline uphill or downhill is greater than 20 %.
- The electric parking brake is applied.
- The vehicle is being held to a stop by the system for more than five minutes.
- The vehicle stops, the driver's seat belt is unbuckled and the driver's door is opened.

When adaptive cruise control is deactivated, the control indicator changes from green to white and a pop-up message is displayed in the Driver Information Centre.

The stored speed is maintained.



On Midlevel display, the stored speed is indicated in brackets in the Driver Information Centre when the system is deactivated but not switched off.

## **△**Warning

When adaptive cruise control is deactivated, the driver must take over full brake and engine control immediately.

#### Switching off the system

Press % to switch off adaptive cruise control. The control indicator % extinguishes in the Driver Information Centre. The stored speed is deleted. Switching off the ignition also

Switching off the ignition also switches off adaptive cruise control and deletes the stored speed.

#### **Driver's attention**

- Use adaptive cruise control carefully on bends or mountain roads, as it can lose the vehicle ahead and needs time to detect it again.
- Do not use the system on slippery roads as it can create rapid changes in tyre traction (wheel spinning), so that you could lose control of the vehicle.
- Do not use adaptive cruise control during rain, snow or heavy dirt, as the radar sensor can be covered by a water film, dust, ice or snow. This reduces or suppresses completely the

visibility. In case of sensor blockage, clean the sensor cover.

## System limits


## **△**Warning

The system's automatic brake force does not permit hard braking and the braking level may not be sufficient to avoid a collision.

- After a sudden lane change, the system needs a certain time to detect the next preceding vehicle. So if a new vehicle is detected, the system may accelerate instead of braking.
- Adaptive cruise control does ignore the oncoming traffic.
- Adaptive cruise control does not consider pedestrians and animals for braking and driving off.
- Adaptive cruise control considers stopped vehicles only at low speed.

- Do not use adaptive cruise control when towing a trailer.
- Do not use adaptive cruise control on roads with an incline of more than 10%.

#### **Bends**



The adaptive cruise control calculates a predicted path based on the centrifugal force. This predicted path considers the current bend characteristic, but cannot consider a future bend change. The system may lose the current vehicle ahead or consider a vehicle which is not in the actual lane. This can happen when entering or exiting a bend or if the bend gets stronger or weaker. The camera applies a certain correction based on the detectable lane markings. The control indicator \( \mathref{\text{\text{will}}} \) extinguish, if a vehicle ahead is no longer detected.

If the centrifugal force is too high in a bend, the system slows down the vehicle slightly. This braking level is not designed to avoid spinning-off the bend. The driver is responsible for reducing the selected speed before entering a bend and in general to adapt the speed to the road type and to existing speed limits.



#### Motorways

On motorways, adapt the set speed to the situation and the weather. Always consider that adaptive cruise control has a limited visibility range, a limited braking level and a certain reaction time to verify if a vehicle is on the driving path or not. Furthermore, adaptive cruise control was designed to brake as late as possible to allow changing the lane before the automatic braking. Adaptive cruise control may not be able to brake the vehicle in time to avoid a collision with

a much slower vehicle or after a lane change. This is particularly true while driving fast or if the visibility is reduced due to weather conditions.

While entering or exiting a motorway, adaptive cruise control may lose the vehicle ahead and accelerate up to the set speed. For this reason, decrease the set speed before the exit or before the entry.

### Vehicle path changes



If another vehicle enters your driving path, adaptive cruise control will first consider the vehicle when it is completely in your path. Be ready to take action and depress the brake pedal, if you need to brake more quickly.

#### Hill and trailer considerations



## **△**Warning

Do not use adaptive cruise control on steep hill roads.

System performance on hills depends on vehicle speed, vehicle load, traffic conditions and the road gradient. It may not detect a vehicle in your path while driving on hills. Full speed range adaptive control is deactivated automatically, as the vehicle is stopping uphill on an incline greater than 10%. In this condition, be prepared to take control of the vehicle.

Note that applying the brake deactivates the system.

#### Radar unit



The radar unit is mounted behind the radiator grille behind or below the brand emblem.

## **△**Warning

The radar unit was aligned carefully during manufacture. Therefore, in the event of a frontend impact, do not use the system. The front bumper may appear to be intact, however the sensor behind can be out of position and react incorrectly. After an

accident, consult a workshop to verify and adjust the radar unit position.

## **Settings**

Settings can be changed in the vehicle personalisation menu in the Info-Display.

Select the relevant setting in **Settings**, **Vehicle** in the Info-Display.

Info-Display \$ 121.

#### Fault

If the adaptive cruise control does not work due to temporary conditions (e.g. blockage by ice, overheated brakes or low speed manoeuvres) or if there is a permanent system error, a message is displayed in the Driver Information Centre.

## Forward collision alert

The forward collision alert may help to avoid or reduce the harm caused by front-end crashes

If the vehicle is equipped with conventional cruise control, the forward collision alert uses the front camera in the windscreen to detect a vehicle directly ahead, in your path.

If the vehicle is equipped with adaptive cruise control, the forward collision alert uses the radar sensor and front camera to detect a vehicle directly ahead, in your path.



A vehicle ahead is indicated by the control indicator  $\widehat{+}$ .

If a vehicle directly ahead is approached too quickly, a warning chime and alert in the Driver Information Centre is provided.

Additionally the driver gets notified by a flashing red LED stripe or a pop up symbol in the head-up display which is projected on the windscreen in the driver's field of view.

A precondition is that forward collision alert in the vehicle personalisation menu is not deactivated ♦ 127.

#### Activation

Forward collision alert with front camera detects vehicles to distances of approximately 60 metres and operates automatically at all speeds above walking speed.

Forward collision alert with radar sensor detects vehicles to distances of approximately 150 metres and operates automatically at all speeds above walking speed.

## Alerting the driver

The control indicator 

changes to yellow when the distance to a preceding moving vehicle gets too small

#### Caution

The colour lighting of this control indicator does not correspond to local traffic laws on following distance. The driver bears full responsibility for maintaining safe following distance according to applicable traffic rules, weather and road conditions etc. at all times.



When the time to a potential collision with a vehicle in front gets too small and a collision is imminent, the collision alert symbol pops-up in the Driver Information Centre and the driver gets notified by a flashing red LED stripe or the pop-up symbol in the head-up display which is projected on the windscreen in the driver's field of view.




Simultaneously a warning chime sounds. Depress the brake pedal and steer the vehicle, if it is required by the situation.

## Selecting the alert sensitivity

Press to set the alert sensitivity to near, medium or far.



The first button press shows the current setting on the Driver Information Centre. Additional button presses will change this setting. The chosen setting will remain until it is changed. The alert timing will vary based on vehicle speed. The faster the vehicle speed, the farther away the alert will occur. Consider traffic and weather conditions when selecting the alert timing.



Note that the alert timing sensitivity setting is shared with the following distance setting of the adaptive cruise control. So changing the alert timing sensitivity changes the adaptive cruise control following distance setting.

#### Deactivation

The system can be deactivated in the personalisation menu, \$\dip\$ 127.

If the forward collision alert was deactivated, alert sensitivity is set to "medium" when ignition is switched on next time.

The last selected setting will be stored when the ignition is switched off.

#### General information

## **△**Warning

Forward collision alert is just a warning system and does not apply the brakes. When approaching a vehicle ahead too rapidly, it may not provide you enough time to avoid a collision.

The driver accepts full responsibility for the appropriate following distance based on traffic, weather and visibility conditions.

The complete attention of the driver is always required while driving. The driver must always be ready to take action and apply the brakes.

#### **System limitations**

Forward collision alert is designed to warn on vehicles only, but may react also to other objects.

In the following cases, Forward collision alert may not detect a vehicle ahead or sensor performance is limited:

- Driving on winding or hilly roads.
- During nighttime driving.
- Weather limits visibility, such as fog, rain, or snow
- The sensor in the windscreen is blocked by snow, ice, slush, mud, dirt, windscreen damage or affected by foreign items, e.g. stickers.

## Following distance indication

The following distance indication displays the distance to a preceding moving vehicle. The front camera in the windscreen is used to detect the distance of a vehicle directly ahead in the vehicle's path. It is active at speeds above 40 km/h.

When a preceding vehicle is detected ahead, the distance is indicated in seconds, displayed on a page in the Driver Information Centre.


On Baselevel display, choose Info Menu signal lever and turn the adjuster wheel to choose following distance indication page, \$\display\$ 114



On Mid- and Uplevel display, select **Info** menu via steering wheel buttons and press **▼** to select following distance indication \$\display\$ 114.

The minimum indicated distance is 0.5 seconds.

If there is no vehicle ahead or the vehicle ahead is out of range, two dashes will be displayed: -.- sec.



## System limitations

In the following cases, following distance indication sensor performance is limited:

- Driving on winding or hilly roads.
- During nighttime driving.

- Weather limits visibility, such as fog, rain, or snow.
- The sensor is blocked by snow, ice, slush, mud, dirt, windscreen damage or affected by foreign items, e.g. stickers.

## Active emergency braking

Active emergency braking can help to reduce the damage and injury from crashes with vehicles, pedestrians and obstacles directly ahead, when a collision can no longer be avoided either by manual braking or by steering. Before the active emergency braking applies, the driver is warned by the Forward collision alert ⋄ 200 or the Front pedestrian protection alert ⋄ 206.

The feature uses various inputs (e.g. camera sensor, radar sensor, brake pressure, vehicle speed) to calculate the probability of a frontal collision.

## **△**Warning

This system is not intended to replace the driver responsibility for driving the vehicle and looking ahead. Its function is limited to supplemental use only to reduce the vehicle speed before a collision.

The system may not react to animals. After a sudden lane change, the system needs a certain time to detect the next preceding vehicle.

The driver must always be ready to take action and apply the brakes and steer to avoid collisions.

## **Functionality**

If equipped only with front camera the active emergency braking operates in forward gear above walking speed up to 85 km/h.

With radar sensor active emergency braking operates in forward gear above walking speed at all speeds.

A precondition is that forward collision alert with front camera system is not deactivated in the vehicle personalisation menu \$\phi\$ 127.

The system includes:

- brake preparation system
- emergency automatic braking
- forward looking brake assist
- intelligent brake assist (only with radar sensor)
- front pedestrian protection system

### Brake preparation system

When approaching a vehicle ahead or a pedestrian so quickly that a collision is likely, the brake preparation system slightly pressurizes the brakes. This reduces the response time, when a manual or automatic braking is requested.

The brake system is prepared so that braking can occur more rapidly.

If equipped only with front camera the system operates up to a speed of 80 km/h.

## **Emergency automatic braking**

After activation of brake preparation system and just before the imminent collision, this function automatically applies limited braking to reduce the impact speed of the collision or prohibit a crash. Depending on the situation, the vehicle may automatically brake moderately or hard. This front automatic braking can only occur if a vehicle ahead is detected, indicated by the vehicle with front pedestrian protection, front automatic braking can also occur when a pedestrian ahead is detected, indicated by the pedestrian ahead indicator \*.

If equipped only with front camera the system operates up to a speed of 80 km/h.

Below a speed of 40 km/h the system can apply full braking.

Emergency automatic braking may slow the vehicle to a complete stop to try to avoid a potential crash. If this happens, emergency automatic braking may engage the electric parking brake to hold the vehicle at a stop. To release press the electric parking brake button or firmly press the accelerator pedal.

## **△**Warning

Emergency automatic braking is an emergency crash preparation feature and is not designed to avoid crashes. Do not rely on the system to brake the vehicle. Emergency automatic braking will not brake outside of its operating speed range and only responds to detected vehicles and pedestrians.

## Forward looking brake assist

In addition to the brake preparation system and emergency automatic braking, the forward looking brake assist function makes the brake assist more sensitive. Therefore, pressing the brake pedal less strongly results in immediate hard braking. This function helps the driver brake quicker and harder before the imminent collision.

If equipped only with front camera the system operates up to a speed of 85 km/h.

## **△**Warning

Active emergency braking is not designed to apply hard autonomous braking or to automatically avoid a collision. It is designed to reduce the vehicle speed before a collision. It may not react to animals. After a sudden lane change, the system needs a certain time to detect the next preceding vehicle.

The complete attention of the driver is always required while driving. The driver must always be ready to take action and apply the brakes and steer to avoid collisions.

The system is designed to work with all occupants wearing their seat belts.

#### **Intelligent Brake Assist**

If the vehicle is equipped with radar sensor Intelligent brake assist may activate when the brake pedal is applied quickly by providing a boost to braking based on the speed of approach and distance to a vehicle ahead.

Minor brake pedal pulsations or pedal movement during this time is normal and the brake pedal should continue to be applied as needed. Intelligent brake assist will automatically disengage only when the brake pedal is released.

## **△**Warning

Intelligent brake assist may increase vehicle braking in situations when it may not be necessary. You could block the flow of traffic. If this occurs, take your foot off the brake pedal and then apply the brakes as needed.

#### 

#### Deactivation

## System limitations

In some cases, the active emergency braking system may provide an automatic braking in situations that seem to be unnecessary, for instance in parking garages, due to traffic signs in a curve or due to vehicles in another lane. This is normal operation, the vehicle does not need service. Firmly apply the accelerator pedal to override the automatic braking if the situation and the surroundings permit.

In the following cases, Active emergency braking performance is limited:

- Driving on winding or hilly roads.
- Detecting all vehicles, especially vehicles with a trailer, tractors, muddy vehicles, etc.

- Detecting a vehicle when weather limits visibility, such as in fog, rain, or snow.
- During nighttime driving.
- Weather limits visibility, such as fog, rain, or snow.
- The sensor in the windscreen is blocked by snow, ice, slush, mud, dirt, windscreen damage or affected by foreign items, e.g. stickers

To avoid malfunction keep the areas of the camera sensor in the windscreen and the radar sensor in the radiator grille always clean from dirt, dust, ice and snow.

Complete attention is always required while driving, and you should be ready to take action and apply the brakes and/or steer the vehicle to avoid crashes.

#### Fault

In case the system requires a service, a message is displayed in the Driver Information Centre.

If the system does not work as it should do, vehicle messages are displayed in the Driver Information Centre.

## Front pedestrian protection

Front pedestrian protection may help to avoid or reduce the harm caused by front-end crashes with nearby pedestrians when driving in a forward gear.

The system uses the front camera in the windscreen to detect a pedestrian directly ahead, in your path.

Front pedestrian protection can detect and alert to pedestrians in a forward gear at speeds between 8 km/h and 80 km/h. Additionally Front pedestrian protection can provide a boost to braking or automatically brake the vehicle.

During daytime driving, the system detects pedestrians up to a distance of approximately 40 metres. During nighttime driving, system performance is limited.

Front pedestrian protection can be set to Off, Alert, or Alert & Brake in vehicle personalisation ₱ 127.

## **⚠** Danger

Front pedestrian braking does not provide an alert or automatically brake the vehicle, unless it detects a pedestrian.

The system may not detect pedestrians, including children, when the pedestrian is not directly ahead, not fully visible, not standing upright, or when part of a group.

Front pedestrian protection includes:

- detecting front pedestrian ahead
- front pedestrian alert
- automatic braking

## Detecting front pedestrian ahead



A pedestrian ahead up to a distance of approximately 40 m is indicated by the control indicator \* in the instrument cluster. On vehicles with head-up display, \* is projected on the windscreen.

## Front pedestrian alert



When approaching a detected pedestrian too quickly, a red flashing LED alert or the pop-up symbol ≯ in the head-up display is projected on the windscreen in the driver's field of view. A warning chime is provided. The brake system may prepare for driver braking to occur more rapidly which can cause a brief, mild deceleration. Continue to apply the brake pedal as required.

Cruise control or Adaptive cruise control may be disengaged when the Front pedestrian alert occurs.

## **Automatic braking**

If a crash into a pedestrian directly ahead is imminent, and the brakes have not been applied, Automatic braking may automatically brake moderately or brake hard. This can help to avoid some very low speed pedestrian crashes or reduce pedestrian injury.

Automatic braking levels may be reduced under certain conditions, such as higher speeds.

If this happens, automatic braking may engage the Electric parking brake to hold the vehicle at a stop. Release the parking brake. A firm press of the accelerator pedal will also release Automatic braking and Electric parking brake ♀ 181.

This system includes Intelligent brake assist, and the Emergency automatic braking system may also respond to pedestrians. See Active emergency braking ₱ 203.

#### General information

## **△**Warning

The driver must always be ready to take action and apply the brakes and steer to avoid collisions.

## **△**Warning

Front pedestrian braking may alert or automatically brake the vehicle suddenly in situations where it is unexpected and undesired. It could falsely alert or brake for objects similar in shape or size to pedestrians, including shadows. This is normal operation and the vehicle does not need a service. To override Automatic braking, firmly depress the accelerator pedal, if it is safe to do so.

## **△**Warning

Using the Front pedestrian braking system while towing a trailer could cause loss of vehicle control and crash. Turn the system to Alert or Off in the vehicle personalisation when towing a trailer. Vehicle personalisation ❖ 127.

## System limitations

In the following cases, front pedestrian protection may not detect a pedestrian ahead or sensor performance is limited:

- Vehicle speed is out of range from 8 km/h to 80 km/h in forward gear.
- The distance to an pedestrian ahead is more than 40 metres.
- Driving on winding or hilly roads.
- During nighttime driving.
- Weather limits visibility, such as fog, rain, or snow.
- The sensor in the windscreen is blocked by snow, ice, slush, mud, dirt, windscreen damage or affected by foreign items, e.g. stickers.

## Parking assist

#### General information

When attaching a trailer or bike carrier to the trailer hitch, the parking assist is deactivated.

## Front-rear parking assist

## **△**Warning

The driver bears full responsibility for the parking manoeuvre.

Always check the surrounding area when driving backwards or forwards while using parking assist system.

The front-rear parking assist measures the distance between the vehicle and obstacles in front and behind the vehicle. It informs and warns the driver by giving acoustic signals and display indication.

It uses two different acoustic warning signals for the front and rear monitoring areas, each with a different tone frequency.



The system has four ultrasonic parking sensors each in the rear and front bumper.

#### Activation

The system is activated automatically at a speed up to 11 km/h.



An illuminated LED in the parking assist button P<sup>\*</sup> indicates that the system is ready to operate.

If P<sup>m</sup> is switched off within an ignition cycle, the front parking assist is deactivated. If vehicle speed has exceeded 25 km/h beforehand, parking assist will be reactivated when speed drops below 11 km/h.

When the system is deactivated, the LED in the button extinguishes and **Park Assist Off** pops-up in the Driver Information Centre.

#### Indication

The system warns the driver with acoustic signals against potentially hazardous obstacles in front of the vehicle in a distance range up to 80 cm and against potentially hazardous obstacles behind the vehicle in a distance range up to 50 cm while a forward gear is engaged, or up to 1.5 m while reverse gear is engaged.

Depending on which side of the vehicle is closer to an obstacle, you will hear acoustic warning signals in the vehicle on the respective side. The interval between the sounds becomes shorter as the vehicle gets closer to that obstacle. When the distance is less than approx. 30 cm, the sound is continuous.

Additionally, the distance to rear and front obstacles is displayed by changing distance lines in the Driver Information Centre \$\Delta\$ 114 or, depending on the version, on the Info-Display \$\Delta\$ 121.



The distance indication can be inhibited by vehicle messages with a higher priority. After dismissing the message distance indication appears again.

Acoustic signal is muted when parking brake is engaged or the selector lever of automatic transmission is in **N**.

#### Deactivation

The system is deactivated automatically when vehicle speed exceeds 11 km/h.

Manual deactivation is also possible by pressing the parking assist button  $P^{m}\underline{A}$ .

When the system is deactivated manually, the LED in the button extinguishes and **Park Assist Off** pops-up in the Driver Information Centre.

After a manual deactivation, the frontrear parking assist is activated again if P<sup>n</sup>▲ is pressed.

The complete system can be manually deactivated in the vehicle personalisation menu in the Info-Display. It remains deactivated during the ignition cycle or until activation in personalisation menu again. Vehicle personalisation \$\cdot\$ 127.

#### Fault

In the event of a fault or if the system does not work temporarily, e.g. because of high external noise level or other interference factors, a message pops-up in the Driver Information Centre.

## Advanced parking assist

## **△**Warning

The driver bears full responsibility for accepting the parking slot suggested by the system and the parking manoeuvre.

Always check the surrounding area in all directions when using the advanced parking assist.

The advanced parking assist measures a suitable parking slot while passing, calculates the trajectory and automatically steers the vehicle into a parallel or perpendicular parking slot.

Instructions are given in the Driver Information Centre ♀ 114 or, depending on the version, on the Info-Display ♀ 121, supported by acoustic signals.

In vehicles with manual transmission, the driver must control acceleration, braking and gear shifting, while steering is done automatically. In vehicles with automatic transmission, the driver must control acceleration and gear shifting, while braking and steering is done automatically.



Advanced parking assist is always combined with front-rear parking assist. Both systems use the same sensors in the front and rear bumper.

The system has six ultrasonic parking sensors each in both the rear and front bumper.

Activation of advanced parking assist Advanced parking assist can only be activated when driving forwards.




When searching for a parking slot, the system is ready to operate with a short press of P#G.

The system recognises and memorises ten metres for parallel parking slots or six metres for perpendicular parking slots in the parking assist mode.

The system can only be activated and searches for a parking slot at a speed up to 30 km/h.


Advanced parking assist may not be activated when driving on very steep inclines.

# Functionality Parking slot searching mode, indication in the Driver Information Centre



Select parallel or perpendicular parking slot in Driver Information Centre by long press on P#B.

The system is configured to detect parking slots by default on the passenger side. To detect parking slots on the driver side, switch on turn signal indicator on the driver side.




When a slot is detected, a visual feedback in the Driver Information Centre and an acoustic signal is given.

#### Indication in the Colour-Info-Display



Select parallel or perpendicular parking slot by tapping the respective icon on the display.

Select parking side by tapping the respective icon on the display.



When a slot is detected, a visual feedback on the Colour-Info-Display and an acoustic signal is given.

If the driver does not stop the vehicle after a parking slot is proposed, the system starts to search for another suitable parking slot.

#### Park guiding mode

The parking slot suggestion of the system is accepted when the vehicle is stopped by the driver within ten metres for parallel parking slots or six metres for perpendicular parking slots after the **Stop** message is given. The system calculates the optimal path into the parking slot.

A brief vibration in the steering wheel after engaging reverse gear indicates that the steering is controlled by the system. Then the vehicle with manual transmission is steered into the slot automatically by giving the driver detailed instructions for braking, accelerating and gear shifting. With automatic transmission the vehicle is steered into the slot automatically by giving the driver detailed instructions for accelerating and shifting forward or reversing. The driver must keep hands away from the steering wheel. During park guiding mode the manoeuvring speed is limited.

Always pay attention to the sound of the front-rear parking assist. Continuous sound indicates that the distance to an obstacle is less than approx. 30 cm.

If, for any reason, the driver must take over control of the steering, hold the steering wheel only at the outer edge. Automatic steering is cancelled in this event.

#### Display indication

The instructions on the display show:

- General hints and warning messages.
- A hint when driving faster than 30 km/h during parking slot searching mode.
- The demand to stop the vehicle, when a parking slot is detected.
- The direction of driving during the parking manoeuvre.
- The demand to shift into reverse or first gear, or R or D with automatic transmission.
- The demand to stop or to drive slowly.
- For some of the instructions a progress bar is shown in the Driver Information Centre.
- The successful completion of the parking manoeuvre indicated by a pop-up symbol and a chime.
- The cancelling of a parking manoeuvre.

### Display priorities

Advanced parking assist indication in the Driver Information Centre can be inhibited by vehicle messages with a higher priority. After approving the message by pressing SET/CLR on the turn signal lever or **✓** on the steering wheel, advanced parking assist instructions appear again and the parking manoeuvre can be continued.

#### Deactivation

The system is deactivated by:

- a short press of p
- parking manoeuvre successfully ended
- driving faster than 30 km/h during parking slot search
- driving faster than 8 km/h during parking guidance
- driver interference on steering wheel detected
- exceeding maximum number of gear changes: eight cycles when parallel parking or five cycles when perpendicular parking
- switching off the ignition

Deactivation by the driver or by the system during manoeuvring will be indicated by Parking Deactivated on the display. Additionally, an acoustic signal sounds.

Automatic transmission:

If advanced park assist is deactivated during the parking manoeuvre or manoeuvre is finished successfully. the assist holds the vehicle in position until one of the following conditions occur:

- 1. brake pedal is applied.
- 2. electric parking brake is activated.
- 3. Selector lever is set to P

#### Fault

A message appears when:

- There is a fault in the system.
- The driver did not successfully complete the parking manoeuvre.
- The system is not operational.
- Any of the deactivation reasons described above apply.

If an object is detected during parking instructions. Stop is indicated on the display. Removing the object will resume the parking manoeuvre. If the object is not removed, the system will be deactivated.

## Basic notes on parking assist systems

## **△**Warning

Under certain circumstances. various reflective surfaces on objects or clothing as well as external noise sources may cause the system to fail to detect obstacles.

#### Caution

Performance of the system can be reduced when sensors are covered, e.g. by ice or snow.

Performance of the parking assist system can be reduced due to heavy loading.

Special conditions apply if there are taller vehicles in the vicinity (e.g. off-road vehicles, mini vans, vans). Object identification and correct distance indication in the upper part of these vehicles cannot be guaranteed.

Objects with a very small reflection cross-section, e.g. objects of narrow size or soft materials, may not be detected by the system.

Parking assist systems do not detect objects outside the detection range.

#### Note

It is possible that the sensor detects a non-existing object caused by echo disturbance from external acoustic noise or mechanical misalignments (sporadic false warnings may occur).

Make sure that the front number plate is properly mounted (not bent and no gaps to the bumper on the left or right side) and the sensors are firmly in place.

Advanced parking assist system may not respond to changes in the available parking space after initiating a parking manoeuvre. The system may recognize an entry, a gateway, a courtyard or even a crossing as a parking slot. After selecting reverse gear the system will start a parking manoeuvre. Take care regarding the availability of the suggested parking slot.

Low curbs and surface irregularities, e.g. on construction zones, are not detected by the system. The driver accepts responsibility.

#### Note

New vehicles require a calibration during first use. For optimal parking guidance, a driving distance of at least 10 km, including a number of bends, is required.

System is calibrated to factory-fitted wheels. Parking performance is altered with other tyre or wheels sizes.

# Side blind spot alert

The Side blind spot alert system detects and reports objects on either side of the vehicle, within a specified "blind spot" zone. The system displays a visual alert in each exterior mirror, when detecting objects that may not be visible in the interior and exterior mirrors.

Side blind spot alert uses some of the advanced parking assist sensors which are located in the front and rear bumper on both sides of the vehicle.


# **▲**Warning

Side blind spot alert does not replace driver vision.

The system does not detect:

- vehicles outside the side blind zones which may be rapidly approaching
- pedestrians, cyclists or animals

Before changing a lane, always check all mirrors, look over the shoulder and use the turn signal.



When the vehicle is started, both exterior mirror displays will briefly illuminate to indicate that the system is operating.

When the system detects a vehicle in the side blind spot while driving forwards, either while passing a vehicle or being passed, a yellow warning symbol  $\star \rightleftharpoons$  will illuminate in the relevant exterior mirror. If the driver then activates the turn signal, the warning symbol  $\star \rightleftharpoons$  starts flashing yellow as a warning not to change lanes.

#### Note

If the overtaking vehicle is at least 10 km/h faster than the vehicle being overtaken, the warning symbol ★ in the relevant exterior mirror may not illuminate.

Side blind spot alert is active from speeds of 10 km/h up to 140 km/h. Driving faster than 140 km/h deactivates the system, indicated by low lighting warning symbols ★♠ in both exterior mirrors. Reducing the speed again will extinguish the warning symbols. If a vehicle is then detected in the blind zone, the warning symbols ★♠ will illuminate as normal on the relevant side.

#### Deactivation

Activation or deactivation of the Side blind zone alert can be set in the vehicle personalisation menu in the Info-Display.

Vehicle personalisation ❖ 127. Info-Display ❖ 121.

Deactivation is indicated by a message in the Driver Information Centre.

#### **Detection zones**

The detection zones start at the rear bumper and extend approx. three metres rearwards and to the sides. The height of the zone is approx. between half a metre and two metres off the ground.

The system is deactivated if the vehicle is towing a trailer or if a bike carrier is attached.

Side blind spot alert is designed to ignore stationary objects, e.g. guardrails, posts, curbs, walls and beams. Parked vehicles or oncoming vehicles are not detected.

## **System limitations**

Occasional missed alerts can occur under normal circumstances and will increase in wet conditions.

The system may not operate properly when:

- Ice, snow, mud, stickers, magnets, metal plates, or anything else covers the sensors.
- Driving in heavy rainstorms.

- The vehicle had an accident or if the area surrounding the detection sensor is damaged or not properly repaired.
- There are extreme temperature changes.
- The vehicle is towing a trailer

In the event of a fault in the system or if the system does not work due to temporary conditions, the symbols in the mirrors will be permanently illuminated and a message is displayed in the Driver Information Centre. Seek the assistance of a workshop.

# Lane change alert

Additional to the side blind spot alert \$\phi\$ 215, lane change alert recognizes rapidly approaching vehicles from behind on parallel lanes next to your vehicle.

The system alerts visually in each exterior mirror when detecting rapidly approaching vehicles from behind.

The radar distance sensors are located in the rear bumper.


# **∆**Warning

Lane change alert does not replace driver vision.

Before changing a lane, always check all mirrors, look over the shoulder and use the turn signal.


When the system detects an approaching vehicle from behind which drives considerably faster, the yellow warning symbol \* will illuminate in the relevant exterior mirror. If the driver then activates the turn signal, the warning symbol \* starts flashing yellow as a warning not to change lanes.

Lane change alert is active at all speeds.



When the vehicle is started, both exterior mirror displays will briefly come on to indicate that the system is operating.

#### **Detection zones**



The system sensors cover a zone of approx. 3.5 metres parallel on both vehicle sides and approx. 3 metres rearwards on side blind zone alert (A) and approx. 50 metres rearwards on lane change alert (B) on parallel lanes. The zones start at each exterior mirror. The height of the zone is approx. between 0.5 metres and 2 metres off the ground.

#### Deactivation

Activation or deactivation of the lane change alert can be set in the vehicle personalisation menu in the Info-Display.

The system is deactivated if the vehicle is towing a trailer.

Deactivation is indicated by a message in the Driver Information Centre.

## System limitations

Occasional missed alerts can occur under normal circumstances or in sharp curves. The system can temporarily alert of objects in the blind spot at specific weather conditions (rain, hail etc). Driving on a wet road or in the transitions from a dry area to a wet area can cause the control indicator ★ to light up, as water splash can be interpreted as an object. Otherwise the control indicator \* may illuminate due to guardrails, signs, trees, shrubs or other immobile objects. This is normal operation and the system does not need to be serviced.

The system may not operate properly when:

- Ice, snow, mud, stickers, magnets, metal plates, or anything else covers the sensors.
- Driving in heavy rainstorms.
- The vehicle had an accident or if the area surrounding the detection sensor is damaged or not properly repaired.
- There are extreme temperature changes.
- The vehicle is towing a trailer

In the event of a fault in the system or if the system does not work due to temporary conditions, a message is displayed in the Driver Information Centre. Seek the assistance of a workshop.

#### Note

After production, the system requires a calibration. For optimal performance, drive as soon as possible on a straight highway road with roadside objects, e.g. guardrails and barriers for some distance.

# Panoramic view system

This system allows views of the vehicle's surroundings to be displayed as a nearly 360° picture in the Info Display, like a bird's eye view.

The system uses four cameras:

- rear camera, installed in the tailgate
- front camera, installed in the front grill below the emblem
- side cameras, located at the bottom of both exterior mirrors.



The screen in the Info Display is divided into two parts: on the left there is a view from above the vehicle, and

on the right there is the view from front or the rear displayed, according to the gear engaged. The parking sensors complete the information on the view.

#### Activation

Panoramic view system is activated:

- engaging reverse gear
- touching the camera icon o in the Info Display
- approaching too close to an object ahead

## **Functionality**

#### Rear view

Rear view displays an image of the area behind the vehicle on the right part of the screen when reverse gear is engaged.

A warning triangle  $\triangle$  may be displayed on the screen when obstacles are detected by the rear sensors of the parking assist. This triangle changes from yellow to red and increases in size the closer the object gets.

The previous content of the Info Display appears when the vehicle is shifted out of reverse gear after a short delay. To return to the previous display content sooner, press the camera icon in the Info Display. Driving faster than 11 km/h in a forward gear will deactivate the panoramic system also.

#### Surround view

Surround view displays an image of the area surrounding the vehicle from above, along with the front or rear camera views in the Info Display.

#### Front view

Front view displays an image of the area in front of the vehicle on the right part of the screen. The view displays after shifting from reverse gear to a forward gear, or by touching the camera icon in the Info Display. Front view also displays objects automatically detected within 30 cm. The front view is only displayed up to a speed of 11 km/h in a forward gear.

#### Deactivation

Panoramic view system is deactivated:

- driving faster than 11 km/h
- touching the camera icon o in the Info Display
- shifting into neutral or P with automatic transmission.

#### General information

# **△**Warning

The panoramic view system does not replace driver vision. It will not display children, pedestrians, cyclists, crossing traffic, animals, or any other objects outside of the camera view areas, e. g. below the bumper, or underneath the vehicle.

Do not drive or park the vehicle using only the panoramic view system.


Always check the surrounding of the vehicle before driving.

# **△**Warning

Displayed images may be further or closer than they appear. The area displayed is limited and objects that are close to either edge of the bumper or under the bumper are not displayed on the screen.

# **⚠**Warning

The panoramic view cameras have blind spot areas and will not display all objects near the edges of the vehicle. Folding side mirrors that are out of position will not display the panoramic view correctly.



Blind spots are represented as hatched areas in the illuminations. Dark areas show the views displayed by the panoramic view system.

# System limitations

#### Caution

For optimal operation of the system, it is important to keep the lenses of the cameras in the front grille, the housings of outside mirrors and in the tailgate between the number plate lights always clean. Rinse the lenses with water and wipe with a soft cloth.

Do not clean the lenses with a steam-jet or high-pressure jet cleaner.

The panoramic view system may not operate properly when:

- The surrounding is dark.
- The sun or the beam of headlights is shining directly into the camera lenses.
- During nighttime driving.
- Weather limits visibility, such as fog, rain, or snow.
- The camera lenses are blocked by snow, ice, slush, mud, dirt.
- The vehicle is towing a trailer.

- The vehicle had an accident.
- There are extreme temperature changes.

#### Rear view camera

The rear view camera assists the driver when reversing by displaying a view of the area behind the vehicle.

The view of the camera is displayed in the Info-Display.

# **△**Warning

The rear view camera does not replace driver vision. Note that objects that are outside the camera's field of view and the parking assist sensors, e.g. below the bumper or underneath the vehicle, are not displayed.

Do not reverse or park the vehicle using only the rear view camera.

Always check the surrounding of the vehicle before driving.

#### Activation

Rear view camera is automatically activated when reverse gear is engaged.

# **Functionality**




The camera is mounted between the number plate lights.



The area displayed by the camera is limited. The distance of the image that appears on the display differs from the actual distance.

#### Guidelines

Dynamic guidelines are horizontal lines at one metre intervals projected onto the picture to define the distance to displayed objects.



Trajectory lane of the vehicle is shown in accordance with the steering angle.

#### Warning symbols

Warning symbols are indicated as triangles  $\triangle$ on the picture, which show obstacles detected by the rear sensors of the advanced parking assist.

Additionally  $\triangle$ appears on the top line of the Info-Display with the warning to check the vehicle surrounding.

#### Deactivation

The camera is switched off when a certain forward speed is exceeded or if reverse gear is not engaged for approx. 10 seconds.

# Deactivation of guidelines and warning symbols



7" Colour-Info-Display: Activation or deactivation of the visual guiding lines and the warning symbols can be changed via touch buttons in the lower zone of the display.

8" Colour-Info-Display: Activation or deactivation of the visual guiding lines and the warning symbols can be

changed in the Settings menu in the Info-Display. Select the relevant setting in **Settings**, **▶ Rear Camera**.

# System limitations

The rear view camera may not operate properly when:


- The surrounding is dark.
- The sun or the beam of headlights is shining directly into the camera lenses.
- During nighttime driving.
- Weather limits visibility, such as fog, rain, or snow.
- The camera lenses are blocked by snow, ice, slush, mud, dirt.
   Clean the lense, rinse with water, and wipe with a soft cloth.
- The vehicle is towing a trailer.
- The vehicle had a rear end accident.
- There are extreme temperature changes.

Fault messages are displayed with a ∆on the top line of the Info-Display.

# Rear cross traffic alert

Additional to the rear view camera 

⇒ 221, rear cross traffic alert warns of cross traffic from left or right side when driving rearwards. When cross traffic is recognized and the rear view camera is activated, a warning triangle with a direction arrow △→ appears on the Colour-Info-Display, showing the direction of the traffic. Furthermore, three beeps will sound from the speaker on the respective side.



The radar distance sensors are located in the rear bumper.

# **△**Warning

The rear cross traffic alert does not replace driver vision. Note that objects that are outside sensors, e.g. below the bumper or underneath the vehicle, are not displayed.


Pedestrians, children or animals are not detected.

Do not reverse the vehicle by only looking at the Info-Display and check the surrounding behind and around the vehicle before reversing.

#### **Activation**

Rear cross traffic alert is automatically activated together with the rear view camera when reverse gear is engaged.

#### **Detection zones**



The system sensors cover a zone of approx. 20 metres at 90° to the left or right side behind the vehicle. Rear cross traffic alert is active up to 10 km/h and issues alerts within cross traffic travelling between 0 and 36 km/h.

#### Deactivation

Rear cross traffic alert is deactivated together with the rear view camera when a certain forward speed is exceeded or if reverse gear is not engaged for approx. 10 seconds.

Activation or deactivation of the rear cross traffic alert can be set in the vehicle personalisation menu in the Info-Display.

The system is deactivated if the vehicle is towing a trailer.

Deactivation is indicated by a message in the Driver Information Centre.

# System limitations

The system may not operate properly when:

- Ice, snow, mud, stickers, magnets, metal plates, or anything else covers the sensors.
- Driving in heavy rainstorms.
- The vehicle had an accident or if the area surrounding the detection sensor is damaged or not properly repaired.
- There are extreme temperature changes.
- The vehicle is towing a trailer

In the event of a fault in the system or if the system does not work due to temporary conditions, a message is displayed in the Driver Information Centre. Seek the assistance of a workshop.

# Traffic sign assistant

# **Functionality**

Traffic sign assistant detects designated traffic signs via a front camera and displays them in the Driver Information Centre.

If the vehicle is equipped with an embedded navigation system, traffic signs from data maps may be included additionally.



Traffic signs, which will be detected, are:

#### Limit and no passing signs

- speed limit
- no passing
- end of speed limit
- end of no passing

#### Road signs

Beginning and end of:

- city regions (country-specific)
- motorways
- A-roads
- play streets

#### Add on signs

- additional hints to traffic signs
- restriction of trailer towing
- tractor constraints
- wet warning
- ice warning
- time constraints
- distance constraints
- direction arrows

Speed limit signs and no passing signs are displayed in the Driver Information Centre until the next speed limit sign or end of speed limit is detected or up to a defined sign timeout.



Indication of multiple signs on the display is possible.



An exclamation mark in a frame indicates that there is an additional sign detected which cannot be clearly identified by the system.

The system operates without loss of performance up to a speed of 200 km/h depending on the lighting conditions. At night the system is active up to a speed of 160 km/h.

## **Display indication**

Information about the currently valid traffic signs is available on the designated traffic sign assistant page in the Driver Information Centre.



Additionally, the currently valid speed limit is displayed permanently in the lower line of the Driver Information Centre. In case a speed limit with add on sign is available, a + symbol is displayed in this area.



On Baselevel display, choose **Info** Menu so via **MENU** and select traffic sign assistant page with the adjuster wheel on the turn signal lever \$\display\$ 114.



On Mid- or Uplevel display, choose **Info** Menu via right steering wheel buttons and press ∇ or Δ to select traffic sign assistant page ♀ 114.

When another page on the Driver Information Centre menu was selected and then traffic sign assistant page is chosen again, the last recognised traffic sign will be displayed.

#### Alert function


The alert function can be activated or deactivated in the setting menu of the traffic sign assistant page.



Once activated and when the traffic sign detection page is currently not displayed, newly detected speed limit and no passing signs are displayed as pop-up alerts in the Driver Information Centre.



On Baselevel Display, when traffic sign assistant page is displayed, press **SET/CLR** on the turn signal lever.



Select **Alerts ON** or **Alerts OFF** by turning the adjuster wheel and press **SET/CLR**.

On Mid- or Uplevel Display, when traffic sign assistant page is displayed, press ➤ on the steering wheel controls.



Activate alerts by setting  $\square$ , deactivate alerts by setting  $\square$  via button  $\checkmark$ .

Pop-up alert is displayed for approx. eight seconds in the Driver Information Centre.

#### System reset

The content of the traffic sign display can be cleared in the setting menu of the traffic sign assistant page by selecting **Reset** and confirm by pressing **SET/CLR** on the turn signal lever or ✓ on the steering wheel controls.

Alternatively, SET/CLR or **✓** can be pressed for three seconds to clear the content of the page.

Upon successful reset, a chime will sound and the following "Default Sign" is indicated until the next traffic sign is detected or provided by map data of the navigation system.



In some cases, traffic sign assistant is cleared up automatically by the system.

# Clearing of traffic signs

There are different scenarios that lead to clearing the currently displayed traffic signs. After clearing, the "Default Sign" or a sign from navigation map data is displayed in the Driver Information Centre.

Reasons for signs being cleared:

- A predefined distance was driven or time has elapsed (differs for each sign type)
- Vehicle drives through a turn
- If no navigation map data is available and speed drops below 52 km/h (city entry detection)
- If navigation map data is available and a city entry/exit was detected due to map data change

# Traffic sign detection in conjunction with navigation system

If the vehicle is equipped with a navigation system, the currently displayed sign can either originate from optical sign detection or from the map data.

If the currently displayed sign originates from map data and the map information changes, a new sign will be displayed. This may lead to detection of a new sign although no sign on the road may have been passed.

## System limitations

Traffic sign assistant may not operate properly when:

- Vehicle speed is faster than 200 km/h.
- Driving on winding or hilly roads.
- During nighttime driving.
- Weather limits visibility, such as fog, rain, or snow.
- The sensor in the windscreen is blocked by snow, ice, slush, mud, dirt, windscreen damage or affected by foreign items, e.g. stickers.
- The sun is shining directly into the camera lens.
- Traffic signs are completely or partially covered or difficult to discern.

- Traffic signs are incorrectly mounted or damaged.
- Traffic signs do not comply with the Vienna Convention on Road Signs and Signals.
- The navigation map data is outdated.

#### Caution

The system is intended to help the driver within a defined speed range to discern certain traffic signs. Do not ignore traffic signs which are not displayed by the system.

The system does not discern any other than the conventional traffic signs that might give or end a speed limit.

Do not let this special feature tempt you into taking risks when driving.

Always adapt speed to the road conditions.

The driver assistance systems do not relieve the driver from full responsibility for vehicle operation.

# Lane keep assist

Lane keep assist helps to avoid crashes due to unintentional lane departures. The front camera observes the lane markings between which the vehicle is driving. If the vehicle approaches a lane marking, the steering wheel is gently turned to position the vehicle back into the lane. Turn steering wheel in same direction, if system steering is not sufficient. Turn steering wheel gently into opposite direction, if lane change is intended.

When crossing a lane marking significantly, lane keep assist starts a visual and acoustic warning.

Unintended lane departure is assumed

- without using turn signal
- using the turn signal in the opposite direction of the lane departure

- without braking
- without acceleration
- without active steering.

#### Note

The system is switched off during detection of ambiguous lane markings, e.g. in construction areas.

#### Note

The system may be switched off if it detects lanes which are too narrow, too wide or too curved.

#### Activation



The lane keep assist is activated by pressing A. The LED in the button illuminates to indicate that the system is switched on.



When the control indicator A in the instrument cluster or in the head-up display illuminates green, the system is ready to assist.

The system is operational at vehicle speeds between 60 km/h and 180 km/h and if lane markings are available.

The system gently turns the steering wheel and the control indicator (A) changes to yellow, if the vehicle approaches a detected lane marking without using the turn signal in that direction.

The system alerts by flashing A together with three chimes, from the respective direction, if the lane is departed significantly.

The system is only operable when a lane marking is detected.

If the system only detects lane markings on one side of the road, it will only assist for this side.

Lane keep assist detects hands-free driving. In this case a message in the Driver Information Centre pops-up and a chime sounds as long as lane keep assist detects hands-free driving.

#### Deactivation

The system is deactivated by pressing *i*⊕; the LED in the button extinguishes.

The system is deactivated automatically when a trailer is detected.

#### System limitations

The system performance may not operate properly when:

- Vehicle speed is out of range from 60 to 180 km/h.
- Driving on winding or hilly roads.
- During nighttime driving.

- Weather limits visibility, such as fog, rain, or snow.
- The sensor in the windscreen is blocked by snow, ice, slush, mud, dirt, windscreen damage or affected by foreign items, e.g. stickers.
- The sun is shining directly into the camera lens.
- Close vehicles ahead
- Banked roads
- Road edges
- Roads with poor lane markings
- Sudden lighting changes
- Vehicle modifications, e.g. tyres.

Switch off the system if the system is disturbed by tar marks, shadows, road cracks, temporary or construction lane markings, or other road imperfections.

# **△**Warning

Always keep your attention on the road and maintain proper vehicle position within the lane, otherwise vehicle damage, injury or death could occur.

Lane keep assist does not continuously steer the vehicle.

The system may not keep the vehicle in the lane or give an alert, even if a lane marking is detected.


The steering of the lane keep assist may not be sufficient to avoid a lane departure.

The system may not detect handsoff driving due to external influences (road condition and surface, weather etc). The driver has full responsibility to control the vehicle and is always required to keep the hands on the steering wheel while driving.

Using the system while towing a trailer or on slippery roads could cause loss of control of the vehicle and a crash. Switch the system off.

# **Fuel**

# Fuel for petrol engines



Only use unleaded fuel that complies with European standard EN 228 or equivalent.

The engine is capable of running with fuel that contains up to 10% ethanol (e.g. named E10).

Use fuel with the recommended octane rating. A lower octane rating can reduce engine power and torque and slightly increases fuel consumption.

#### Caution

Do not use fuel or fuel additives that contain metallic compounds such as manganese-based additives. This may cause engine damage.

#### Caution

Use of fuel that does not comply to EN 228 or equivalent can lead to deposits or engine damage.

#### Caution

Use of fuel with a lower octane rating than the lowest possible rating could lead to uncontrolled combustion and engine damage.

The engine specific requirements regarding octane rating are given in the engine data overview № 294. A country-specific label at the fuel filler flap can supersede the requirement.

#### Fuel additives outside Europe

Fuel should contain detergent additives that help prevent engine and fuel system deposits from forming. Clean fuel injectors and intake valves will allow the emission control system to work properly. Some fuel does not contain sufficient quantities of additive to keep fuel injectors and intake valves clean.

To make up for this lack of detergency, add Fuel System Treatment PLUS to the fuel tank at every engine oil change or every 15,000 km, whichever occurs first. It is available at your workshop.

Fuels containing oxygenates such as ethers and ethanol, as well as reformulated fuel, are available in some cities. If these fuels comply with the previously described specification, then they are acceptable to use. However, E85 (85% ethanol) and other fuels containing more than 15% ethanol must be used only in FlexFuel vehicles.

#### Caution

Do not use fuel containing methanol. It can corrode metal parts in the fuel system and also damage plastic and rubber parts. This damage would not be covered by the vehicle warranty.

Some fuels, mainly high octane racing fuels, can contain an octane enhancing additive called methylcyclopentadienyl manganese tricarbonyl (MMT). Do not use fuels or fuel additives with MMT as they can reduce spark plug life and affect emission control system performance. The malfunction indicator light 🖾 may illuminate 109. If this occurs, seek the assistance of a workshop.

# Fuel for diesel engines



Only use diesel fuel that complies with EN 590 and which has a sulphur concentration of max. 10 ppm.

Fuels with a biodiesel (compliant with EN 14214) content of max. 7% by volume may be used (e.g. named B7).

If travelling in countries outside the European Union occasional use of Euro-Diesel fuel with a sulphur concentration below 50 ppm is possible.

#### Caution

Frequent usage of diesel fuel containing more than 15 ppm sulphur will cause severe engine damage.

#### Caution

Use of fuel that does not comply to EN 590 or similar can lead to engine powerloss, increased wear or engine damage and may affect your warranty.

Do not use marine diesel oils, heating oils, Aquazole and similar dieselwater emulsions. Diesel fuels must not be diluted with fuels for petrol engines.

### Low temperature operation

At temperatures below 0° C, some diesel products with biodiesel blends may clog, freeze or gel, which may affect the fuel supply system. Starting and engine operation may not work properly. Make sure to fill winter grade diesel fuel at ambient temperatures below 0°C.

Arctic grade diesel fuel can be used in extreme cold temperatures below -20° C. Using this fuel grade in warm or hot climates is not recommended

and may cause engine stalling, poor starting or damage on the fuel injection system.

# Refuelling



# **∆**Danger

Before refuelling, switch off ignition and any external heaters with combustion chambers.

Follow the operating and safety instructions of the filling station when refuelling.

# **▲**Danger

Fuel is flammable and explosive. No smoking. No naked flames or sparks.

If you can smell fuel in your vehicle, have the cause of this remedied immediately by a workshop.

A label with symbols at the fuel filler flap is indicating the allowed fuel types. In Europe the pump nozzles of the filling stations are marked with these symbols. Refuel only the allowed fuel type.

#### Caution

In case of misfuelling, do not switch on ignition.

Fuel filler flap is located at right rear side of vehicle.



The fuel filler flap can only be opened if the vehicle is unlocked. Release the fuel filler flap by pushing the flap.

## Petrol and Diesel refuelling



Place the nozzle in straight position to the filler neck and press with slight force to insert.

To refuel, switch on pump nozzle.

After the automatic cut-off, the tank can be topped up by operating the pump nozzle a maximum of two more times.

#### Caution

Wipe off any overflowing fuel immediately.

Close the flap and allow it to engage.

#### Misfuel inhibitor

# **⚠** Warning

Do not try to open the flap of the fuel filler neck manually on vehicles with misfuel inhibitor

Disregarding this could lead to trapping of the fingers.

All vehicles are equipped with a misfuel inhibitor



The misfuel inhibitor ensures that the flap of the fuel filler neck can only be opened by using the suitable fuel nozzle or a funnel for emergency refilling.

In case of an emergency, refill with a canister. A funnel must be used to open the cap of the filler neck.



The funnel may be stowed in the load compartment or the glovebox.

Place the funnel in straight position to the filler neck and press with slight force to insert.

After topping-up, clean funnel from fuel remains and stow it away.

# Trailer hitch

# General information

The factory-fitted towing equipment is folded up under the rear bumper fascia.

Entrust retrofitting of towing equipment to a workshop. It may be necessary to make changes that affect the cooling system, heat shields or other equipment. Only use towing equipment that has been approved for your vehicle.

To avoid vehicle damage, the power tailgate cannot be operated with the electronic key when a trailer is electrically connected.

The bulb outage detection function for trailer brake light cannot detect a partial bulb outage, e.g. in case of four times five watt bulbs, the function only detects lamp outage when only a single five Watt lamp remains or none remain.

Fitting of towing equipment could cover the opening of the towing eye. If this is the case use the coupling ball bar for towing.

# Driving characteristics and towing tips

Before attaching a trailer, lubricate the coupling ball. However, do not do so if a stabiliser, which acts on the coupling ball, is being used to reduce snaking movements.

During trailer towing do not exceed a speed of 80 km/h. A maximum speed of 100 km/h is only appropriate if an oscillation damper is used and the permissible gross trailer weight does not exceed the vehicle's kerb weight.

For trailers with low driving stability and caravan trailers, the use of an oscillation damper is strongly recommended.

If the trailer starts snaking, drive more slowly, do not attempt to correct the steering and brake sharply if necessary.

When driving downhill, drive in the same gear as if driving uphill and drive at a similar speed.

# Trailer towing

#### **Trailer loads**

The permissible trailer loads are vehicle and engine-dependent maximum values which must not be exceeded. The actual trailer load is the difference between the actual gross weight of the trailer and the actual coupling socket load with the trailer coupled.

The permissible trailer loads are specified in the vehicle documents. In general, they are valid for gradients up to 12%.

The permissible trailer load applies up to the specified incline and at sea level. Since engine power decreases as altitude increases due to the air becoming thinner, therefore reducing climbing ability, the permissible gross train weight also decreases by 10% for every 1000 metres of altitude. The gross train weight does not have to be reduced when driving on roads with slight inclines (less than 8%, e.g. motorways).

## Vertical coupling load

The vertical coupling load is the load exerted by the trailer on the coupling ball. It can be varied by changing the weight distribution when loading the trailer.

The maximum permissible vertical coupling load of:

- 60 kg (Grand Sport with all engines except B20DTH / B20NFT / D20DTR)
- 75 kg (Sports Tourer, Country Tourer with all engines except B20DTH / B20NFT / D20DTR)
- 90 kg (All bodystyles with engines B20DTH / B20NFT / D20DTR)

is specified on the towing equipment identification plate and in the vehicle documents. Always aim for the maximum load, especially in the case of heavy trailers. The vertical coupling load should never fall below 25 kg.

#### Rear axle load

When the trailer is coupled and the towing vehicle fully loaded, the permissible rear axle load (see identification plate or vehicle documents) may be exceeded by 70 kg (engines B20DTH: 80 kg), the gross vehicle weight rating must not be exceeded. If the permissible rear axle load is exceeded, a maximum speed of 100 km/h applies.

# Towing equipment

#### Caution

The folding coupling ball bar cannot be removed from the vehicle. When driving without a trailer, fold in the coupling ball bar.

# **⚠**Warning


Make sure that no one is in the pivot zone of the coupling ball bar. Risk of body injury.

When releasing the stowed coupling ball bar, make sure to stand left of the grip.

# Release stowed coupling ball bar



Pull the grip located left to the number plate under the rear bumper fascia at an angle of approx. 45° to the ground.



A buzzing tone sounds as a warning when the release handle is pulled out and the ball neck is disengaged.

Take the released coupling ball bar and raise it up until it engages.

Ensure the coupling ball bar is correctly engaged and the released handle is guided back to its hidden initial position, otherwise the buzzing tone will not stop.

# Stow/hide coupling ball bar



Pull the grip located left of the number plate under the rear bumper fascia at an angle of approx. 45° to the ground.



A buzzing tone sounds as a warning when the release handle is pulled out and the ball neck is disengaged.



With the flat of the hand, swivel the released coupling ball bar to the right until it engages under the floor. Make sure that the release handle is back in its hidden initial position, otherwise the buzzing tone will not stop.

# **△**Warning

Towing a trailer is permitted only when the coupling ball bar is fitted correctly. If the coupling ball bar does not engage correctly or if the release handle is impossible to guide to its hidden initial position in the housing or if the buzzing tone sounds after engaging the coupling ball bar, seek the assistance of a workshop.

Eye for break-away stopping cable Attach break-away stopping cable to eye.

# Trailer stability assist

If the system detects snaking movements, engine power is reduced and the vehicle/trailer combination is selectively braked until the snaking ceases. While the system is working keep steering wheel as still as possible.

# Vehicle care

General Information	239
Accessories and vehicle	
modifications	
Vehicle storage	
End-of-life vehicle recovery	
Vehicle checks	
Performing work	
Bonnet	
Engine oil	
Engine coolant	
Washer fluid	
Brakes	244
Brake fluid	
Vehicle battery	245
Diesel fuel system bleeding	
Wiper blade replacement	
Bulb replacement	
Halogen headlights	247
LED headlights	249
Fog lights	
Tail lights	
Side turn lights	
Number plate light	257
Interior lights	
Instrument panel illumination.	25/

Electrical system	. 257
Fuses	. 257
Engine compartment fuse box	. 258
Instrument panel fuse box	. 261
Vehicle tools	. 262
Tools	
Wheels and tyres	. 263
Winter tyres	
Tyre designations	. 264
Tyre pressure	
Tyre pressure monitoring	
system	. 265
Tread depth	
Changing tyre and wheel size.	268
Wheel covers	
Tyre chains	
Tyre repair kit	. 269
Wheel changing	
Spare wheel	. 276
Jump starting	. 278
Towing	. 279
Towing the vehicle	
Towing another vehicle	
Appearance care	
Exterior care	. 281
Interior care	
	0

# **General Information**

# Accessories and vehicle modifications

We recommend the use of genuine parts and accessories and factory approved parts specific for your vehicle type. We cannot assess or guarantee reliability of other products - even if they have a regulatory or otherwise granted approval.

Any modification, conversion or other changes made to standard vehicle specifications (including, without limitation, software modifications, modifications of the electronic control units) may invalidate the warranty offered by Opel. Furthermore, such changes may affect driver assistance systems, fuel consumption, CO<sub>2</sub> emissions and other emissions of the vehicle. They may also invalidate the vehicle operating permit.

#### Caution

When transporting the vehicle on a train or on a recovery vehicle, the mud flaps might be damaged.

# Vehicle storage

# Storage for a long period of time

If the vehicle is to be stored for several months:

- Wash and wax the vehicle.
- Have the wax in the engine compartment and underbody checked.
- Clean and preserve the rubber seals.
- Fill up fuel tank completely.
- Change the engine oil.
- Drain the washer fluid reservoir.
- Check the coolant antifreeze and corrosion protection.
- Adjust tyre pressure to the value specified for full load.

- Park the vehicle in a dry, well ventilated place. Engage first or reverse gear or set selector lever to P. Prevent the vehicle from rolling.
- Do not apply the parking brake.
- Open the bonnet, close all doors and lock the vehicle.
- Disconnect the clamp from the negative terminal of the vehicle battery. Beware that all systems are not functional, e.g. anti-theft alarm system.

# Putting back into operation


When the vehicle is to be put back into operation:

- Connect the clamp to the negative terminal of the vehicle battery. Activate the electronics of the power windows.
- Check tyre pressure.
- Fill up the washer fluid reservoir.
- Check the engine oil level.
- Check the coolant level.
- Fit the number plate if necessary.

# End-of-life vehicle recovery

Information on end-of-life vehicle recovery centres and the recycling of end-of-life vehicles is available on our website, where legally required. Only entrust this work to an authorised recycling centre.

# Vehicle checks Performing work



# **△**Warning

Only perform engine compartment checks when the ignition is off.

The cooling fan may start

operating even if the ignition is off.

# **⚠** Danger


The ignition system uses extremely high voltage. Do not touch.

# **Bonnet**

# Opening



Pull the release lever and return it to its original position.



Move the safety catch sideways to the left vehicle side and open the bonnet.

The bonnet is held open automatically.

If the bonnet is opened during an Autostop, the engine will be restarted automatically for safety reasons.

# Closing

Lower the bonnet and let it fall into the latch. Check that the bonnet is engaged.

#### Caution


Do not press the bonnet into the latch to avoid dents.

Active bonnet \$\frac{1}{2}\$ 71.


# Engine oil

The maximum engine oil consumption is 0.6 litres per 1000 km.


Check with the vehicle on a level surface. The engine must be at operating temperature and switched off for at least five minutes.



Pull out the dipstick, wipe it clean, reinsert fully, pull out and read the engine oil level.



Different dipsticks are used depending on engine variant.



We recommend the use of the same grade of engine oil that was used at last change.



When the engine oil level has dropped to the **MIN** mark, top up engine oil.

The engine oil level must not exceed the **MAX** mark on the dipstick.

#### Caution

Wipe off any spilled engine oil immediately.

#### Caution

Overfilled engine oil must be drained or suctioned out.

Fit the cap on straight and tighten it.

# Engine coolant

The coolant provides freeze protection down to approx. -28 °C. In cold regions with very low temperatures, the factory filled coolant provides frost protection down to approx. -37 °C.


#### Caution

Only use approved antifreeze.


#### Coolant level

#### Caution

Too low a coolant level can cause engine damage.



If the cooling system is cold, the coolant level should be above the filling line mark. Top up if the level is low.



Depending on the engine, the position of the coolant container may be different.

# **△**Warning

Allow the engine to cool before opening the cap. Carefully open the cap, relieving the pressure slowly.

To top up, use a 1:1 mixture of released coolant concentrate mixed with clean tap water. If no coolant concentrate is available, use clean tap water. Install the cap tightly. Have the coolant concentration checked and have the cause of the coolant loss remedied by a workshop.

# Washer fluid



Fill with clean water mixed with a suitable quantity of approved windscreen washer fluid which contains antifreeze.

#### Caution

Only washer fluid with a sufficient antifreeze concentration provides protection at low temperatures or a sudden drop in temperature.

Washer fluid \$\triangle 286.

#### **Brakes**

In the event of minimum thickness of the brake lining, a squealing noise sounds during braking.


Continued driving is possible but have the brake lining replaced as soon as possible.

Once new brake linings are installed, do not brake unnecessarily hard for the first few journeys.

#### **Brake fluid**

# **⚠**Warning

Brake fluid is poisonous and corrosive. Avoid contact with eyes, skin, fabrics and painted surfaces.



The brake fluid level must be between the **MIN** and **MAX** marks.

If fluid level is below **MIN** seek the assistance of a workshop.

Brake and clutch fluid \$ 286.

# Vehicle battery

The vehicle battery is located in the engine compartment.

The vehicle battery is maintenancefree provided that the driving profile allows sufficient charging of the battery. Short-distance-driving and frequent engine starts can discharge the battery. Avoid the use of unnecessary electrical consumers.



Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.

Laying up the vehicle for more than four weeks can lead to battery discharge. Disconnect the clamp from the negative terminal of the vehicle battery.

Ensure the ignition is switched off before connecting or disconnecting the vehicle battery.

## Disconnecting the battery

If the vehicle's battery is to be disconnected (e.g. for maintenance work), the alarm siren must be deactivated as follows: Switch the ignition on then off, then disconnect the vehicle's battery within 15 seconds.

# Replacing the vehicle battery

#### Note

Any deviation from the instructions given in this section may lead to temporary deactivation or disturbance of the stop-start system.

When the vehicle battery is being replaced, please ensure that there are no open ventilation holes in the vicinity of the positive terminal. If a ventilation hole is open in this area, it must be closed off with a dummy cap, and the ventilation in the vicinity of the negative terminal must be opened.

Ensure that the battery is always replaced by the same type of battery.

We recommend that you have the vehicle battery replaced by a workshop.

# Charging the vehicle battery

# **△**Warning

On vehicles with stop-start system, ensure that the charging potential does not exceed 14.6 volts when using a battery charger. Otherwise the vehicle battery might be damaged.

## Warning label



Meaning of symbols:


- No sparks, naked flames or smoking.
- Always shield eyes. Explosive gases can cause blindness or injury.
- Keep the vehicle battery out of reach of children.
- The vehicle battery contains sulphuric acid which could cause blindness or serious burn injuries.
- See the Owner's Manual for further information.
- Explosive gas may be present in the vicinity of the vehicle battery.

# Diesel fuel system bleeding

If the tank has been run dry, the diesel fuel system must be bled. Switch on the ignition three times for 15 seconds at a time. Then crank the engine for a maximum of 40 seconds. Repeat this process after no less than five seconds. If the engine fails to start, seek the assistance of a workshop.

# Wiper blade replacement

#### Windscreen




Lift the wiper arm until it stays in the raised position. Lift retaining clip to disengage the wiper blade and remove.

Attach the wiper blade slightly angled to the wiper arm and push until it engages.

Lower wiper arm carefully.

#### Rear window

#### **Grand Sport**




Lift the wiper arm until it stays in the raised position, press button to disengage the wiper blade and remove.

Attach the wiper blade slightly angled to the wiper arm and push until it engages.

Lower wiper arm carefully.

## Sports Tourer, Country Tourer



Lift wiper arm. Disengage wiper blade as shown in illustration and remove.

Attach the wiper blade slightly angled to the wiper arm and push until it engages.

Lower wiper arm carefully.

# Bulb replacement

Switch off the ignition and switch off the relevant switch or close the doors.

Only hold a new bulb at the base. Do not touch the bulb glass with bare hands.

Use only the same bulb type for replacement.


Replace headlight bulbs from within the engine compartment.

#### **Bulb check**

After a bulb replacement switch on the ignition, operate and check the lights.


# Halogen headlights

Halogen headlights with separate bulbs for low beam and high beam.



Low beam (1) outer bulb. High beam (2) inner bulb.


# Low beam (1)



1. Rotate the cap anticlockwise and remove it.



Disengage bulb holder by pressing the retainer to the front. Withdraw the bulb holder from the reflector housing.



- 3. Detach the bulb from the bulb holder and replace the bulb.
- 4. Insert the bulb holder.
- 5. Fit the cap and rotate clockwise.


# High beam (2)



 Rotate the cap anticlockwise and remove it.



Disengage bulb holder by pressing the retainer to the front. Withdraw the bulb holder from the reflector housing.



- 3. Detach the bulb from the bulb holder and replace the bulb.
- 4. Insert the bulb holder.
- 5. Fit the cap and rotate clockwise.

## Front turn signal light

In case of defective LEDs, have them replaced by a workshop.

# Side light

In case of defective LEDs, have them replaced by a workshop.

#### Daytime running light

In case of defective LEDs, have them replaced by a workshop.

# LED headlights

Headlights for low and high beam, sidelights, daytime running lights and turn signal lights are designed as LEDs and cannot be changed.

Have lights repaired by a workshop in case of failure.

# Fog lights

1. Grand Sport, Sports Tourer



Wrap a cloth around the tip of a flat screwdriver to prevent paint damage. Insert the screwdriver in the recess at the edge of the cover. Release the cover by levering it out carefully.

#### **Country Tourer**



Undo the screw with a torx screwdriver.

#### 2. Grand Sport, Sports Tourer



Undo screw with the torx screwdriver and remove the faceplate.

#### **Country Tourer**



Wrap a cloth around the tip of the flat screwdriver to prevent paint damage. Lever out the faceplate by inserting the screwdriver in the recess and remove it.



Undo three screws with the torx screwdriver and remove the light assembly to the front.



 Turn the bulb socket anticlockwise and remove it from the light assembly.



5. Disengage the plug connector by pressing the retaining lug.

- Remove and replace the bulb unit and attach the plug connector. Note that the bulb and the socket are one unit and have to be changed together.
- Insert the bulb socket into the light assembly by turning clockwise and engage.
- 8. Mount the light assembly by tightening the three screws.
- 9. Attach the faceplate and tighten the screw.
- Grand Sport, Sports Tourer
   Attach and engage the cover.

# Tail lights

Tail lights and brake lights are designed as LEDs. In case of failure, have LEDs replaced by a workshop.

Turn signal lights, rear fog lights and reverse lights are designed for bulbs and can be changed as follows.

### **Grand Sport**

Light assembly in the body



1. Remove the cover on the respective side.




2. Unscrew the two plastic securing nuts from the inside by hand.



 Carefully withdraw tail light assembly from recess and remove. Take care that the cable duct remains in position.



 Turn the turn signal light bulb socket anticlockwise and remove it from the light assembly.



5. Remove and replace the turn signal light bulb.

- Attach the bulb socket to the light assembly.
- Attach the light assembly to the vehicle body and tighten the securing nuts from the inside of the load compartment. Attach cover.

#### Light assembly in the tailgate




1. Release the cover in the tailgate and remove it.




2. Unscrew the plastic securing nut by hand.




 Carefully withdraw the light assembly from the recesses and remove. Take care that the cable duct remains in position.



- 4. Turn the bulb socket anticlockwise and remove it from the light assembly.
  - Rear fog light (1)
  - Reverse light (2)
- 5. Detach the bulb from the bulb socket and replace the bulb.



Rear fog light



#### Reverse light


 Insert the bulb socket into the tail light assembly. Fit light assembly on the tailgate and tighten the screw from the inside. Attach cover.

#### Sports Tourer, Country Tourer

Light assembly in the body




 Open the covers with screwdriver. Unscrew and remove both screws.



Carefully withdraw tail light assembly from recess and remove. Take care that the cable duct remains in position.



Turn the turn signal light bulb socket anticlockwise and remove it from the light assembly.



- 4. Detach the bulb from the bulb socket and replace the turn signal light bulb.
- 5. Attach the bulb socket to the light assembly.
- Attach the light assembly to the vehicle body and tighten the screws. Close covers.

Light assembly in the tailgate




1. Release the cover in the tailgate and remove it.



2. Unscrew the plastic securing nut by hand.



Carefully withdraw the light assembly from the recesses and remove. Take care that the cable duct remains in position.




 Turn the bulb socket anticlockwise and remove it from the light assembly.


Rear fog light (1)

Reverse light (2)

5. Detach the bulb from the bulb socket and replace the bulb.



Rear fog light




### Reverse light

 Insert the bulb socket into the tail light assembly. Fit light assembly on the tailgate and tighten the screw from the inside. Attach cover.

# Side turn lights


To replace bulb, remove lamp housing:



1. Slide lamp to its left side and remove with its right end.



2. Turn bulb holder anticlockwise and remove from housing.



3. Pull bulb from bulb holder and replace it.

- 4. Insert bulb holder and turn clockwise.
- 5. Insert left end of the lamp, slide to the left and insert right end.

# Number plate light

The number plate light is designed as LEDs and can not be changed. In case of defective LEDs, have them replaced by a workshop.

# Interior lights

#### Courtesy light, reading lights

Have bulbs replaced by a workshop.

#### Load compartment light

Have bulbs replaced by a workshop.

# Instrument panel illumination

Have bulbs replaced by a workshop.

# Electrical system

#### **Fuses**

Data on the replacement fuse must match the data on the defective fuse.

There are three fuse boxes in the vehicle:

- engine compartment
- instrument panel

Before replacing a fuse, turn off the respective switch and the ignition.


A blown fuse can be recognised by its melted wire.

#### Caution

Do not replace the fuse until the cause of the fault has been remedied.

Some functions are protected by several fuses.


Fuses may also be inserted without existence of a function.






#### **Fuse extractor**

A fuse extractor may be located in the fuse box in the engine compartment.




Place the fuse extractor on the various types of fuse from the top or side, and withdraw fuse.

# Engine compartment fuse box



The fuse box is in the front left of the engine compartment.

Disengage the cover and remove it.



No.	Circuit	No.	Circuit	No.	Circuit
1	-	18	Sunblind	35	Damping/All-wheel drive
2	-	19	Power seat, driver	36	Fuel system
3	ABS	20	-	37	-
4	-	21	Sunroof	38	-
5	-	22	Rear wiper/Airbag	39	-
6	Tailgate	23	Adaptive forward lighting	40	Steering wheel lock
7	Fog light	24	-	41	-
8	Memory module	25	-	42	-
9	Heated windscreen	26	Transmission control module	43	Heated steering wheel
10	Seat lumbar	27	Ignition/Instrument panel	44	Headlight range adjustment
11	DC/DC battery	28	-	45	-
12	Heated rear window	29	Rear view camera/Air vent	46	Engine control module
13	Heated mirror	30	Malfunction indicator light/	47	-
14	-		Trailer	48	DC/DC converter/Air vent/E-
15	_	31	-		Boost
16	Front wiper	32	Camera	49	Rear door control module
17	Power seat, passenger	33	Seat heat front	50	-
''	i ower seat, passenger	34	Seat heat rear	51	_

260


No. Circuit	No. Circuit	No. Circuit
52 -	69 Right high beam (Halogen)/	86 –
53 –	Right headlight (LED)	87 Diesel fuel heating
54 –	70 Left high beam (Halogen)	88 Air shutter
55 –	71 –	89 –
56 Starter	72 Starter	90 –
57 –	73 –	91 –
58 –	74 Transmission control module	92 After boil pump
59 Left headlight (LED)	75 Engine control module	93 Electronic key system
60 Cooling fan	76 Exhaust reduction system	94 –
61 –	77 –	95 Coolant pump
	78 Horn	
62 –	79 Washer system	96 Diesel fuel heating
63 -	80 -	97 –
64 –	81 Engine control module	98 –
65 Climate control	82 -	99 Coolant pump
66 –		After having changed defective fuses,
67 –	o o	close the fuse box cover and press until it engages.
68 –	84 Ignition coil	If the fuse box cover is not closed
	85 Powertrain	correctly, malfunction may occur.

# Instrument panel fuse box




In left-hand drive vehicles, the fuse box is behind a cover in the instrument panel.

Disengage cover at the side and remove.



In right-hand drive vehicles, the fuse box is located behind a cover in the glovebox. Open the glovebox and remove the cover.



#### No. Circuit

- Left power window
- 2 Right power window
- 3 Body control module
- 4 Climate control fan
- 5 Body control module
- 5 Trailer provisions
- 7 Rear seat power folding
- 8 Body control module
- 9 Engine control module
- 10 Head-up display
- 11 NO<sub>x</sub> reduction/Pipe heater
- 12 NO<sub>x</sub> reduction/Soot sensor
- 13 UREA module
- 14 Heated steering wheel
- 15 Transmission control module
- 16 Amplifier
- 17 Alarm

# No. Circuit Body control module URFA module Body control module Body control module Body control module Electric steering wheel lock Airbag Diagnostic connector Power outlet load compartment EBCM valve Police provision 29 30 Steering wheel controls Ignition switch Climate control Central gateway module


#### No. Circuit

- 35 AUX/USB connector
- 36 Wireless charger
- 37 Rear wiper
- 38 Onstar
- 39 Display
- 40 Parking assist
- 41 Overhead console
- 42 Radio

# Vehicle tools

#### **Tools**

#### Vehicles with spare wheel



The jack with wheel wrench, the tools, an extension bolt for securing a damaged wheel and the towing eye are placed in the tool box below the spare wheel in the load compartment. Spare wheel ▷ 276.

#### Vehicles without spare wheel



The screwdriver and the towing eye are located in a box below the floor cover in the load compartment.

Tyre repair kit ♦ 269.

#### Vehicles with audio speaker system



The screwdriver and the towing eye are located below the floor cover in the load compartment, beside the round speaker system component.

Tyre repair kit 

≥ 269.

# Wheels and tyres

#### Tyre condition, wheel condition

Drive over edges slowly and at right angles if possible. Driving over sharp edges can cause tyre and wheel damage. Do not trap tyres on the kerb when parking.

Regularly check the wheels for damage. Seek the assistance of a workshop in the event of damage or unusual wear.

# Winter tyres

Winter tyres improve driving safety at temperatures below 7 °C and should therefore be fitted on all wheels.

In accordance with country-specific regulations, affix the speed sticker in the driver's field of view.

All tyre sizes are permitted as winter tyres \$\dip\$ 304.

# GSi with Michelin Pilot Super Sport or Pilot Sport 4 S tyres

This model is factory-fitted with high performance sports tyres, which have a reduced performance at low temperature.

## **⚠** Danger

Use winter tyres at temperatures below 0 °C, otherwise damage of the high performance sports tyres is possible.

# Tyre designations

E.g. **215/60 R 16 95 V** 

215: tyre width, mm

60 : cross-section ratio (tyre height

to tyre width), %

R : belt type: Radial RF : type: RunFlat

16 : wheel diameter, inches

95 : load index e.g. 95 is equivalent to 690 kg

speed code letter

Speed code letter:

Q: up to 160 km/hS: up to 180 km/h

: up to 190 km/h

H: up to 210 km/h V: up to 240 km/h W: up to 270 km/h

Choose a tyre appropriate for the maximum speed of your vehicle.

The maximum speed is achievable at kerb weight with driver (75 kg) plus 125 kg payload. Optional equipment could reduce the maximum speed of the vehicle.

## Directional tyres

Directional tyres should be mounted so that they rotate in the correct direction. The proper rotation direction is indicated by a symbol (e.g. an arrow) on the sidewall.

# Tyre pressure

Check the pressure of cold tyres at least every 14 days and before any long journey. Do not forget the spare wheel. This also applies to vehicles with tyre pressure monitoring system.



The tyre pressure information label on the left door frame indicates the original equipment tyres and the correspondent tyre pressures.

The tyre pressure data refers to cold tyres. It applies to summer and winter tyres.

Always inflate the spare tyre to the pressure specified for full load.

The ECO tyre pressure serves to achieve the smallest amount of fuel consumption possible.

Make sure tyre loading setting matches the current tyre pressure. Tyre loading ♦ 265.

Incorrect tyre pressures will impair safety, vehicle handling, comfort and fuel economy and will increase tyre wear.

Tyre pressures differ depending on various options. For the correct tyre pressure value, follow the procedure below:

- 1. Identify drive axle and body style.
- 2. Identify the engine identifier code. Engine data \$\dip\$ 294.
- 3. Identify the respective tyre.

The tyre pressure tables show all possible tyre combinations ▷ 304.

For the tyres approved for your vehicle, refer to the EEC Certificate of Conformity provided with your vehicle or other national registration documents.

The driver is responsible for correct adjustment of tyre pressure.

#### **△**Warning

If the pressure is too low, this can result in considerable tyre warmup and internal damage, leading to tread separation and even to tyre blow-out at high speeds.

## **△**Warning

For specific tyres the recommended tyre pressure as shown in the tyre pressure table may exceed the maximum tyre pressure as indicated on the tyre. Never exceed the maximum tyre pressure as indicated on the tyre.

#### Temperature dependency

The tyre pressure depends on the temperature of the tyre. During driving, tyre temperature and pressure increase. Tyre pressure

values provided on the tyre information label and tyre pressure chart are valid for cold tyres, which means at 20 °C.

The pressure increases by nearly 10 kPa for a 10 °C temperature increase. This must be considered when warm tyres are checked.

The tyre pressure value displayed in the Driver Information Centre shows the real tyre pressure. A cooled down tyre will show a decreased value, which does not indicate an air leak.

# Tyre pressure monitoring system

The tyre pressure monitoring system checks the pressure of all four wheels once a minute when vehicle speed exceeds a certain limit.

#### Caution


Tyre pressure monitoring system warns just about low tyre pressure condition and does not replace regular tyre maintenance by the driver.

All wheels must be equipped with pressure sensors and the tyres must have the prescribed pressure.

#### Note

In countries where the tyre pressure monitoring system is legally required, the use of wheels without pressure sensors will invalidate the vehicle operating permit.

Select the **Tyre pressure monitoring** page under the **Info** Menu in the Driver Information Centre ❖ 114.



System status and pressure warnings are displayed by a message indicating the corresponding tyre in the Driver Information Centre.

The system considers the tyre temperature and the tyre loading setting for the warnings.

Tyre loading setting, see below in this chapter.

Baselevel display: If the pressure of a tyre decreases significantly, the respective tyre pressure value is displayed inverted.

Midlevel and uplevel display: Tyre pressure values in normal range are shown in green letters. If the pressure of a tyre decreases significantly, the respective value will turn its colour to amber.



A detected low tyre pressure condition is indicated by the control indicator ⊕ > 111.

If ① illuminates, stop as soon as possible and inflate the tyres as recommended ▷ 304.

Ensure that vehicle loading status matches selected tyre pressure. Vehicle loading status, see below in this chapter.

After inflating, some driving may be required to update the tyre pressure values in the Driver Information Centre. During this time (!) may continue to illuminate.

If ① illuminates at lower temperatures and extinguishes after some driving, this could be an indicator for approaching a low tyre pressure condition. Check tyre pressure.

Only mount wheels with pressure sensors, otherwise the tyre pressure will not be displayed and (!) illuminates continuously.

A spare wheel or temporary spare wheel is not equipped with pressure sensors. The tyre pressure monitoring system is not operational for these wheels. Control indicator (!)

illuminates. For the further three wheels the system remains operational.

The use of commercially available liquid tyre repair kits can impair the function of the system. Factoryapproved repair kits can be used.

Operating electronic devices or being close to facilities using similar wave frequencies could disrupt the tyre pressure monitoring system.

Each time the tyres are replaced tyre pressure monitoring system sensors must be dismounted and serviced. For the screwed sensor replace valve core and sealing ring, for clipped sensor replace complete valve stem.

Use only original plastic valve caps to protect valve on any damage.

#### Caution

Do not use metal valve caps as they lead to valve oxidation and damage.

#### Vehicle loading status

Adjust tyre pressure to load condition according tyre information label or tyre pressure chart \$\phi\$ 304, and select the appropriate setting in the **Tyre loading** page under the **Settings** menu in the Driver Information Centre \$\phi\$ 114. This setting determines the reference pressures for the tyre pressure warnings.

Depending on the display, the menu **Tyre loading** only appears if the vehicle is at a standstill and the parking brake is applied. On vehicles with automatic transmission the selector lever must be in **P**.



#### Select:

- Light for comfort pressure up to 3 people.
- **Eco** for Eco pressure up to 3 people.
- Max for full loading.

#### Auto learn function

After changing wheels or wheel positions the vehicle must be stationary for approx. 20 minutes, before the system recalculates. The following relearn process takes up to 10 minutes of driving in a speed range of 40 to 100 km/h. Avoid to drive outside of this range for a longer time. If possible, use a country road or similar which allows continuous driving. During relearn process — can be displayed or pressure values can swap in the Driver Information Centre.

If problems occur during the relearn process, a failure message is displayed in the Driver Information Centre. ① will flash for 60 seconds and then illuminate continuously.

If this happens, repeat learning process. Keep your vehicle stationary for approx. 20 minutes and then drive again for 10 minutes as described above.

# Tread depth

Check tread depth at regular intervals.

Tyres should be replaced for safety reasons at a tread depth of 2-3 mm (4 mm for winter tyres).

For safety reasons, it is recommended that the tread depth of the tyres on one axle should not vary by more than 2 mm.



The legally permissible minimum tread depth (1.6 mm) has been reached when the tread has worn down as far as one of the tread wear indicators (TWI). Their position is indicated by markings on the sidewall.

If there is more wear at the front than the rear, swap round front wheels and rear wheels periodically. Ensure that the direction of rotation of the wheels remains the same.

Tyres age, even if they are not used. We recommend tyre replacement every 6 years.

# Changing tyre and wheel size

If tyres of a different size than those fitted at the factory are used, it may be necessary to reprogramme the speedometer as well as the nominal tyre pressure and make other vehicle modifications.

After converting to a different tyre size, have the label with tyre pressures replaced and the tyre pressure monitoring system reinitialised. \$\display 265

## **△**Warning

The use of unsuitable tyres or wheels may lead to accidents and will invalidate the vehicle operating permit.

#### Wheel covers

Wheel covers and tyres that are factory approved for the respective vehicle and comply with all of the relevant wheel and tyre combination requirements must be used.

If the wheel covers and tyres used are not factory approved, the tyres must not have a rim protection ridge.

Wheel covers must not impair brake cooling.

### **△**Warning

Use of unsuitable tyres or wheel covers could lead to sudden pressure loss and thereby accidents.

Vehicles with steel wheels: When using locking wheel nuts, do not attach wheel covers.

# Tyre chains



Tyre chains are only permitted on the front wheels.

Always use fine mesh chains that add no more than 10 mm to the tyre tread and the inboard sides (including chain lock).

## **△**Warning

Damage may lead to tyre blowout.

Tyre chains are only permitted on tyres of size 215/60 R16, 215/55 R17, 225/55 R17 and 235/45 R18.

#### Temporary spare wheel

The use of tyre chains is not permitted on the temporary spare wheel.

# Tyre repair kit

Minor damage to the tyre tread can be repaired with the tyre repair kit.


Do not remove foreign bodies from the tyres.

Tyre damage exceeding 4 mm or that is at tyre's side wall cannot be repaired with the tyre repair kit.

#### **△**Warning

Do not drive faster than 80 km/h. Do not use for a lengthy period. Steering and handling may be affected.

Two types of tyre repair kit are available:




 Type 1 indicated by the on/off switch at the top of the compressor.



 Type 2 indicated by the on/off switch at the side of the compressor.

If vehicle has a flat tyre:

Apply the parking brake and engage first gear, reverse gear or **P**.



On vehicles with audio speaker system, the tyre repair kit is stowed together with the tools.



On other versions, the tyre repair kit is stored in a bag.

Loosen the screw and remove the bag.



Take the sealant bottle and the compressor out of the box.



 Remove the electrical connection cable and air hose from the stowage compartments on the underside of the compressor.




Type 1: screw the compressor air hose to the connection on the sealant bottle and fit the sealant bottle into the retainer on the compressor.



Type 2: remove screw plug from the compressor and from the sealant bottle. Screw the bottle on the compressor without removing the tinfoil from the bottle.

- Set the compressor near the tyre in such a way that the sealant bottle is upright.
- 4. Unscrew valve cap from defective tyre.



5. **Type 1:** screw the filler hose to the tyre valve.



**Type 2:** remove protection cap from filler hose and screw the filler hose to the tyre valve. The air

- release valve must be closed (turn clockwise).
- The switch on the compressor must be set to O.
- Connect the compressor plug to the power outlet or cigarette lighter socket.

To avoid discharging the battery, we recommend running the engine.



Set the rocker switch on the compressor to I. The tyre is filled with sealant.

- The compressor pressure gauge briefly indicates up to 6 bar whilst the sealant bottle is emptying (approx. 30 seconds). Then the pressure starts to drop.
- 10. All of the sealant is pumped into the tyre. Then the tyre is inflated.
- 11. The prescribed tyre pressure should be obtained within
  10 minutes. Tyre pressure
  ⇒ 304. When the correct pressure is obtained, switch off the compressor.

Do not run the compressor longer than 10 minutes.

Type 1: if the tyre pressure is not obtained within 10 minutes, remove the tyre repair kit. Move the vehicle one tyre rotation. Reattach the tyre repair kit and continue the filling procedure for 10 minutes. Check tyre pressure once more. If the prescribed tyre pressure is still not obtained, the tyre is too badly damaged. Seek the assistance of a workshop.



If the pressure is obtained within 10 minutes, correct to the prescribed tyre pressure by using the compressor to increase or decrease with the button over the pressure indicator.

Type 2: remove tyre repair kit and drive immediately up to 10 km, but not longer than 10 minutes. Check tyre pressure once more. If the tyre pressure is not obtained, reattach the tyre repair kit and continue the filling procedure for 10 minutes. If the prescribed tyre pressure is still not obtained, the tyre is too badly damaged. Seek the assistance of a workshop.

If the pressure is obtained, correct to the prescribed tyre pressure by using the compressor to increase or decrease by opening the air release valve (turn anticlockwise) at the air filler hose.

12. Detach the tyre repair kit.

**Type 1:** push catch on bracket to remove sealant bottle from bracket. Screw tyre inflation hose to the free connection of sealant bottle. This prevents sealant from escaping.

**Type 2:** Sealant bottle can not be removed from the compressor. Have the sealant bottle replaced by your workshop.

- 13. Stow tyre repair kit in the load compartment.
- 14. Remove any excess sealant using a cloth.
- Take the label indicating maximum permitted speed from the sealant bottle and affix in the driver's field of view.
- Continue driving immediately so that sealant is evenly distributed in the tyre. After driving approx.

10 km (but no more than 10 minutes), stop and check tyre pressure. Screw compressor air hose directly onto tyre valve.



If tyre pressure is more than 1.3 bar, set it to the correct value. Repeat the procedure until there is no more loss of pressure.

If the tyre pressure has fallen below 1.3 bar, the vehicle must not be used. Seek the assistance of a workshop.

- 17. Stow away tyre repair kit in the box.
- 18. Fix the box with the screw.

#### Note

The driving characteristics of the repaired tyre is severely affected, therefore have this tyre replaced.

If unusual noise is heard or the compressor becomes hot, turn compressor off for at least 30 minutes.

The built-in safety valve opens at a pressure of 7 bar.

Note the expiry date of the kit. After this date its sealing capability is no longer guaranteed. Pay attention to storage information on sealant bottle.

Replace the used sealant bottle. Dispose of the bottle as prescribed by applicable laws.

The compressor and sealant can be used from approx. -30 °C.

The adapters supplied can be used to pump up other items e.g. footballs, air mattresses, inflatable dinghies etc. They are located on the underside of the compressor. To remove, screw on compressor air hose and withdraw adapter.

# Wheel changing

Make the following preparations and observe the following information:

- Park the vehicle on a level, firm and non-skid surface. The front wheels must be in the straightahead position.
- Apply the parking brake and engage first gear, reverse gear or P.
- Never change more than one wheel at once.
- Use the jack only to change wheels in case of puncture, not for seasonal winter or summer tyre change.
- The jack is maintenance-free.
- If the ground on which the vehicle is standing is soft, a solid board (max. 1 cm thick) should be placed under the jack.
- Take heavy objects out of the vehicle before jacking up.

- No people or animals may be in the vehicle when it is jacked-up.
- Never crawl under a jacked-up vehicle.
- Do not start the vehicle when it is raised on the jack.
- Clean wheel nuts and thread with a clean cloth before mounting the wheel.

### **△**Warning

Do not grease wheel bolt, wheel nut and wheel nut cone.


 Steel wheels with cover: Pull off the wheel cover.

Alloy wheels: Disengage wheel nut caps with a flat screwdriver and remove. To protect the wheel paint and the cap, wrap a cloth around the screwdriver tip.



Fold out the wheel wrench and install ensuring that it locates securely and loosen each wheel nut by half a turn.

The wheels might be protected by locking wheel nuts. To loosen these specific nuts, first attach the adapter for the locking wheel nuts onto the head of the nut before installing the wheel wrench. The adapter is located in the glovebox.




Ensure the jack is correctly positioned under the relevant vehicle jacking point.



Some versions have sill panellings with covered vehicle

jacking points: pull out the cover at the respective jacking point firstly.



 Set the jack to the necessary height. Position it directly below the jacking point in a manner that prevents it from slipping.



Attach wheel wrench and with the jack correctly aligned rotate wheel wrench until wheel is clear of the ground.

- 5. Unscrew the wheel nuts.
- 7. Screw on the wheel nuts.
- 8. Lower vehicle.
- Install the wheel wrench ensuring that it is located securely and tighten each nut in a crosswise sequence. Tightening torque is 140 Nmfor all models except GSi. GSi models have a tightening torque of 190 Nm

276


 Align the valve hole in the wheel cover with the tyre valve before installing.

Install wheel nut caps.


- 11. Install vehicle jacking point cover.
- 12. Stow and secure the replaced wheel ♀ 276, the vehicle tools ♀ 262 and the adapter for the locking wheel nuts ♀ 73.
- Check the tyre pressure of the installed tyre and the wheel nut torque as soon as possible.

Have the defective tyre renewed or repaired as soon as possible.

#### Jacking position for lifting platform



Rear arm position of the lifting platform centrically under the relevant vehicle jacking point.



Front arm position of the lifting platform centrically under the relevant vehicle jacking point.

# Spare wheel


Some vehicles are equipped with a tyre repair kit instead of a spare wheel.

If mounting a spare wheel, which is different from the other wheels, this wheel might be classified as a temporary spare wheel and the corresponding speed limits apply, even though no label indicates this. Seek the assistance of a workshop to check the applicable speed limit.

The spare wheel has a steel rim.

#### Caution

The use of a spare wheel that is smaller than the other wheels or in combination with winter tyres could affect driveability. Have the defective tyre replaced as soon as possible.




The spare wheel is located in the load compartment beneath the floor covering.

#### To remove:

- 1. Open the floor cover.
- The spare wheel is secured with a wing nut. Turn wing nut anticlockwise and remove the spare wheel.
  - Under the spare wheel there is the box with vehicle tools.
- When, after a wheel change, no wheel is placed in the spare wheel well, secure the tool box by turning right back the wing nut and close the floor cover.
- After wheel change back to full size wheel, place the spare wheel outside up in the well and secure with the wing nut.

# Stowing the replaced full size wheel in the spare wheel well

Secure a damaged full size wheel facing upwards with the wing nut in the spare wheel well after mounting an extension bolt on the thread bolt. The extension bolt is stowed with the vehicle tools \$\dip\$ 262. To secure the wheel:



- Stick the extension bolt onto the thread bolt.
- Store the damaged wheel outside up in the spare wheel well and secure it by turning the wing nut clockwise on the extension bolt.

#### **△**Warning

Storing a jack, a wheel or other equipment in the load compartment could cause injury if they are not fixed properly. During a sudden stop or a collision, loose equipment could strike someone.

Store wheel, jack and tools always in the original storage location and secure them by fixing.

#### Temporary spare wheel

#### Caution

The use of a spare wheel that is smaller than the other wheels or in combination with winter tyres could affect driveability. Have the defective tyre replaced as soon as possible.

Only mount one temporary spare wheel. Do not drive faster than 80 km/h. Take curves slowly. Do not use for a long period of time.

If your vehicle gets a flat tyre on the rear while towing another vehicle, mount the temporary spare wheel in the front and the full tyre in the rear.

Tyre chains \$\dip\$ 269.

#### Spare wheel with directional tyre

Fit directional tyres such that they roll in the direction of travel. The rolling direction is indicated by a symbol (e.g. an arrow) on the sidewall.

The following applies to tyres fitted opposing the rolling direction:

- Driveability may be affected.
   Have the defective tyre renewed or repaired as soon as possible and fit it instead of the spare wheel.
- Drive particularly carefully on wet and snow-covered road surfaces.

# Jump starting

Do not start with quick charger.

A vehicle with a discharged vehicle battery can be started using jump leads and the vehicle battery of another vehicle.

### **△**Warning

Be extremely careful when starting with jump leads. Any deviation from the following instructions can lead to injuries or damage caused by battery explosion or damage to the electrical systems of both vehicles.


#### **△**Warning

Avoid contact of the battery with eyes, skin, fabrics and painted surfaces. The fluid contains sulphuric acid which can cause injuries and damage in the event of direct contact.

 Never expose the vehicle battery to naked flames or sparks.

- A discharged vehicle battery can already freeze at a temperature of 0 °C. Defrost the frozen battery before connecting jump leads.
- Wear eye protection and protective clothing when handling a battery.
- Use a booster battery with the same voltage (12 Volts). Its capacity (Ah) must not be much less than that of the discharged vehicle battery.
- Use jump leads with insulated terminals and a cross section of at least 16 mm<sup>2</sup> (25 mm<sup>2</sup> for diesel engines).
- Do not disconnect the discharged vehicle battery from the vehicle.
- Switch off all unnecessary electrical consumers.
- Do not lean over the vehicle battery during jump starting.
- Do not allow the terminals of one lead to touch those of the other lead.

- The vehicles must not come into contact with each other during the jump starting process.
- Apply the parking brake, transmission in neutral, automatic transmission in P.



Open the positive terminal protection caps of both vehicle batteries.

Lead connection order:

- Connect the red lead to the positive terminal of the booster battery.
- Connect the other end of the red lead to the positive terminal of the discharged battery.

- Connect the black lead to the negative terminal of the booster battery.
- Connect the other end of the black lead to a vehicle grounding point of your vehicle in the engine compartment.


Route the leads so that they cannot catch on rotating parts in the engine compartment.

To start the engine:

- Start the engine of the vehicle providing the jump.
- After five minutes, start the other engine. Start attempts should be made for no longer than 15 seconds at an interval of one minute.
- Allow both engines to idle for approx. three minutes with the leads connected.
- Switch on electrical consumers (e.g. headlights, heated rear window) of the vehicle receiving the jump start.
- 5. Reverse above sequence exactly when removing leads.


# **Towing**

# Towing the vehicle



Wrap a cloth around the tip of a flat screwdriver to prevent paint damage. Insert the screwdriver in the slot at the edge of the cap. Release the cap by levering it out carefully.

The towing eye is stowed with the vehicle tools \$\dip\$ 262.



Screw in the towing eye as far as it will go until it stops in a horizontal position.

Attach a tow rope – or better still a tow rod – to the towing eye.

The towing eye must only be used for towing and not for recovering the vehicle.

Switch on ignition to release steering wheel lock and to permit operation of brake lights, horn and windscreen wiper.

Switch the selector lever to neutral. Release the parking brake.

#### Caution

Drive slowly. Do not drive jerkily. Excessive tractive force can damage the vehicle.

When the engine is not running, considerably more force is needed to brake and steer.

To prevent the entry of exhaust gases from the towing vehicle, switch on the air recirculation and close the windows.

Vehicles with manual transmission and All-wheel drive: If the vehicle is towed with all four wheels on the ground then there are no technical limitations for speed and distance. If only one axle has been raised, the maximum speed is 50 km/h. There is no distance limitation.


Vehicles with automatic transmission and All-wheel drive: The vehicle must be towed facing forwards. If the vehicle is towed with all four wheels on the ground, the maximum speed is 50 km/h and for a maximum of 50 km. If the front axle has been

raised, the maximum speed is 50 km/h. There is no distance limitation.

Seek the assistance of a workshop. After towing, unscrew the towing eye.


linsert cap with the outer flange into the recess and fix cap by pushing.

# Towing another vehicle



Wrap a cloth around the tip of a flat screwdriver to prevent paint damage. Insert the screwdriver in the slot at the edge of the cap. Release the cap by levering it out carefully.

The towing eye is stowed with the vehicle tools \$\dip\$ 262.



Screw in the towing eye as far as it will go until it stops in a horizontal position.

The lashing eye at the rear underneath the vehicle must never be used as a towing eye.

Attach a tow rope – or better still a tow rod – to the towing eye.

The towing eye must only be used for towing and not for recovering a vehicle.

#### Caution

Drive slowly. Do not drive jerkily. Excessive tractive force can damage the vehicle.

After towing, unscrew the towing eye. Insert cap with the upper flange into the recess and fix cap by pushing.

# Appearance care

#### **Exterior care**

#### Locks

The locks are lubricated at the factory using a high quality lock cylinder grease. Use a de-icing agent only when absolutely necessary, as this has a degreasing effect and impairs lock function. After using a de-icing agent, have the locks regreased by a workshop.

## Washing

The paintwork of your vehicle is exposed to environmental influences. Wash and wax your vehicle regularly. When using automatic vehicle washes, select a programme that includes waxing.

Bird droppings, dead insects, resin, pollen and the like should be cleaned off immediately, as they contain aggressive constituents which can cause paint damage.

If using a vehicle wash, comply with the vehicle wash manufacturer's instructions. The windscreen wiper and rear window wiper must be switched off. Remove antenna and external accessories such as roof racks etc.

If you wash your vehicle by hand, make sure that the insides of the wheel housings are also thoroughly rinsed out.

Wax painted parts of the vehicle regularly.

Clean edges and folds on opened doors and the bonnet as well as the areas they cover.

Clean bright metal mouldings with a cleaning solution approved for aluminium to avoid damages.

#### Caution

Always use a cleaning agent with a pH value of four to nine.

Do not use cleaning agents on hot surfaces.

Do not clean the engine compartment with a steam-jet or high-pressure jet cleaner.

Thoroughly rinse and leather-off the vehicle. Rinse leather frequently. Use separate leathers for painted and glass surfaces: remnants of wax on the windows will impair vision.

Have the door hinges of all doors greased by a workshop.

Do not use hard objects to remove spots of tar. Use tar removal spray on painted surfaces.

#### **Exterior lights**

Headlight and other light covers are made of plastic. Do not use any abrasive or caustic agents, do not use an ice scraper, and do not clean them dry.

#### Polishing and waxing

Wax the vehicle regularly (at the latest when water no longer beads). Otherwise, the paintwork will dry out. Polishing is necessary only if the paint has become dull or if solid deposits have become attached to it.

Paintwork polish with silicone forms a protective film, making waxing unnecessary.

Plastic body parts must not be treated with wax or polishing agents.

# Windows and windscreen wiper blades

Use a soft lint-free cloth or chamois leather together with window cleaner and insect remover.

When cleaning the rear window from inside, always wipe in parallel to the heating element to prevent damage.

For mechanical removal of ice, use a sharp-edged ice scraper. Press the scraper firmly against the glass so that no dirt can get under it and scratch the glass.

Clean smearing wiper blades with a soft cloth and window cleaner.

Remove dirt residues from smearing wiper blades by using a soft cloth and window cleaner. Also make sure to remove any residues such as wax, insect residues and similar from the window.

Ice residues, pollution and continuous wiping on dry windows will damage or even destroy the wiper blades.

#### Sunroof

Never clean with solvents or abrasive agents, fuels, aggressive media (e.g. paint cleaner, acetonecontaining solutions etc.), acidic or highly alkaline media or abrasive pads. Do not apply wax or polishing agents to the sunroof.

#### Wheels and tyres

Do not use high-pressure jet cleaners.

Clean rims with a pH-neutral wheel cleaner.

Rims are painted and can be treated with the same agents as the body.

#### Paintwork damage

Rectify minor paintwork damage with a touch-up pen before rust forms. Have more extensive damage or rust areas repaired by a workshop.

#### Underbody

Some areas of the vehicle underbody have a PVC undercoating while other critical areas have a durable protective wax coating.

After the underbody is washed, check the underbody and have it waxed if necessary.

Bitumen/rubber materials could damage the PVC coating. Have underbody work carried out by a workshop.

Before and after winter, wash the underbody and have the protective wax coating checked.

### Liquid gas system

## **△** Danger

Liquid gas is heavier than air and can collect in sink points.

Take care when performing work at the underbody in a pit.

For painting work and when using a drying booth at a temperature above 60 °C, the liquid gas tank must be removed.

Do not make any modifications to the liquid gas system.

#### **Towing equipment**

Do not clean the coupling ball bar with a steam-jet or high-pressure jet cleaner.

#### Interior care

#### Interior and upholstery

Only clean the vehicle interior, including the instrument panel fascia and panelling, with a dry cloth or interior cleaner.

Clean the leather upholstery with clear water and a soft cloth. In case of heavy soiling, use leather care.

The instrument cluster and the displays should only be cleaned using a soft damp cloth. If necessary use a weak soap solution.

#### 284 Vehicle care

Clean fabric upholstery with a vacuum cleaner and brush. Remove stains with an upholstery cleaner.

Clothing fabrics may not be colourfast. This could cause visible discolourations, especially on light-coloured upholstery. Removable stains and discolourations should be cleaned as soon as possible.

Clean seat belts with lukewarm water or interior cleaner.

#### Caution

Close Velcro fasteners as open Velcro fasteners on clothing could damage seat upholstery.

The same applies to clothing with sharp-edged objects, like zips or belts or studded jeans.

#### Plastic and rubber parts

Plastic and rubber parts can be cleaned with the same cleaner as used to clean the body. Use interior cleaner if necessary. Do not use any other agent. Avoid solvents and petrol in particular. Do not use high-pressure jet cleaners.

# Service and maintenance

General information Service information	
Recommended fluids, lubricants and parts	286
Recommended fluids and lubricants	286

# General information

#### Service information

In order to ensure economical and safe vehicle operation and to maintain the value of your vehicle, it is of vital importance that all maintenance work is carried out at the proper intervals as specified.

The detailed, up-to-date service schedule for your vehicle is available at the workshop.

Service display \$\triangle\$ 106.

#### European service intervals

Maintenance of your vehicle is required every 30,000 km or after 1 year, whichever occurs first, unless otherwise indicated in the service display.

A shorter service interval can be valid for severe driving behaviour, e.g. for taxis and police vehicles.

The European service intervals are valid for the following countries:

Andorra, Austria, Belgium, Bosnia-Herzegovina, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Greenland, Hungary, Iceland, Ireland, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Macedonia, Malta, Monaco, Montenegro, Netherlands, Norway, Poland, Portugal, Romania, San Marino, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, United Kingdom.

#### International service intervals

Maintenance of your vehicle is required every 15,000 km or after 1 year, whichever occurs first, unless otherwise indicated in the service display.

Severe operating conditions exist if one or more of the following circumstances occur frequently: Cold starting, stop and go operation, trailer operation, mountain driving, driving on poor and sandy road surfaces, increased air pollution, presence of airborne sand and high dust content, driving at high altitude and large variations of temperature. Under these severe operating conditions, certain service work may be required more frequently than the regular service interval.

The international service intervals are valid for the countries which are not listed in the European service intervals.

Service display \$\times\$ 106.

#### Confirmations

Confirmation of service is recorded in the Service and Warranty Booklet. The date and mileage is completed with the stamp and signature of the servicing workshop.

Make sure that the Service and Warranty Booklet is completed correctly as continuous proof of service is essential if any warranty or goodwill claims are to be met, and is also a benefit when selling the vehicle.

# Service interval with remaining engine oil life duration

The service interval is based on several parameters depending on usage.

The service display lets you know when to change the engine oil. Service display ♀ 106.

# Recommended fluids, lubricants and parts

# Recommended fluids and lubricants

Only use products that meet the recommended specifications.

# **△**Warning

Operating materials are hazardous and could be poisonous. Handle with care. Pay attention to information given on the containers.

### Engine oil

Engine oil is identified by its quality and its viscosity. Quality is more important than viscosity when selecting which engine oil to use. The oil quality ensures e.g. engine cleanliness, wear protection and oil aging control, whereas viscosity grade gives information on the oil's thickness over a temperature range.

Dexos is the newest engine oil quality that provides optimum protection for petrol and diesel engines. If it is unavailable, engine oils of other listed qualities must be used.

Recommendations for petrol engines are also valid for Compressed Natural Gas (CNG), Liquified Petroleum Gas (LPG) and Ethanol (E85) fuelled engines.

#### Topping up engine oil

#### Caution

In case of any spilled oil, wipe it up and dispose it properly.

Engine oils of different manufacturers and brands can be mixed as long as they comply with the required engine oil quality and viscosity.

Use of engine oils for all petrol engines with only ACEA quality is prohibited, since it can cause engine damage under certain operating conditions.

#### Additional engine oil additives

The use of additional engine oil additives could cause damage and invalidate the warranty.

#### Engine oil viscosity grades

The SAE viscosity grade gives information on the thickness of the oil.

Multigrade oil is indicated by two figures, e.g. SAE 5W-30. The first figure, followed by a W, indicates the low temperature viscosity and the second figure the high temperature viscosity.

Select the appropriate viscosity grade depending on the minimum ambient temperature  $\Rightarrow$  291.

All of the recommended viscosity grades are suitable for high ambient temperatures.

#### Coolant and antifreeze

Use only organic acid type-long life coolant (LLC) antifreeze approved for the vehicle. Consult a workshop.

The system is factory filled with coolant designed for excellent corrosion protection and frost protection down to approx. -28 °C. In cold regions with very low temperatures the factory filled coolant provides frost protection down to approx. -37 °C. This concentration should be maintained all year round. The use of additional coolant additives that intend to give additional corrosion protection or seal against minor leaks can cause function problems. Liability for consequences resulting from the use of additional coolant additives will be rejected.

#### Washer fluid

Use only washer fluid approved for the vehicle to prevent damage of wiper blades, paintwork, plastic and rubber parts. Consult a workshop.

#### Brake and clutch fluid

Over time, brake fluid absorbs moisture which will reduce braking effectiveness. The brake fluid should therefore be replaced at the specified interval.

#### **AdBlue**

Only use AdBlue to reduce the nitrogen oxides in the exhaust emission ▷ 172.

289
289
289
290
291
291
294
296
299
302
303
304
308

## Vehicle identification

## Vehicle Identification Number




The Vehicle Identification Number is visible through the windscreen.

The Vehicle Identification Number may be stamped on the identification plate and on the floor pan, under the floor covering, visible under a cover, or in the engine compartment on the right body panel.

## Identification plate



The identification label is located on the front left or right door frame.



Information on identification plate:

- 1 : manufacturer
- 2 : type approval number
- 3 : vehicle identification number
- 4 : permissible gross vehicle weight rating in kg
- 5 : permissible gross train weight in kg
- **6**: maximum permissible front axle load in kg
- 7 : maximum permissible rear axle load in kg
- 8 : vehicle-specific or countryspecific data, e.g. MY = model year

The combined total of front and rear axle loads must not exceed the permissible gross vehicle weight. For example, if the front axle is bearing its maximum permissible load, the rear axle can only bear a load that is equal to the gross vehicle weight minus the front axle load.

The technical data is determined in accordance with European Community standards. We reserve the right to make modifications.

Specifications in the vehicle documents always have priority over those given in this manual.

## Engine identification

The technical data tables use the engine identifier code. The engine data table additionally shows the engineering code. Engine data 

⇒ 294.

To identify the respective engine, refer to the EEC Certificate of Conformity provided with your vehicle or other national registration documents.

The Certificate of Conformity shows the engine identifier code, other national publications may show the engineering code. Check piston displacement and engine power to identify the respective engine.

## Vehicle data Recommended fluids and lubricants

#### European service schedule

#### Required engine oil quality

#### 

Engine oil quality	Petrol engines (including CNG, LPG, E85)	Diesel engines
dexos1 Gen2	✓	
dexos2	-	✓

Diesel engines only: In case dexos quality is unavailable, you may use max. one litre engine oil quality ACEA C3 once between each oil change.

#### Engine oil viscosity grades

#### 

Ambient temperature	Petrol and diesel engines
down to -25 °C	SAE 0W-30 or SAE 0W-40
	SAE 5W-30 or SAE 5W-40
below -25 °C	SAE 0W-30 or SAE 0W-40

#### International service schedule

#### Required engine oil quality

#### 

Engine oil quality Petrol engines (including CNG, LPG, E85)		Diesel engines
dexos1 Gen2	<b>√</b>	-
dexos2	-	✓

In case dexos quality is unavailable you may use the oil qualities listed below:

### 

Engine oil quality	Petrol engines	Diesel engines
	(including CNG, LPG, E85)	
ACEA A3/B4	-	✓
ACEA C3	7	✓

## Engine oil viscosity grades

#### 

Ambient temperature	Petrol and diesel engines
down to -25 °C	SAE 0W-30 or SAE 0W-40
	SAE 5W-30 or SAE 5W-40

	All countries with international service interval ⊅ 285
below -25 °C	SAE 0W-30 or SAE 0W-40
down to -20 °C	SAE 10W-30 <sup>1)</sup> or SAE 10W-40 <sup>1)</sup>

<sup>1)</sup> Permitted, but usage of oils with dexos quality is recommended.

## Engine data

Engine identifier code	B15XHL	B15XHT	B20NFT
Sales designation	1.5T	1.5T	2.0T
Engineering code	B15XHT	B15XHT	B20NFT
Piston displacement [cm³]	1490	1490	1998
Engine power [kW]	103	121	191
at rpm	5600	5600	5500
Torque [Nm]	250	250	400
at rpm	2000-4100	2000-4500	3000-4000
Fuel type	Petrol	Petrol	Petrol
Octane rating RON <sup>2)</sup>			
recommended	95	95	95
possible	98	98	98
possible	91	91	91
Additional fuel type	_	_	_

<sup>2)</sup> A country-specific label at the fuel filler flap can supersede the engine-specific requirement.

			Techni	cal data 295
Engine identifier code	B16DTE	B16DTH	B20DTH	D20DTR
Sales designation	1.6	1.6	2.0	2.0
Engineering code	B16DTE	B16DTH	B20DTH	D20DTR
Piston displacement [cm³]	1598	1598	1956	1956
Engine power [kW]	81	100	125	154
at rpm	3500	3500-4000	3750	4000
Torque [Nm]	300	320	400	480
at rpm	1750-2000	2000-2250	1750-2500	1500
Fuel type	Diesel	Diesel	Diesel	Diesel

## Performance

## **Grand Sport**

Engine	B15XHL	B15XHT	B20NFT
Maximum speed [km/h]			_
Manual transmission	210/213 <sup>3)</sup>	222/225 <sup>3)</sup>	-
Automatic transmission	_	218	250

3) ECO

Engine	B16DTE	B16DTH	B20DTH FWD <sup>4)</sup>	B20DTH AWD <sup>5)</sup>	D20DTR
Maximum speed [km/h]					_
Manual transmission	201/205 3)	211	226	223	_
Automatic transmission	_	203	223	_	233

<sup>3)</sup> ECO

<sup>4)</sup> Front wheel drive5) All wheel drive

Engine	B15XHL	B15XHT	B20NFT	
Maximum speed [km/h]				
Manual transmission	207/210 <sup>3)</sup>	218/221 <sup>3)</sup>	_	
Automatic transmission	_	214	245	

3) ECO

Engine	B16DTE	B16DTH	B20DTH FWD <sup>4)</sup>	B20DTH AWD <sup>5)</sup>	D20DTR
Maximum speed [km/h]					
Manual transmission	201	212	223	220	_
Automatic transmission	-	204	220	-	231

<sup>4)</sup> Front wheel drive5) All wheel drive

## **Country Tourer**

Engine	B15XHL	B15XHT	B20NFT
Maximum speed [km/h]			
Manual transmission	203	213	_
Automatic transmission	_	210	242
Engine	B20DTH FWD <sup>4)</sup>	B20DTH AWD <sup>5)</sup>	D20DTR
Maximum speed [km/h]			
Manual transmission	220	218	-
Automatic transmission	218		228

<sup>4)</sup> Front wheel drive

<sup>5)</sup> All wheel drive

## Vehicle weight

### Kerb weight, basic model without any optional equipment

Grand Sport	Engine	Manual transmission	Automatic transmission	
[kg]	B15XHL	1440/1456 <sup>6)</sup>	——————————————————————————————————————	
	B15XHT	1441/1472 <sup>6)</sup>	1472	
	B20NFT	-	1649/1683 <sup>7)</sup>	
[kg]	B16DTE	1487/1503 <sup>6)</sup>	_	
	B16DTH	1503	1522	
	B20DTH	1582	1613	
	B20DTH AWD <sup>8)</sup>	1683	-	
	D20DTR	_	1733/1772 <sup>7)</sup>	

<sup>6)</sup> ECO

Optional equipment and accessories increase the kerb weight.

<sup>7)</sup> GSi

<sup>8)</sup> All wheel drive

Kerb weight, basic model without any optional equipment

Sports Tourer	Engine	Manual transmission	Automatic transmission	
[kg]	B15XHL	1487	——————————————————————————————————————	
	B15XHT	1487/1503 <sup>6)</sup>	1522	
	B20NFT	_	1683/1716 <sup>7)</sup>	
[kg]	B16DTE	1522	-	
	B16DTH	1537	1567	
	B20DTH	1633	1666	
	B20DTH AWD <sup>8)</sup>	1716	-	
	D20DTR	_	1772/1807 <sup>7)</sup>	

<sup>6)</sup> ECO

Optional equipment and accessories increase the kerb weight.

<sup>7)</sup> GSi

<sup>8)</sup> All wheel drive

### Kerb weight, basic model without any optional equipment

Country Tourer	Engine	Manual transmission	Automatic transmission	
[kg]	B15XHL	1522	- -	
	B15XHT	1522	1552	
	B20NFT	_	1699	
[kg]	B20DTH	1666	1666	
	B20DTH AWD <sup>8)</sup>	1716	-	
	D20DTR	-	1807	

<sup>8)</sup> All wheel drive

Optional equipment and accessories increase the kerb weight. Loading information  $\diamondsuit$  86.

## Vehicle dimensions

	Grand Sport	Sports Tourer, Country Tourer
Length minmax. [mm]	4897	4986-5004 <sup>9)</sup>
Width with folded exterior mirrors [mm]	1941	1941
Width with unfolded exterior mirrors [mm]	2093	2093
Height (without antenna) [mm]	1425-1485 <sup>10)</sup>	1450-1550 <sup>10)</sup>
Vehicle height - Rear compartment open [mm]	2123	2065-2088 <sup>9)</sup>
Length of load compartment floor [mm]	1133	1178
Length of load compartment with folded rear seats [mm]	1940	2005
Load compartment width [mm]	1030	1030
Load compartment height [mm]	497	384
Wheelbase [mm]	2829	2829
Turning circle diameter [m]	11.75	11.75

 <sup>9)</sup> Minimum length for standard version, maximum length for Country Tourer version.
 10) Depending on body- and equipment variants.

## Capacities

## Engine oil

Engine	B15XHL	B15XHT	B20NFT
including filter [l]	4.0	4.0	5.7
between MIN and MAX [I]	1.0	1.0	1.0

Engine	B16DTE	B16DTH	B20DTH	D20DTR
including filter [I]	5.0	5.0	5.25	4.5
between MIN and MAX [I]	1.0	1.0	1.0	1.0

## Fuel tank

Petrol/diesel, refilling quantity [l]	61
---------------------------------------	----

## AdBlue tank

AdBlue, refilling quantity [I] 15

## Tyre pressures

Tyre pressures differ depending on the model variant. The order of the listed car models is as follows:

- Vehicles with Front-wheel drive
- Vehicles with All-wheel drive

Refer to the table header to find the correct tyre pressure for your model.

## Tyre pressures for vehicles with Front-wheel drive

Grand Sport, Sports Tourer, Country Tourer

		Comfort with up to 3 people		ECO with up to 3 people		With full load	
Engine	Tyres	front	rear	front	rear	front	rear
		[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])
B15XHT, B16DTE,	215/60 R16, 225/55 R17, 215/55 R17, 235/45 R18, 235/50 R18 <sup>11)</sup> , 245/45 R18	220/2.2 (32)	220/2.2 (32)	270/2.7 (39)	270/2.7 (39)	240/2.4 (35)	270/2.7 (39)
B20DTH	225/55 R17, 235/50 R18 <sup>11)</sup> , 245/45 R18	220/2.2 (32)	220/2.2 (32)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
	235/45 R18, 245/35 R20	230/2.3 (33)	230/2.3 (33)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
All	Temporary spare wheel 125/80 R16, 125/70 R17	420/4.2 (60)	420/4.2 (60)	-	-	420/4.2 (60)	420/4.2 (60)

<sup>11)</sup> Country Tourer only

## Tyre pressures for vehicles with All-wheel drive

Grand Sport, Sports Tourer, Country Tourer


		Comfort with up to 3 people ECO with up to 3 people		With full load	With full load		
Engine	Tyres	front	rear	front	rear	front	rear
		[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])
B20NFT	245/45 R18, 235/50 R18 <sup>11)</sup> 245/35 ZR20	230/2.3 (33)	230/2.3 (33)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
	235/45 R18	250/2.5 (36)	250/2.5 (36)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
B20DTH	225/55 R17, 245/45 R18, 235/50 R18 <sup>11)</sup>	220/2.2 (32)	220/2.2 (32)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
	235/45 R18, 245/35 R20	230/2.3 (33)	230/2.3 (33)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)

		Comfort with	up to 3 people	ECO with up	to 3 people	With full load	d
Engine	Tyres	front	rear	front	rear	front	rear
		[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])	[kPa/bar] ([psi])
D20DTR	225/55 R17, 245/45 R18, 235/50 R18 <sup>11)</sup>	230/2.3 (33)	230/2.3 (33)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
	235/45 R18	250/2.5 (36)	250/2.5 (36)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
	245/35 R20	240/2.4 (35)	240/2.4 (35)	270/2.7 (39)	270/2.7 (39)	260/2.6 (38)	290/2.9 (42)
All	Temporary spare wheel 125/80 R16, 125/70 R17	420/4.2 (60)	420/4.2 (60)	-	-	420/4.2 (60)	420/4.2 (60)


<sup>11)</sup> Country Tourer only

## Towing hitch installation dimensions

## Grandsport



## **Sports Tourer, Country Tourer**



## Customer information

Customer information	310
Declaration of conformity	310
REACH	314
Collision damage repair	314
Software acknowledgement	314
Software update	316
Registered trademarks	316
Vehicle data recording and pri-	
vacy	317
Event data recorders	
Radio Frequency Identification	
(RFID)	320

## **Customer information**

## **Declaration of conformity**

#### Radio transmission systems

This vehicle has systems that transmit and/or receive radio waves subject to Directive 1999/5/EC or 2014/53/EU. These systems are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC or 2014/53/EU. The full text of the EU declaration of conformity for each system is available at the following internet address: www.opel.com/conformity

Importer is Opel / Vauxhall, Bahnhofsplatz,

65423 Ruesselsheim am Main, Germany.

#### Antenna

Laird

Daimlerring 31, 31135 Hildesheim, Germany

Operation frequency: N/A Maximum output: N/A

#### Antenna

Kathrein Automotive GmbH

Roemerring 1, 31137 Hildesheim, Germany

Operation frequency: N/A

Maximum output: N/A

#### Electronic key receiver

**Denso Corporation** 

Waldeckerstaße 11, 64546 Mörfelden-Walldorf, Germany

Operation frequency: 125 kHz

Maximum output: -0.14 dBm

#### Electronic key transmitter

**Denso Corporation** 

1-1, Showa-cho, Kariya-shi, Aichiken 448-8661, Japan

Operation frequency: 433.92 MHz

Maximum output: -5.88 dBm

#### Immobiliser

Robert Bosch GmbH

Robert Bosch Platz 1, 70839

Gerlingen, Germany

Operation frequency: 125 kHz

Maximum output: 5.1 dBuA/m @ 10 m

#### Infotainment system R 4.0 IntelliLink LGE

LG Electronics European Shared Service Center B.V., Kriigsman 1. 1186 DM Amstelveen. The Netherlands

Operation Maximum output frequency (MHz) (dBm) 2400.0 - 2483.5 4 2400.0 - 2483.5 5725.0 - 5850.0 13

#### Infotainment system Navi 900 IntelliLink

Robert Bosch Car Multimedia GmbH Robert-Bosch-Straße 200, 31139 Hildesheim, Germany

Operation Maximum output frequency (MHz) (dBm) 2400.0 - 2480.0 10 2400.0 - 2480.0

20

Delphi Deutschland GmbH 42367 Wuppertal, Germany Operation frequency: N/A Maximum output: N/A

### OnStar module

I GF

LG Electronics European Shared Service Center B.V., Krijgsman 1, 1186 DM Amstelveen. The Netherlands

Operation frequency (MHz)	Maximum output (dBm)
2402 - 2480	4
2412 - 2462	18
880 - 915	33
1710 - 1785	24
1850 - 1910	24
1920 - 1980	24
2500 - 2570	23

#### Parking heater remote control receiver

Webasto Thermo & Comfort SF

Friedrichshafener Str. 9, 82205 Gilching, Germany Operation frequency: N/A Maximum output: N/A

#### Parking heater remote control transmitter

Webasto Thermo & Comfort SF Friedrichshafener Str. 9, 82205 Gilching, Germany

Operation frequency: 869.0 MHz Maximum output: 14 dBm

#### Radar unit

Continental Automotive GmbH ADC Automotive Distance Control Systems GmbH, Peter-Dornier-Strasse 10, 88131 Lindau, Germany Operation frequency: 76-77 Ghz

Maximum output: 35 EIRP dBm

#### Radar unit

Hella KGaA Hueck & Co. Rixbecker Straße 75, 59552 Lippstadt Operation frequency:

24.05-24.25 Ghz

#### 312 Customer information

Maximum output: 20 EIRP dBm

#### Radio remote control transmitter

Robert Bosch GmbH

Robert Bosch Platz 1, 70839

Gerlingen, Germany

Operation frequency: 433.92 MHz

Maximum output: -4 dBm

#### Radio remote control receiver

Robert Bosch GmbH

Robert Bosch Platz 1, 70839 Gerlingen, Germany

Operation frequency: N/A

Maximum output: N/A

#### Tyre pressure sensors

Schrader Electronics Ltd.

11 Technology Park, Belfast Road, Antrim BT41 1QS, Northern Ireland, United Kingdom

Operation frequency: 433.92 MHz

Maximum output: 10 dBm

## Jack



#### **REACH**

Registration, Evaluation,
Authorisation and Restriction of
Chemicals (REACH) is a European
Union regulation adopted to improve
the protection of human health and
the environment from the risks that
can be posed by chemicals. Visit
www.opel.com/reach for further
information and for access to the
Article 33 communication.

## Collision damage repair Opel Exclusive paint

#### Note

Differing from standard vehicle paints, paint thickness may vary over the whole body due to manual paint operation.



A colour code label with information about the individual Opel Exclusive paint formula is placed in the spare wheel well.

## Software acknowledgement

Certain OnStar components include libcurl and unzip software and other third party software. Below are the notices and licenses associated with libcurl and unzip and for other third party software please see http://www.lg.com/global/support/opensource/index.

#### libcurl

Copyright and permission notice Copyright (c) 1996 - 2010, Daniel Stenberg, <daniel@haxx.se>.

All rights reserved.

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

The software is provided "as is", without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose and noninfringement of third party rights. In no event shall the authors or copyright holders be liable for any claim, damages or other liability, whether in an action of contract, tort or otherwise, arising from, out of or in connection with the software or the use or other dealings in the software.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other

dealings in this Software without prior written authorization of the copyright holder.

#### unzip

This is version 2005-Feb-10 of the Info-ZIP copyright and license. The definitive version of this document should be available at ftp://ftp.info-zip.org/pub/infozip/license.html indefinitely.

Copyright (c) 1990-2005 Info-ZIP. All rights reserved.

For the purposes of this copyright and license, "Info-ZIP" is defined as the following set of individuals:

Mark Adler, John Bush, Karl Davis, Harald Denker, Jean-Michel Dubois, Jean-loup Gailly, Hunter Goatley, Ed Gordon, Ian Gorman, Chris Herborth, Dirk Haase, Greg Hartwig, Robert Heath, Jonathan Hudson, Paul Kienitz, David Kirschbaum, Johnny Lee, Onno van der Linden, Igor Mandrichenko, Steve P. Miller, Sergio Monesi, Keith Owens, George Petrov, Greg Roelofs, Kai Uwe Rommel, Steve Salisbury, Dave Smith. Steven M. Schweda. Christian

Spieler, Cosmin Truta, Antoine Verheijen, Paul von Behren, Rich Wales, Mike White.

This software is provided "as is," without warranty of any kind, express or implied. In no event shall Info-ZIP or its contributors be held liable for any direct, indirect, incidental, special or consequential damages arising out of the use of or inability to use this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

- Redistributions of source code must retain the above copyright notice, definition, disclaimer, and this list of conditions.
- 2. Redistributions in binary form (compiled executables) must reproduce the above copyright notice, definition, disclaimer, and this list of conditions in documentation and/or other materials provided with the distribution. The sole exception to this condition is redistribution of a

- standard UnZipSFX binary (including SFXWiz) as part of a self-extracting archive; that is permitted without inclusion of this license, as long as the normal SFX banner has not been removed from the binary or disabled.
- 3. Altered versions--including, but not limited to, ports to new operating systems, existing ports with new graphical interfaces, and dynamic, shared, or static library versions--must be plainly marked as such and must not be misrepresented as being the original source. Such altered versions also must not be misrepresented as being Info-ZIP releases--including, but not limited to, labeling of the altered versions with the names "Info-ZIP" (or any variation thereof. including, but not limited to, different capitalizations), "Pocket UnZip." "WiZ" or "MacZip" without the explicit permission of Info-ZIP. Such altered versions are further prohibited from misrepresentative

use of the Zip-Bugs or Info-ZIP email addresses or of the Info-ZIP URL(s).

 Info-ZIP retains the right to use the names "Info-ZIP," "Zip," "UnZip," "UnZipSFX," "WiZ," "Pocket UnZip," "Pocket Zip," and "MacZip" for its own source and binary releases.

## Software update

The Infotainment system can download and install selected software updates over a wireless connection.

#### Note

The availability of these over-the-air vehicle software updates varies by vehicle and country. Find more information on our home page.

#### Internet connection

Downloading over-the-air vehicle software updates requires internet connectivity, which can be accessed through the vehicle's built-in OnStar connection or another passwordprotected Wi-Fi hotspot, e.g. provided by a mobile phone.

To connect the Infotainment system to a hotspot, select **Settings** on the home screen, **Wi-Fi** and then **Manage Wi-Fi Networks**. Select the desired Wi-Fi network, and follow the onscreen prompts.

#### **Updates**

The system will prompt for certain updates to be downloaded and installed. There is also an option to check for updates manually.

To manually check for updates, select **Settings** on the home screen, **Software Information** and then **System Update**. Follow the on-screen prompts.

#### Note

Steps for downloading and installing updates may vary by vehicle.

#### Note

During the installation process, the vehicle may not be operational.

### Registered trademarks

#### Apple Inc.

Apple CarPlay™ is a trademark of Apple Inc.

App Store® and iTunes Store® are registered trademarks of Apple Inc.

iPhone®, iPod®, iPod touch®, iPod nano®, iPad® and Siri® are registered trademarks of Apple Inc.

#### Bluetooth SIG, Inc.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

#### DivX, LLC

DivX® and DivX Certified® are registered trademarks of DivX, LLC.

#### EnGIS Technologies, Inc.

BringGo® is a registered trademark of EnGIS Technologies, Inc.

#### Google Inc.

Android™ and Google Play™ Store are trademarks of Google Inc.

#### Stitcher Inc.

Stitcher™ is a trademark of Stitcher, Inc.

Verband der Automobilindustrie e.V. AdBlue<sup>®</sup> is a registered trademark of the VDA.

## Vehicle data recording and privacy

#### **Event data recorders**

Electronic control units are installed in your vehicle. Control units process data which is received by vehicle sensors, for example, or which they generate themselves or exchange amongst themselves. Some control units are necessary for the safe functioning of your vehicle, others assist you while you drive (driver assistance systems), while others provide comfort or infotainment functions

#### Operating data in the vehicle

Control units process data for operation of the vehicle.

This data includes, for example:

- Vehicle status information (e.g. wheel rotation rate, speed, movement delay, lateral acceleration, "seatbelts fastened" display),
- Ambient conditions (e.g. temperature, rain sensor, distance sensor).

Most of this data is volatile and is processed only in the vehicle itself, and not beyond the operating time.

Moreover, many control units include data storage device (amongst others the vehicle key). This is used to allow information to be documented temporarily or permanently on vehicle condition, component stress, maintenance requirements and technical events and errors.

The following information, for example, is stored:

- System component operating states (e.g. fill level, tyre pressure, battery status),
- State of charge of the high voltage battery, estimated range (in the case of electric vehicles),

- Faults and defects in important system components (e.g. lights, brakes).
- System reactions in special driving situations (e.g. triggering of an airbag, actuation of the stability control systems),
- Information on events damaging the vehicle.

In special cases (e.g. if the vehicle has detected a malfunction), it may be necessary to save data that would otherwise just be volatile.

When you use services, the operating data saved can be read together with the vehicle identification number and used if necessary. Staff working for the service net-work (e.g. garages, manufacturers) or third parties (e.g. breakdown services) can read the data from the vehicle. Services include repair services, maintenance processes, warranty cases and quality assurance measures.

Data is generally read via the OBD (On-Board Diagnostics) port prescribed by law in the vehicle. The operating data which has been read out documents the technical condition of the vehicle or individual components and assists with fault diagnosis, compliance with warranty obligations and quality improvement. This data, in particular information on component stress, technical events, operator errors and other faults, is transmitted to the manufacturer where appropriate, together with the vehicle identification number. The manufacturer is also subject to product liability. The manufacturer potentially also needs operating data from vehicles for product recalls.

Fault memories in the vehicle can be reset by a service company when carrying out servicing or repairs.

#### Comfort and infotainment functions

Comfort settings and custom settings can be stored in the vehicle and changed at any time.

Depending on the equipment level in question, these include

- Seat and steering wheel position settings.
- Chassis and air conditioning settings.
- Custom settings such as interior liahtina.

You can input your own data in the infotainment functions for your vehicle as part of the selected features.

Depending on the equipment level in question, these include

- Multimedia data such as music. videos or photos for playback in an integrated multimedia system,
- Address book data for use with an integrated hands-free system or an integrated navigation system.
- Input destinations,
- Data on the use of online services.

This data for comfort and infotainment functions can be stored locally in the vehicle or be kept on a

device that you have connected to the vehicle (e.g. a smartphone, USB stick or MP3 player). Data that you have input yourself can be deleted at any time.

This data can only be transmitted out of the vehicle at your request, particularly when using online services in accordance with the settings selected by you.

## Smartphone integration, e.g. Android Auto or Apple CarPlay

If your vehicle is equipped accordingly, you can connect your smartphone or another mobile device to the vehicle so that you can control it via the controls integrated in the vehicle. The smartphone image and sound can be output via the multimedia system in this case. At the same time, specific information is transmitted to your smartphone. Depending on the type of integration, this includes data such as position data, day / night mode and other general vehicle information. For more

information, please see the operating instructions for the vehicle / infotainment system.

Integration allows selected smartphone apps to be used, such as navigation or music playback. No further integration is possible between smartphone and vehicle, in particular active access to vehicle data. The nature of further data processing is determined by the provider of the app used. Whether you can define settings, and if so which ones, is dependent on the app in question and your smartphone's operating system.

#### Online services

If your vehicle has a radio network connection, this allows data to be exchanged between your vehicle and other systems. The radio network connection is made possible by means of a transmitter device in your vehicle or a mobile device provided by you (e.g. a smartphone). Online functions can be used via this radio network connection. These include online services and applications / apps provided to you by the manufacturer or other providers.

#### Services of the manufacturer

In the case of the manufacturer's online services, the relevant functions are described by the manufacturer in an appropriate location (e.g. Owner's Manual, the manufacturer's website) and the associated data protection information is provided. Personal data may be used to provide online services. Data exchange for this purpose takes place via a protected connection, e.g. using the manufacturer's IT systems provided for the purpose. Collection,

processing and use of personal data for the purposes of preparation of services take place solely on the basis of legal permission, e.g. in the case of the eCall emergency communication system or a contractual agreement, or by virtue of consent.

You can activate or deactivate the services and functions (which are subject to charges to some extent) and, in some cases, the vehicle's entire radio network connection. In particular, this does not include statutory functions and services such as eCall.

#### Third party services

If you make use of online services from other providers (third parties), these services are subject to the liability and data protection and usage conditions of the provider in question. The manufacturer frequently has no influence over the content exchanged in this regard.

Therefore, please note the nature, scope and purpose of the collection and use of personal data within the scope of third party services provided by the service provider in question.

## Radio Frequency Identification (RFID)

RFID technology is used in some vehicles for functions such as tyre pressure monitoring and ignition system security. It is also used in connection with conveniences such as radio remote controls and electronic keys for door locking/ unlocking and starting, and in-vehicle transmitters for garage door openers. RFID technology in Opel vehicles does not use or record personal information or link with any other Opel system containing personal information.

# Index

Α
Accessories and vehicle
modifications
Active bonnet71
Active emergency braking 203
Adaptive cruise control 113, 192
AdBlue111, 172
Adjustable air vents 159
Airbag and belt tensioners 108
Airbag deactivation 63, 108
Airbag label58
Airbag system 58
Air conditioning regular
operation 161
Air conditioning system 150
Air intake 160
Air vents
All-wheel drive
Antilock brake system 180
Antilock brake system (ABS) 110
Anti-theft alarm system 34
Anti-theft locking system 34
Appearance care
Armrest 53, 55
Armrest storage74
Ashtrays 97
Automatic anti-dazzle39
Automatic dimming 38
Automatic light control 137
Automatic locking27

Automatic transmissionAutostopAuxiliary heater	167
B Baselevel display	148 126 56 172 241 286 109 182 244 244 279
C Capacities	81 171 25 147 74 268 109 28
1000110113	07

Child restraints       64         Child restraint systems       64         Climate control       16         Clock       93         Collision damage repair       314         Control indicators       107         Control of the vehicle       163         Controls       89         Convex shape       37         Coolant and antifreeze       286         Cruise control       113, 189         Cupholders       73         Curtain airbag system       62         Curve lighting       140         D       Danger, Warnings and Cautions       4         Daytime running lights       140         Declaration of conformity       310         DEF       172         Diesel exhaust fluid       172         Diesel fuel system bleeding       246	E Electric adjustment	F   First aid kit
Diesel particle filter	Engine oil pressure       111         Entry lighting       147         Event data recorders       317         Exit lighting       147         Exterior care       281         Exterior light       112         Exterior lighting       13, 136         Exterior mirrors       37	Gauges

Headlight flash
Horn 14, 90
Identification plate
Instrument panel illumination 257 Instrument panel illumination control

Interactive driving system.186Interior care.283Interior lighting.145Interior lights.145, 257Interior mirrors.39Introduction.3
Jump starting278
K Key, memorised settings
L Lane change alert
M Malfunction indicator light

Manual transmission  Massage  Memorised settings  Midlevel display  Mirror adjustment  Misted light covers	55 25 114 8
<b>N</b> New vehicle running-in Number plate light	
Object detection systems	104 291 131 93
P Panoramic view system	169 209 181 144 170 113 296 241
Power button Power outlets	

D		01 1 1 1
Power seat adjustment 50	S	Stop-start system
Power windows40	Safety belts56	Storage73
Preheating 111	Safety net81	Storage compartments73
Puncture	Seat adjustment6	Sunglasses storage74
	Seat belt 8	Sunroof 43
Q	Seat belt reminder 107	Sunvisor lights 147
Quickheat159	Seat belts56	Sun visors 42
R	Seat heating	Symbols 4
	Seat heating, front54	,
Radio Frequency Identification	Seat heating, rear55	T
(RFID)320	Seat position47	Tachometer 105
Radio remote control21		Tail lights251
REACH314	Selective catalytic reduction 172	Three-point seat belt57
Reading lights 146	Service	Tools
Rear cross traffic alert 223	Service display	Tow bar235
Rear floor storage cover 80	Service information	Towing
Rear fog light 113, 144	Side airbag system 62	Towing another vehicle 280
Rear seats55	Side blind spot alert215	Towing equipment
Rear storage80	Sidelights136	Towing hitch installation
Rear view camera 221	Side turn lights256	dimensions
Rear window wiper and washer 92	Software acknowledgement 314	
Recommended fluids and	Software update316	Towing the vehicle
lubricants 286, 291	Spare wheel 276	Traction Control system
Refuelling233	Speed limiter 113, 190	Traction Control system off 111
Registered trademarks316	Speedometer 103	Traffic sign assistant 113, 224
Poteined newer off 165	Starting and operating 163	Trailer coupling235
Retained power off	Starting off18	Trailer stability assist 238
Reversing lights	Starting the engine 165	Trailer towing 235
Ride control systems	Steering	Transmission 17
Roof43	Steering wheel adjustment 9, 89	Tread depth268
Roof load86	, ,	Trip odometer 104
Roof rack 85	Steering wheel controls 89	•

Turn lights	. 269 . 264 . 264 , 265 . 304
U Ultrasonic parking assist Upholstery Uplevel display Using this manual	. 283 . 114
V Valet mode Vehicle battery Vehicle checks Vehicle data Vehicle data recording and	. 245 . 241
vehicle detected ahead	. 113 . 302 . 289 . 262 . 125 . 127 34 3

W         Warning chimes       126         Warning lights       103         Warning triangle       84         Washer and wiper systems       14         Washer fluid       244         Wheel changing       274         Wheel covers       268         Wheels and tyres       263         Windows       40         Windscreen       40         Windscreen wiper and washer       90         Winter tyres       263         Wiper blade replacement       246	Vehicle tools	6 299
	Warning chimes Warning lights Warning triangle Washer and wiper systems Washer fluid Wheel changing Wheel covers Wheels and tyres Windows Windscreen Windscreen wiper and washer Winter tyres	103 84 14 244 274 268 263 40 40 90 263

#### www.opel.com

Copyright by Opel Automobile GmbH, Rüsselsheim, Germany.

The information contained in this publication is effective as of the date indicated below. Opel Automobile GmbH reserves the right to make changes to the technical specifications, features and design of the vehicles relative to the information in this publication as well as changes to the publication itself.

Edition: January 2018, Opel Automobile GmbH, Rüsselsheim.

Printed on chlorine-free bleached paper.

ID-OINBOBSE1801-en

